



Owner's Manual

Wireless Speaker

WS-B1A

EN

Thank you for purchasing this Yamaha product.


This wireless speaker is a Bluetooth® speaker that you can take anywhere you like and enjoy music from a smart device whenever you want to.

Be sure to read the included Safety Brochure to ensure proper and safe use. Keep it readily available for future reference.

CONTENTS

Included accessories	3
Control buttons	4
Charging the unit	5
Turning on the unit	6
Connecting a Bluetooth® device	7
Troubleshooting	8
Restarting or initializing the unit	12
List of lamp displays	13
Specifications	15

Included accessories



USB cable
(for charging the unit; 1 m,
Type A to Type C)



Quick Start Guide




Safety Brochure

Control buttons



Power button

Power lamp



▶ Play/Pause button

During playback, press the button twice quickly to skip to the next song, or three times to skip backward to the beginning of the current song or previous song.

-/+ Volume buttons

Adjust the volume.

Clear Voice lamp

Clear Voice button

When the Clear Voice function is enabled, the Clear Voice lamp glows, and human voices such as dialog in the audio can be heard more clearly.


Charging the unit



Do not charge the unit when it is wet. Charging with liquid or foreign matter on the terminals may cause fire, explosion, liquid leakage, electric shock, or malfunction.

Use a commercially available USB power adapter that can output DC 5 V (2 A or more) when charging the unit.

A charging cradle (Yamaha CC-T1A; sold separately) can also be used to charge the unit.



1 Connect the Type-C connector of the USB cable to the USB port on this unit.

2 Connect the Type-A connector of the USB cable to the USB power adapter.


3 Plug in the USB power adapter to an AC wall outlet.

The power lamp glows orange and charging will start. When charging is completed, the power lamp turns off.

NOTE

- When charging with a DC 5 V (2 A or more) USB power adapter, the charging time is approximately three hours. Charging time varies depending on the usage environment and conditions.
- If the unit is charged while it is playing at a high volume, the remaining battery may decrease. Turn down the volume or turn off the unit and wait until charging is complete, and then use it.

Turning on the unit



Hold down the power button to turn on the unit.

The power lamp flashes to inform you of the remaining battery level.

- Flashing white: Remaining battery level is more than half.
- Flashing orange: Remaining battery level is less than half.

After showing the remaining battery level, the unit turns on. To turn off the unit, press and hold the power button again

NOTE

- If the Play/Pause button (▶) is pressed for at least five seconds while the unit is on, the power lamp and a melody inform you of the remaining battery level.

Remaining battery level	Power lamp	Melody
More than half	Flashes white	Long sound
Less than half	Flashes orange	Medium length sound
Less than 20%		Short sound

- This unit will automatically switch to standby in any of the following situations (Auto Standby):
 - No playback for 20 minutes or more
 - No operation for eight hours or more, regardless of playback

Sound guide (default setting: enabled)

A melody will inform you of the status of this unit, such as when the power is turned on or when a Bluetooth device is connected.

To disable the Sound Guide, hold down the Clear Voice button (☞ p. 4) for at least three seconds. The Sound Guide switches between enabled and disabled each time the button is held down.

Connecting a Bluetooth® device

A Bluetooth device can be connected when the power lamp is flashing blue.


NOTE

- If other Bluetooth devices have been connected before, the unit will connect to the last connected device when the unit is turned on. To connect a new Bluetooth device, disconnect the currently connected Bluetooth device and then connect the new device.
- To terminate the Bluetooth connection from this unit, press the volume (–) button and Play/Pause (▶) (☞ p. 4) button simultaneously for at least five seconds.

1 On the Bluetooth device, enable the Bluetooth function.

2 On the Bluetooth device, select this unit (Yamaha WS-B1A) from the list of available devices to connect to.

If a passkey is required, enter the number “0000”.



When the connection is established, the power lamp glows blue.

3 Play audio content on the Bluetooth device.



Troubleshooting

Try following the instructions described in “Troubleshooting” first when the unit does not function properly. If an error occurs, the lamp flashes to notify you. See “List of lamp displays” (☞ p. 13) for details.

If the unit does not function properly after following the instructions to solve the problem, restart or initialize it. (☞ p. 12)

If the unit still does not function properly even after following these instructions, turn off the unit and contact the nearest authorized Yamaha dealer or service center.

The unit cannot be charged / It takes a long time to charge

- **A USB power adapter that is not compatible with the unit is being used.**

Use a USB power adapter that can output DC 5 V (2 A or more). (☞ p. 5)

- **The USB power adapter and this unit are not properly connected.**

Check that all connections are made properly. (☞ p. 5)

- **Ambient temperature is too high or too low.**

Charge the unit within the temperature range of 5°C to 35°C. (☞ p. 5)

- **Charging takes a long time.**

It is possible that charging is stopped. Disconnect and reconnect the USB cable and charge the unit again. (☞ p. 5)

- **The protection circuitry of this unit has been activated.**

Check the lamp display. (☞ p. 13)

- **The unit is connected to a USB charging compatible port on a computer.**

This function is not guaranteed. Use a USB power adapter that can output DC 5 V (2 A or more).

The unit cannot be turned on

- **The power button is not being pressed and held.**

To turn on the unit, press and hold the power button for at least three seconds. (☞ p. 6)

- **The remaining battery level is low.**

Charge the unit. (☞ p. 5)

- **Ambient temperature is too high or too low.**

Use the unit within the operating temperature range. (☞ p. 15)

The unit turns off suddenly

- **The remaining battery level is low.**

Charge the unit. (☞ p. 5)

NOTE

If the unit is playing at a high volume, the remaining battery may decrease and the unit may turn off even if it is charging. In this case, turn off the unit, and then fully charge it before use.

- **The Auto Standby function turned off the unit.**

Turn on the unit again. (☞ p. 6)

- **Ambient temperature is too high or too low.**

Use the unit within the operating temperature range. (☞ p. 15)

- **The rechargeable battery in the unit has deteriorated.**

Contact the nearest authorized or Yamaha dealer or service center.

The unit cannot be connected to a Bluetooth device

- **The name of this unit is not displayed in the list of available devices to connect to on the Bluetooth device.**

Try disabling and re-enabling the Bluetooth function of the Bluetooth device. The name of this unit may then be displayed.

- **This unit cannot be connected to the Bluetooth device even though the name of the unit is displayed in the list of available devices to connect to on the Bluetooth device.**

Try deleting the name of this unit from the list and connecting the unit to the Bluetooth device again. The unit may then be connected to the Bluetooth device.

- **The Bluetooth device is not turned on.**

Turn on the Bluetooth device and ensure that its Bluetooth function is enabled.

- **The unit is connected to another Bluetooth device.**

Terminate the current Bluetooth connection, and then connect to the new device. (⇨ p. 7)

- **The unit and the Bluetooth device are too far away from each other.**

Move the Bluetooth device and/or the unit so that they are closer to each other.

- **The audio output destination on the Bluetooth device is not set to this unit.**

Select the unit as the audio output destination on the Bluetooth device.

- **Electromagnetic waves being emitted from devices using 2.4 GHz (such as microwave ovens or wireless devices) are obstructing the wireless communication.**

Do not use the unit near such devices.

- **This unit has been initialized.**

The connection information will be deleted when the unit is initialized. Delete the name of this unit from the list of available devices to connect to on the Bluetooth device and then connect to the Bluetooth device again. (⇨ p. 7)

- **The passkey for the Bluetooth device is not "0000".**

Bluetooth devices with a passkey other than "0000" cannot be used.

- **The Bluetooth device you are using does not support the A2DP profile.**

Use a Bluetooth device that supports the A2DP profile.

No sound

- **The unit and Bluetooth device are not connected.**

Connect to the Bluetooth device. (🔗 p. 7)

- **The volume is too low.**

Turn up the volume. (🔊 p. 4)

Broken, distorted, or unusual sound is heard from the unit

- **The volume is too high.**

Turn down the volume. (🔊 p. 4)

- **Electromagnetic waves being emitted from devices using 2.4 GHz (such as microwave ovens or wireless devices) are obstructing the wireless communication.**

Do not use the unit near such devices.

- **The unit and the Bluetooth device are too far away from each other.**

Move the Bluetooth device and/or the unit so that they are closer to each other.

Noise is emitted from electronic devices installed near the unit

- **The Bluetooth connection is unstable.**

Install this unit away from electronic devices.

Restarting or initializing the unit

If the unit does not function properly after following the instructions described in “Troubleshooting”, restart or initialize (factory reset) the unit.

Restarting the unit

Press and hold the power button for at least 10 seconds to restart the unit. The connection information will not be deleted even if the unit is restarted.

If the unit does not turn on automatically after restarting, press and hold the power button for at least three seconds to turn on the unit.

Initializing the unit

If the unit does not function properly even after restarting, initialize it. When the unit is initialized, the factory settings will be restored and all connection information will be deleted.

1 Press the power button while holding down the Clear Voice button in standby state.







The ClearVoice lamp flashes.






2 Press the Play/Pause button while the Clear Voice lamp is flashing.

The unit will be initialized.

List of lamp displays

The status of this unit is shown by the color of the lamp (white, blue, or orange) and by glowing/ flashing.

Power lamp	Clear Voice lamp	Power status	Status of the unit	Solution
 Glowing blue	–	On	Connected to a Bluetooth device	–
 Flashing blue	–	On	Waiting for the Bluetooth connection	–
 Glowing blue brightly and dimly alternately	–	On	Charging (when the unit is connected to a Bluetooth device)	–
 Glowing orange	–	Standby	Charging	–
 Off	–	Standby	Charging is completed or the unit is in standby state.	–
 Flashes orange four times while glowing blue or flashing blue	–	On	Remaining battery level is less than 20%.	Charge the unit.

Power lamp	Clear Voice lamp	Power status	Status of the unit	Solution
  The power lamp and Clear Voice lamp are flashing.		On/Standby	An error occurred*	Unplug the USB power adapter from the AC wall outlet, and then plug it in again. If the lamps are still flashing, restart the unit. (→ p. 12)
 Flashing orange	—	On/Standby (in charging state)	An error occurred*	Unplug the USB power adapter from the AC wall outlet, and then plug it in again after 5 to 10 minutes.
  Flashing orange and white alternately	—	On	An error occurred*	Turn off the unit, and then turn it on again after 5 to 10 minutes.

* If an error occurs and the unit does not function properly even after following the instructions to solve the problem, turn off the unit and contact the nearest authorized Yamaha dealer or service center.

Specifications

Bluetooth

Bluetooth version	Bluetooth Version 5.0
Supported profiles	A2DP (Advanced Audio Distribution Profile) AVRCP (Audio/Video Remote Control Profile)
Maximum communication range	Approx. 10 m (33 ft) (without interference)

Power

Built-in rechargeable battery	Lithium-ion battery
Continuous playback time	Approx. 12 hours on a full charge (IEC62396-1)
Charging time	Approx. 3 hours
(Playback/charging time varies depending on the usage environment and conditions.)	
Input	DC 5 V, 2 A

General

Dimensions (W × H × D)	88 × 105 × 88 mm (3-1/2" × 4-1/8" × 3-1/2")
Weight	0.49 kg (1.08 lb)
Waterproof and dustproof performance	IP67
Operating temperature range	5°C to 35°C



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Yamaha Corporation is under license. Other trademarks and trade names are those of their respective owners.

Yamaha Global Site
<https://www.yamaha.com/>

Yamaha Downloads
<https://download.yamaha.com/>

© 2022 Yamaha Corporation
Published 06/2022
KSOD-A0

YAMAHA CORPORATION

10-1 Nakazawa-cho, Naka-ku, Hamamatsu, 430-8650 Japan

AV21-0206