THR30II Wireless

Bluetooth Button
Press and hold for three seconds to activate Bluetooth pairing. The LED display will flash in green.

EFFECT Knob
Select the type and amount of modulation.

USER MEMORY Button
Store and recall user presets.

GAIN Knob
Adjusts the amount of preamp gain.

BASS Knob
Tone adjustment for the guitar's sound about low-range frequencies.

ECHO/REV Knob
Select the type and amount of echo/reverb.

AUX Jack
This is a stereo mini phone jack used to connect an external audio device.

HEADPHONE Jack
This is a stereo mini phone jack used to connect headphones.

Power Button

LED Display

INPUT Jack
This is a standard phone jack used to connect a guitar.

TAP/TUNER Button
Tap to set the tempo of delay repeats. Press and hold to activate the tuner.

AMP Knob
Selects the amp model.

MASTER Knob
Adjusts the amount of power amp gain.

TREBLE Knob
Tone adjustment for the guitar's sound about the high-range frequencies.

GUITAR Knob
Adjusts the overall volume of the guitar sound.

AMP Switch
Selects the bank of amp models.

MIDDLE Knob
Tone adjustment for the guitar's sound about the mid-range frequencies.

AUDIO Knob
Adjusts the audio playback volume for audio from the computer connected to the USB jack, an audio device connected to the AUX jack, or a smart device connected by Bluetooth.

THR10II Wireless & THR10II

USER MEMORY Button
Store and recall user presets. Enable Bluetooth by pressing the USER MEMORY button 4 and 5 simultaneously.

GAIN Knob
Adjusts the amount of preamp gain.

BASS Knob
Tone adjustment for the guitar's sound about low-range frequencies.

EFFECT Knob
Select the type and amount of modulation.

ECHO/REV Knob
Select the type and amount of echo/reverb.

AUX Jack
This is a stereo mini phone jack used to connect an external audio device.

HEADPHONE Jack
This is a stereo mini phone jack used to connect headphones.

Power Button

INPUT Jack
This is a standard phone jack used to connect a guitar.

LED Display

TAP/TUNER Button
Tap to set the tempo of delay repeats. Press and hold to activate the tuner.

AMP Knob
Selects the amp model.

MASTER Knob
Adjusts the amount of power amp gain.

TREBLE Knob
Tone adjustment for the guitar's sound about the high-range frequencies.

GUITAR Knob
Adjusts the overall volume of the guitar sound.

MIDDLE Knob
Tone adjustment for the guitar's sound about the mid-range frequencies.

AUDIO Knob
Adjusts the audio playback volume for audio from the computer connected to the USB jack, an audio device connected to the AUX jack, or a smart device connected by Bluetooth.

THR30IIA Wireless

Bluetooth Button
Press and hold for three seconds to activate Bluetooth pairing. The LED display w will flash in green.

USER MEMORY Button
Store and recall user presets.

TONE BLEND Knob
Blend the direct signal from your guitar with the processed signal from the THR. (Maximum setting produces the mic sound only. Minimum setting produces the direct pickup sound only.)

EFFECT Knob
Select the type and amount of modulation.

VOLUME Knob
Adjusts the overall volume of the guitar sound.

MIC/INST Jack
For connection to a microphone or electronic instrument.

GAIN Knob
Adjusts the input signal level of the MIC/INST jack.

AUX Jack
This is a stereo mini phone jack used to connect an external audio device.

HEADPHONE Jack
This is a stereo mini phone jack used to connect headphones.

Power Button

LED Display

GUITAR Jack
This is a standard phone jack used to connect a guitar.

TAP/TUNER Button
Tap to set the tempo of delay repeats. Press and hold to activate the tuner.

TONE SELECT Knob
Select the mic model or voicing.

BASS Knob
Tone adjustment for the guitar's sound about low-range frequencies.

REVERB Knob
Select the type and amount of reverb.

MIC/INST REVERB Knob
Adjust the reverb amount for the secondary input.

MIC/INST VOLUME Knob
Adjust the volume for the secondary input.

STEREO IMAGER Switch
Expands the stereo width of the guitar signal.

TREBLE Knob
Tone adjustment for the guitar's sound about the high-range frequencies.

MIDDLE Knob
Tone adjustment for the guitar's sound about the mid-range frequencies.

THR5

GAIN Knob
Adjusts the amount of guitar distortion.

EFFECTS Knob
Select the type and amount of modulation.

VOLUME Knob
Adjusts the overall volume of the guitar sound.

Power Switch

LED Display

AUX Jack
This is a stereo mini phone jack used to connect an external audio device.

HEADPHONE Jack
This is a standard phone jack used to connect a pair of stereo headphones to the unit. It can also be used as a line out jack.

INPUT Jack
This jack is used to connect a guitar to the unit.

TAP/TUNER Button
Tap to set the tempo of delay repeats. Press and hold to activate the tuner.

AMP Knob
Selects the amp model.

MASTER Knob
Adjusts the amount of power amp gain.

TONE Knob
Adjust the EQ curve with a single control.

DLY/REV Knob
Select the type and amount of delay/reverb.

THR5A

BLEND/GAIN Knob
Blends the direct sound of the pickup with the sound of the mic simulation when a MIC TYPE r other than EG CLN is selected (the minimum setting is direct sound only, maximum setting is mic simulation only). When EG CLN is selected as the MIC TYPE, it adjusts the amount of distortion in the guitar sound.

EFFECTS Knob
Select the type and amount of modulation.

VOLUME Knob
Adjusts the overall volume of the guitar sound.

Power Switch

LED Display

AUX Jack
This is a stereo mini phone jack used to connect an external audio device.

HEADPHONE Jack
This is a standard phone jack used to connect a pair of stereo headphones to the unit. It can also be used as a line out jack.

INPUT Jack
This jack is used to connect a guitar to the unit.

TAP/TUNER Button
Tap to set the tempo of delay repeats. Press and hold to activate the tuner.

MIC TYPE Knob
Select the mic simulation type that you want to apply to the acoustic guitar's sound.

MASTER Knob
Adjusts the amount of power amp gain. This control only adjusts the volume when a MIC TYPE other than EG CLN is selected.

TONE Knob
Tone adjustment for the guitar's sound.

DLY/REV Knob
Select the type and amount of delay/reverb.