

PSR-SX920 & SX720

# Premium China Pack 1

## VOICE

	Voice Name	Voice Type	Voice Number		
			MSB#	LSB#	Prg#(1)
1	Er Hu 1	Regular	51	1	1
2	Er Hu 2	Regular	51	1	2
3	Ma Tou Qin	Regular	51	1	3
4	Ban Hu	Regular	51	1	4
5	Jing Hu 1	Regular	51	1	5
6	Jing Hu 2	Regular	51	1	6
7	Jing Hu Tremolo	Regular	51	1	7
8	Gao Hu	Regular	51	1	8
9	Pi Pa 1	Regular	51	1	9
10	Pi Pa 2	Regular	51	1	10
11	Pi Pa Tremolo	Regular	51	1	11
12	Liu Qin	Regular	51	1	12
13	Ruan	Regular	51	1	13
14	San Xian	Regular	51	1	14
15	Yang Qin	Regular	51	1	15
16	Gu Zheng 1	Regular	51	1	16
17	Gu Zheng 2	Regular	51	1	17
18	Di Zi 1	Regular	51	1	18
19	Di Zi 2	Regular	51	1	19
20	Xiao 1	Regular	51	1	20
21	Xiao 2	Regular	51	1	21
22	Xun	Regular	51	1	22
23	Sheng 1	Regular	51	1	23
24	Sheng 2	Regular	51	1	24
25	Suo Na 1	Regular	51	1	25
26	Suo Na 2	Regular	51	1	26
27	Hu Lu Si	Regular	51	1	27
28	Ba Wu	Regular	51	1	28
29	Ba Wu & Hu Lu Si	Regular	51	1	29
30	Er Hu Ensemble	Regular	51	1	30
31	China Kit 1	SFX	126	1	33
32	China Kit 2	SFX	126	1	34

## STYLE

	Style Name	Style Type
1	CN Ballad 5	Session
2	Contemporary 6-8	Normal
3	CN Country 1	Normal
4	CN Slow 2	Normal
5	CN 70's 8Beat	Normal
6	CN Ballroom 1	Normal
7	CN Slow 3	Normal
8	CN Folk 1	Session
9	Wuxia 1	Normal
10	CN 6-8	Normal
11	CN New Year 1	Normal
12	Square Dance 1	Session
13	CN Techno 1	Normal
14	Luogu 1	Normal
15	China Dance 1	Session
16	CN 70's TV Theme 1	Session
17	CN 16Beat 1	Normal
18	CN Epic Ballad	Normal
19	CN 16Beat 2	Normal
20	CN Shuffle 1	Normal