

Clavinova®

CVP-709
CVP-705

Data List
Daten-Liste
Liste des données
Lista de datos
Lista de dados

Piano Types in the Piano Room..... 2 Klaviermodelle im Piano Room Types de piano dans Piano Room Tipos de pianos de Piano Room Tipos de piano do Piano Room	Chord Types Recognized in the Fingered Mode 49 Im Fingered-Modus erkannte Akkordarten Types d'accords reconnus en mode Fingered Tipos de acordes reconocidos en el modo Fingered (digitado) Tipos de acorde reconhecidos no modo dedilhado
Accompaniment Types in the Piano Room 3 Begleitungsarten im Piano Room Types d'accompagnements dans Piano Room Tipos de acompañamientos de Piano Room Tipos de acompanhamento do Piano Room	Effect Type List 50 Liste der Effektypen Liste des types d'effet Lista de tipos de efecto Lista de tipos de efeito
Voice List 4 Voice-Liste Liste des sonorités Lista de voces Lista de vozes	Vocal Harmony Type List 59 Liste der Vocal-Harmony-Typen Liste des types d'harmonies vocales Lista de tipos de armonías vocales Lista de tipos de harmonia vocal
Mega Voice Map 30 Sound-Zuordnungen der Mega Voices Carte des sonorités Mega Voice Mapa de Mega Voice Mapa de voz mega	Vocal Effect Type List 60 Liste der Gesangseffekt-Typen Liste des types d'effets vocaux Lista de tipos de efectos vocales Lista de tipos de efeito vocal
Drum/key Assignment List 35 Liste der Tastenzuordnungen der Schlaginstrumente Liste des affectations d'instrument de batterie/touche de clavier Lista de asignación de teclas/batería Lista de atribuições de bateria/tecla	Parameter Chart 61 Parametertabelle Tableau des paramètres Gráfico de parâmetros Gráfico de parâmetro
Style List 43 Liste der Styles Liste des styles Lista de estilos Lista de estilos	

Piano Types in the Piano Room / Klaviermodelle im Piano Room / Types de piano dans Piano Room / Tipos de pianos de Piano Room / Tipos de piano do Piano Room

CVP-709

Voice Name
CFX Grand
Bösendorfer
Pop Grand
Upright Piano
Honky Tonk Upright
Suitcase Hard
Vintage EP
CP80 Studio
TX816 EP Bright

CVP-705

Voice Name
CFX Grand
Bösendorfer
Pop Grand
Upright Piano
Honky Tonk Upright
Suitcase EP
Vintage EP
CP80 Stage
Sweet DX

Accompaniment Types in the Piano Room / Begleitungsarten im Piano Room / Types d'accompagnements dans Piano Room / Tipos de acompañamientos de Piano Room / Tipos de acompanhamento do Piano Room

CVP-709

Style Name
Contemp Gtr Pop
Standard Piano Bld
Acoustic Gtr Ballad
Funky Shuffle
Swing Medium
Cool Jazz Waltz
Standard Waltz
Brazilian Bossa
Rumba Bolero
West Coast Beat
80s American Pop
70s Piano Hit
60s Big Hit
Vintage R&R
Easy 8Beat 1
6-8 Soul Ballad
Easy 8Beat 2
6-8 Ballad Rock
90s Piano Ballad
Smooth Ballad
MOR 16Beat
Easy Acoustic Bld
70s Cool Shuffle
Easy Country Pop
70s Country Swing
Standard Swing
Slow Country Pop
Country Pop Ballad
The Blues
Cool Jazz Club
Slow Jazz Ballad
Fast Jazz
Easy Waltz
Mod Broadway Bld
Cartoon Ballad
Standard Rumba
Cool Bossa
Bossa Slow
Bossa Fast
Samba Fast

CVP-705

Style Name
Contemp Gtr Pop
Standard Piano Bld
Acoustic Gtr Ballad
Funky Shuffle
Swing Medium
Cool Jazz Waltz
Standard Waltz
Brazilian Bossa
Rumba Bolero
West Coast Beat
80s American Pop
70s Piano Hit
60s Big Hit
Vintage R&R
Easy 8Beat 1
6-8 Soul Ballad
Easy 8Beat 2
6-8 Ballad Rock
90s Piano Ballad
Smooth Ballad
MOR 16Beat
Easy Acoustic Bld
70s Cool Shuffle
Easy Country Pop
70s Country Swing
Standard Swing
Slow Country Pop
Country Pop Ballad
The Blues
Cool Jazz Club
Slow Jazz Ballad
Fast Jazz
Easy Waltz
Mod Broadway Bld
Cartoon Ballad
Standard Rumba
Cool Bossa
Bossa Slow
Bossa Fast
Samba Fast

Voice List / Voice-Liste / Liste des sonorités / Lista de voces / Lista de vozes

CVP-709

Main Category: PIANO

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
VRM Piano	CFX Grand	108	0	0	VRM	
	Bösendorfer	108	6	0	VRM	
	Pop Grand	108	17	1	VRM	
	Mellow Piano	108	18	0	VRM	
	Studio Grand	108	30	0	VRM	
	Themic Grand	108	6	1	VRM	
	Bright Piano	108	16	1	VRM	
	Ambient Piano	108	27	3	VRM	
	Rock Piano	108	16	2	VRM	
	Stage Piano	108	31	0	VRM	
	Grand Piano 1octave	108	22	1	VRM	
	Grand Piano 2octaves	108	23	1	VRM	
	Cocktail Piano	108	28	3	VRM	
	Grand Piano	CFX Grand	0	122	0	Natural!
Bösendorfer		104	18	0	Natural!	
Pop Grand		104	6	0	Natural!	
Mellow Piano		0	124	0	Natural!	
Studio Grand		104	19	0	Natural!	
Themic Grand		104	18	1	Natural!	
Bright Piano		0	123	0	Natural!	
Ambient Piano		104	19	3	Natural!	
Rock Piano		0	124	2	Natural!	
Stage Piano		104	20	0	Natural!	
Grand Piano 1octave		0	123	3	Natural!	
Grand Piano 2octaves		0	124	3	Natural!	
Cocktail Piano		104	20	3	Natural!	
Upright Piano		Upright Piano	104	13	0	Natural!
	Pop Upright	104	13	1	Natural!	
	70s Ballad Piano	104	14	0	Natural!	
	Chill Out Piano	104	15	0	Natural!	
	Honky Tonk Upright	104	13	3	Natural!	
	Saloon Upright	104	14	1	Natural!	
	Upright 1octave	104	14	3	Natural!	
	Upright 2octaves	104	15	3	Natural!	
Piano Layer	Superstar Grand	108	25	4	Natural!	
	Imperial Ballad	108	26	4	Natural!	
	CFX DX Layer	108	33	2	Natural!	
	Bösendorfer DX Layer	108	34	2	Natural!	
	MIDI Grand	104	2	2	Natural!	
	MIDI Grand Pad	104	3	2	Natural!	
	Grand Piano & Choir	108	25	0	Natural!	
	Bright Grand Pad	104	8	0	Natural!	
	Grand Piano & Strings	108	23	0	Natural!	
	Grand Piano & Orchestra	104	12	0	Natural!	
	Piano & EP 1	108	25	2	Natural!	
	Piano & EP 2	108	26	2	Natural!	
	Grand Pad Layer	108	32	2	Natural!	
	Warm Grand Pad	108	24	0	Natural!	
	Electric Piano	Suitcase Hard	104	16	4	Cool!
		Suitcase Soft	104	7	4	Cool!
Vintage EP		104	8	4	Cool!	
Suitcase Ballad		104	9	4	Cool!	
Suitcase Phaser		104	10	4	Cool!	
Suitcase Drive		104	11	4	Cool!	
Suitcase Tremolo		104	12	4	Cool!	
Suitcase Jazz		104	13	4	Cool!	
Suitcase Warmth		104	14	4	Cool!	
Vintage EP Drive		104	15	4	Cool!	
Suitcase EP		0	118	4	Cool!	
Vintage EP		0	116	4	Regular	
Electric Piano 1		0	119	4	Cool!	
Electric Piano 2		0	122	4	Natural!	
Stage EP		0	117	4	Regular	
Funky EP		0	123	4	Natural!	

Main Category: PIANO

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Electric Piano	Tremolo Suitcase EP	0	113	4	Cool!	
	Tremolo Stage EP	0	124	4	Natural!	
	Smooth Tine	0	119	5	Regular	
	CP80 Studio	0	123	2	Natural!	
	Magnetics	104	0	4	Regular	
	CP80 Stage	0	113	2	Regular	
	FM E.Piano	TX816 EP Bright	104	10	5	Cool!
		TX816 EP Mellow	104	11	5	Cool!
TX816 EP Warm		104	12	5	Cool!	
Studio Ballad DX		104	9	5	Regular	
Sparkle Stack		0	121	5	Cool!	
Sweet DX		104	0	5	Cool!	
Ballad DX		0	124	5	Cool!	
DX Dynamics		0	123	5	Cool!	
Ballad Bells		104	2	5	Cool!	
Galaxy EP		0	114	4	Cool!	
DX7 EP		0	122	5	Natural!	
Dream DX		104	3	5	Cool!	
Midnight DX		104	1	5	Cool!	
Piano Sweeper		104	3	99	Regular	
Pianosphere	104	19	88	Regular		
Clavi	Clavi	8	33	20	S.Art!	
	Clavi Funk	8	34	20	S.Art!	
	Clavi Drive	8	36	20	S.Art!	
	Clavi Bright	0	112	7	Regular	
	Clavi Warm	0	122	7	Natural!	
	Wah Clavi	0	113	7	Regular	
	Funk Clavi	0	123	7	Natural!	
	Phase Clavi	0	115	7	Regular	
	Harpischord	Harpischord 1	0	122	6	Natural!
		Harpischord 2	8	32	112	S.Art!
Harpischord 3		0	125	6	Natural!	
Harpischord Coupler		0	123	6	Natural!	
Grand Harpischord		0	113	6	Live!	
Harpischord & Strings		0	124	6	Natural!	

Main Category: ORGAN

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Tonewheel Organ	Whiter Bars	8	32	29	S.Art!
	Curved Bars	0	121	16	Cool!
	All Bars Out	8	32	30	S.Art!
	Even Bars	0	111	16	Cool!
	Jazz Rotary	8	32	113	S.Art!
	Vintage Fast	0	127	16	Cool!
	Classic Bars	8	34	29	S.Art!
	Scanner Jazz	0	118	18	Cool!
	Rock Rotary	8	33	113	S.Art!
	Organ-a-Go-Go	104	0	16	Cool!
	Prog Rock Organ	8	33	29	S.Art!
	Organ Accom 1	0	108	17	Regular
	R&B Tremolo	0	111	18	Cool!
	Organ Accom 2	0	107	17	Regular
	Classic Jazz	0	117	16	Cool!
	Organ Accom 3	0	106	17	Regular
	Hold It Fast	0	111	17	Cool!
	Organ Accom 4	0	105	17	Regular
	Full Rocker	0	115	18	Cool!
	Organ Accom 5	0	104	17	Regular
	Whiter Bars Slow	104	1	17	Cool!
	Whiter Bars Fast	104	0	17	Cool!
	Jazz Organ Slow	0	126	17	Cool!
	Jazz Organ Fast	0	127	17	Cool!

CVP-709

Main Category: ORGAN

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Tonewheel Organ	All Bars Out Slow	104	1	18	Cool!
	All Bars Out Fast	104	0	18	Cool!
	All Bars Phase	104	2	18	Cool!
	Rotor Organ	0	117	18	Cool!
	Mellow Drawbar	0	115	17	Regular
	Two Channels Organ	0	109	17	Cool!
Transistor Organ	60s Combo 1	104	32	16	Cool!
	60s Combo 2	104	33	16	Cool!
	60s Combo 3	104	34	16	Cool!
	60s Combo 4	104	35	16	Cool!
	Euro Organ	0	118	16	Regular
Classical Pipe	Lieblich Gedackt	104	6	19	Regular
	Diapason	104	4	19	Regular
	Claribel 8' & Flute 4'	104	5	19	Regular
	Soft Reeds	104	7	19	Regular
	Grand Jeu	104	1	19	Live!
	Fonds Et Anches	104	2	19	Live!
	Organo Pleno	104	3	19	Live!
	Tutti	104	0	19	Live!
	Full Organ	0	112	19	Regular
	Pipe Organ 8'	0	124	19	Natural!
	Pipe Organ Principal	0	123	19	Natural!
	Chapel Organ	0	113	19	Regular
	Pipe Organ Twelfth	0	125	19	Natural!
	Hymn Organ	0	114	19	Regular
	Pipe Organ Tutti 1	0	126	19	Natural!
	Church Organ	0	115	19	Regular
	Pipe Organ Tutti 2	0	122	19	Natural!
Theatre Pipe	Full Theatre	0	127	18	Regular
	Tibia 8'	104	6	17	Regular
	Sweet Theatre	0	126	18	Regular
	Tibia 8'&4'	104	9	16	Regular
	Ballroom Organ	0	115	3	Regular
	Tibia 16'&4'	104	8	16	Regular
	Tibia Chorus	104	5	17	Regular
	Vox Humana 8'	104	7	17	Regular
	Vox Humana & Tibia	104	10	16	Regular
	Theatre Trumpet 8'	0	124	16	Regular
	Theatre Kinura 8'	0	123	16	Regular
	Theatre Trumpet & Kinura	0	125	17	Regular
	Theatre Trumpet 16'&8'	0	124	17	Regular
	Organ Flutes	Organ Flutes	10	0	8
USD Smile		10	1	8	OrganFlutes
Reggae Bars		10	2	8	OrganFlutes
Warm Theatre		10	3	8	OrganFlutes
Organ Pops		10	4	8	OrganFlutes
Rock Organ		10	5	8	OrganFlutes
Soul Percussion		10	6	8	OrganFlutes
Gospel Truth		10	7	8	OrganFlutes
Pad Organ		10	8	8	OrganFlutes
Full Organ		10	9	8	OrganFlutes
String Bars		10	0	9	OrganFlutes
Latin Spin		10	1	9	OrganFlutes
Shady Bars		10	2	9	OrganFlutes
Funk Organ		10	3	9	OrganFlutes
Ballad Organ		10	4	9	OrganFlutes
Rich Bars		10	5	9	OrganFlutes
Trumpet Bars		10	6	9	OrganFlutes
Soul Bars		10	7	9	OrganFlutes
Clari Bars		10	8	9	OrganFlutes
Jazz Squabble		10	9	9	OrganFlutes
Euro Perc		10	0	10	OrganFlutes
Ballad Euro		10	1	10	OrganFlutes
Euro Reeds		10	2	10	OrganFlutes

Main Category: ORGAN

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Organ Flutes	Even Warmth	10	3	10	OrganFlutes
	Bright Euro	10	4	10	OrganFlutes
	Euro Accomp 1	10	7	10	OrganFlutes
	Full Euro	10	6	10	OrganFlutes
	Euro Accomp 2	10	8	10	OrganFlutes
	Euro Pops	10	5	10	OrganFlutes
	Euro Accomp 3	10	9	10	OrganFlutes
Harmonica	Harmonica	8	64	104	S.Art2!
	Blues Harp	8	65	104	S.Art2!
	Harmonica	0	112	22	Sweet!
Accordion	Full Accordion Register	104	2	21	Regular
	French Musette Acc.	0	119	21	Regular
	Master Accordion	0	118	21	Regular
	Steirische	0	117	21	Regular
	Jazz Accordion	0	120	21	Regular
	Cassotto	104	0	21	Regular
	Cajun	104	3	21	Regular
	Accordion Clarinet	104	1	21	Regular
	Bandoneon	0	113	23	Regular
	Tango Accordion	0	114	23	Regular
	Full Register Bass	104	5	21	Regular
	Musette Bass	0	123	21	Regular
	Master Bass	0	122	21	Regular
	Cajun Bass	104	6	21	Regular
	Accordion Bass	0	121	21	Regular
	Tango Bass	0	115	23	Regular

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Nylon Acoustic	Flamenco Guitar	8	35	1	S.Art!	
	Spanish Guitar	8	34	1	S.Art!	
	Spanish Electro Acoustic	8	36	1	S.Art!	
	Slide Spanish Guitar	104	9	25	Live!	
	Concert Guitar	8	32	0	S.Art!	
	Dynamic Nylon	0	116	24	Live!	
	Hard Flamenco	0	118	24	Live!	
	Nylon Guitar	8	34	0	S.Art!	
	Classical Guitar	0	115	24	Live!	
	Slide Nylon	0	117	24	Live!	
	Nylon Mute	0	119	24	Live!	
	Electro Acoustic Guitar	8	35	0	S.Art!	
	Steel Acoustic	Steel Acoustic Guitar	8	37	1	S.Art!
		Steel Acoustic Strum	104	10	25	Live!
Steel Guitar Twin 1		104	12	25	Live!	
Steel Guitar Twin 2		104	13	25	Live!	
Chicken Pick Guitar		104	11	25	Live!	
12String Guitar Twin		8	39	1	S.Art!	
Chicken Pick Switch		8	38	1	S.Art!	
12String Strumming		8	40	1	S.Art!	
Steel Guitar		8	32	1	S.Art!	
Slide Steel		0	118	25	Live!	
Folk Guitar Harmonics		8	33	1	S.Art!	
Dynamic Steel		0	116	25	Live!	
Steel Guitar Strum		0	117	25	Live!	
Steel Guitar Mute		0	120	25	Live!	
12String Guitar		0	113	25	Live!	
Clean Solid		Shadowed Guitar	8	56	3	S.Art!
		Oldies Guitar	8	52	5	S.Art!
	Vintage Short Delay	8	48	5	S.Art!	
	Finger Slap Slide	8	51	3	S.Art!	
	Rough Fingers	8	39	4	S.Art!	
	Clean Fingers	8	38	4	S.Art!	

CVP-709

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Clean Solid	Country Pick Drive	8	40	4	S.Art!
	Country Pick Vintage	8	41	4	S.Art!
	Pure Vintage	8	42	5	S.Art!
	Bluesy Fingers	8	37	4	S.Art!
	Jazz Combo	8	54	5	S.Art!
	Finger Chorus	8	42	3	S.Art!
	Warm Solid	8	33	3	S.Art!
	Single Coil Clean	8	39	3	S.Art!
	Clean Solid	8	34	3	S.Art!
	Bright Chorus	8	45	3	S.Art!
	Vintage Slap	8	48	3	S.Art!
	Ballad Delay	8	46	3	S.Art!
	Vintage Pure	8	47	3	S.Art!
	Jazz Vintage	8	38	6	S.Art!
	Jazz Artist	8	39	6	S.Art!
	Finger Bright	8	50	3	S.Art!
	Slide Clean	0	117	28	Cool!
	Warm Electric	8	32	3	S.Art!
	Slide Warm	104	6	27	Cool!
	Clean Electric	8	35	3	S.Art!
	Slide Pick	104	7	27	Cool!
	Jazz Clean	8	32	6	S.Art!
	Country Pick	8	44	3	S.Art!
	Jazz Solo Guitar	0	116	26	Cool!
	Semi Acoustic	8	33	6	S.Art!
	Electric Guitar	0	114	28	Cool!
	Chorus Solid	0	107	27	Cool!
	Dynamic Mute	0	118	28	Cool!
	Slide Solid	0	110	27	Cool!
	Cool Wah Guitar	104	4	27	Regular
	Slap Solid	0	108	27	Cool!
	Slapback	104	0	27	Cool!
	Light Chorus	8	53	3	S.Art!
	Funk Slap	8	49	3	S.Art!
	Smooth Jazz Guitar	8	35	6	S.Art!
	Slide Finger	104	5	27	Cool!
	Lounge Guitar	104	1	26	Regular
	Vintage Muted Guitar	104	0	28	Cool!
	Vintage Spring	8	54	3	S.Art!
	Vintage Muted Echo	0	115	28	Regular
	Vintage Open	0	123	27	Regular
	Vintage Strum	0	126	27	Regular
	Funk Guitar	0	116	28	Cool!
	70s Solid Guitar	8	38	3	S.Art!
	Slide Jazz	104	0	26	Cool!
	Jazz Guitar	0	115	26	Cool!
	Clean Guitar	0	112	27	Cool!
	60s Clean	0	117	27	Regular
	Tremolo Solid	0	111	27	Cool!
	Muted Guitar	0	119	28	Cool!
Ballad Solid	0	109	27	Cool!	
Octave Guitar	0	113	26	Regular	
Distortion Solid	Solo King	8	50	5	S.Art!
	Rhythm King	8	53	5	S.Art!
	Vintage Distortion Full	8	43	5	S.Art!
	Vintage Distortion Solo	8	44	5	S.Art!
	Vintage Distortion Stage	8	45	5	S.Art!
	Vintage Heavy	8	47	5	S.Art!
	Vintage Overdrive Wah	8	46	5	S.Art!
	Rock Hero	8	35	5	S.Art!
	Stage Lead	8	38	5	S.Art!
	Grunge Guitar	8	40	5	S.Art!
	Big Combo	8	51	5	S.Art!
	Vintage Warm Drive	8	49	5	S.Art!

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type		
		MSB	LSB	Prg			
Distortion Solid	Overdrive Wah	8	39	5	S.Art!		
	Vintage Amp	8	41	3	S.Art!		
	Rock Legend	8	34	5	S.Art!		
	Finger Amp	8	43	3	S.Art!		
	Vintage Rock	8	36	5	S.Art!		
	Slide Pick Amp	104	8	27	Cool!		
	Guitar Hero	8	32	5	S.Art!		
	Half Drive	8	37	3	S.Art!		
	Blues Slap Slide	8	36	4	S.Art!		
	Classic Stack	8	41	5	S.Art!		
	Vintage Blues	8	37	5	S.Art!		
	Crunch Guitar	8	33	5	S.Art!		
	Blues Warm	8	34	4	S.Art!		
	Heavy Rock	8	32	4	S.Art!		
	Bluesy Night	8	55	3	S.Art!		
	Stereo Rock	104	2	30	Cool!		
	Blues Bright	8	35	4	S.Art!		
	Feedbacker	8	33	4	S.Art!		
	Power Lead	0	115	30	Cool!		
	Vintage Amp	0	115	29	Regular		
	Metal Master	0	120	30	Regular		
	Vintage Lead	0	125	27	Cool!		
	Crunch Guitar	0	113	30	Regular		
	Blues Guitar	0	117	29	Cool!		
	Heavy Stack	0	114	30	Regular		
	World	Pedal Steel Amp	8	52	3	S.Art!	
		Mandolin	0	114	25	Sweet!	
		Pedal Steel	8	36	3	S.Art!	
		Zither 1	104	1	15	Regular	
		Banjo	104	0	105	Regular	
		Zither 2	104	0	15	Regular	
		Shamisen	0	112	106	Regular	
		Dulcimer	0	112	15	Regular	
		Koto	0	112	107	Regular	
		Hackbrett	104	2	46	Regular	
		Aloha Guitar	0	118	26	Regular	
		Sitar	104	0	104	Regular	
		Pedal Steel	0	115	27	Regular	
		Bass	Vintage Round Bass	8	32	17	S.Art!
			Acoustic Bass	8	32	16	S.Art!
			Vintage Flatwound Bass	8	33	17	S.Art!
	Soft Acoustic Bass		8	33	16	S.Art!	
	Vintage Mute Bass		8	32	18	S.Art!	
	Acoustic Bass & Cymbal		0	114	32	Regular	
Vintage Pick Bass	104		1	34	Regular		
Fusion Bass	0		113	36	Regular		
Fretless Bass	8		32	19	S.Art!		
Slap Bass	0		112	36	Regular		
Vintage Round Bass	104		1	33	Cool!		
Soft Acoustic Bass	104		2	32	Regular		
Vintage Flatwound Bass	104		2	33	Cool!		
Acoustic Bass	104		1	32	Regular		
Vintage Mute Bass	104		3	33	Cool!		
Ballroom Bass	104		0	32	Regular		
Vintage Pick Mute Bass	104		0	34	Cool!		
Half Mute Bass	0		115	33	Cool!		
Fretless Bass	0		112	35	Cool!		
Vintage Dyno Bass	104		2	34	Cool!		
Rock Bass	0		114	34	Regular		
Electric Bass	0		114	33	Cool!		
Pick Dyno Bass	0		113	34	Cool!		
Mellow Finger Bass	0		112	33	Regular		
Super Fretless Bass	0		113	35	Regular		

CVP-709

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Bass	Pick Bass	0	112	34	Regular
	Funk Bass	0	112	37	Regular
Synth Bass	BPF Buzz	8	32	122	S.Art!
	Wobble (Pedal)	8	33	122	S.Art!
	Ramp Bass (Pedal)	8	34	122	S.Art!
	Square Pluck (Pedal)	8	35	122	S.Art!
	Deep Sub (Pedal)	104	18	87	Regular
	Modern Pop	104	19	87	Regular
	Multi Saw Bass	104	20	87	Regular
	Brite Dub Bass	104	21	87	Regular
	Pulse & Saw	104	22	87	Regular
	Twenty Five	104	23	87	Regular
	Punchy Square	104	24	87	Regular
	Softwood	104	25	87	Regular
	Punchy DX	104	26	87	Regular
	Dark Sequence Bass	104	27	87	Regular
	Pumping Saw	104	28	87	Regular
	Pumping Square	104	29	87	Regular
	Lo Bass	104	0	39	Regular
	Fat Pulse	104	2	39	Regular
	Dark Bass	104	1	39	Regular
	Wazzo Saw	104	3	80	Regular
	Moon Bass	104	0	38	Regular
	Deep Point	104	3	38	Regular
	Kick Bass	104	1	38	Regular
	Tight Bass	104	3	39	Regular
	Club Bass	104	2	38	Regular
	Competitor	104	4	38	Regular
	1o1 Sub	104	5	38	Regular
	Trance Bass	104	9	38	Regular
	Little Bass Synth	104	6	38	Regular
	Sub Cut Bass	104	5	39	Regular
	Tekno Bass	104	7	38	Regular
	Dyno Acid Bass	104	10	38	Regular
	Perc Punch	104	8	38	Regular
	Mini Sub	104	6	39	Regular
	Square Bass	104	4	39	Regular
	Fat Sine Resonance	104	11	38	Regular
	Ballad Bass	104	7	39	Regular
	House Bass	0	116	38	Regular
	Velo Master	104	17	81	Regular
	Big Drone	0	118	38	Regular
	Sub Bass	0	114	39	Regular
	Hard Bass	0	114	38	Regular
Resonance Bass	0	112	38	Regular	
TB Bass	0	117	39	Regular	

Main Category: STRINGS&VOCAL

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
String Solo	Jazz Violin	8	64	48	S.Art2!
	Classic 1st Violin	8	33	43	S.Art!
	Celtic Violin	8	65	48	S.Art2!
	Classic 2nd Violin	8	33	44	S.Art!
	Viola	0	112	41	Regular
	Classic Viola	8	33	45	S.Art!
	Cello	0	122	42	Natural!
	Classic Cello	8	33	46	S.Art!
	String Quartet	8	34	47	S.Art!
	Contrabass	0	112	43	Regular
	Violin	0	113	40	Sweet!
	Fiddle	0	112	110	Regular

Main Category: STRINGS&VOCAL

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
String Solo	Solo Violin	0	112	40	Regular
	Cello	0	112	42	Regular
String Ensemble	Romance Strings	8	43	49	S.Art!
	Pizzicato	0	113	45	Live!
	Concert Strings	8	32	49	S.Art!
	Real Tremolo Strings	104	0	44	Live!
	Broadway Strings	8	38	48	S.Art!
	Real Spiccato	104	6	48	Live!
	Chamber Strings	8	42	48	S.Art!
	Real String Pad	8	43	48	S.Art!
	Real Strings	8	33	49	S.Art!
	Classical Strings	8	36	48	S.Art!
	Real 1st Violins	8	32	43	S.Art!
	Classic 1st Violins	8	34	43	S.Art!
	Real 2nd Violins	8	32	44	S.Art!
	Classic 2nd Violins	8	34	44	S.Art!
	Real Violas	8	32	45	S.Art!
	Classic Violas	8	34	45	S.Art!
	Real Cellos	8	32	46	S.Art!
	Classic Cellos	8	34	46	S.Art!
	Real Contrabasses	8	32	47	S.Art!
	Spiccato	0	120	48	Live!
	Theatre Strings	8	37	48	S.Art!
	Lush Strings	8	41	48	S.Art!
	Ballroom Strings	8	35	49	S.Art!
	Studio Strings	8	32	48	S.Art!
	Strings	0	122	48	Natural!
	Movie Strings	0	123	48	Live!
	Disco Strings 1	0	123	49	Live!
	Ballad Strings	8	34	49	S.Art!
	Disco Strings 2	0	124	49	Live!
	Warm Strings	8	39	48	S.Art!
	Tremolo Strings	0	113	44	Live!
	Big Strings	8	40	48	S.Art!
	Spiccato	8	33	48	S.Art!
	Strings	0	117	49	Live!
	Real Strings f	8	40	49	S.Art!
	Allegro	0	122	49	Live!
	Real Strings mf	8	41	49	S.Art!
	Dynamic Strings	0	124	48	Live!
	Real Strings p	8	42	49	S.Art!
	Chamber Strings	0	112	49	Regular
	Real Tremolo Sforzando	104	1	44	Live!
	Tremolo Bowing	8	34	48	S.Art!
Strings f	0	119	48	Live!	
Real Strings f	104	4	49	Live!	
Strings mf	0	118	48	Live!	
Real Strings mf	104	5	49	Live!	
Strings p	0	117	48	Live!	
Real Strings p	104	6	49	Live!	
Orchestral Layers	Horns & Strings	8	38	49	S.Art!
	Symphonic Unison	104	0	49	Regular
	Tutti	0	120	49	Regular
	Theatre Orchestra	104	1	49	Regular
Pizzicato Glocken	0	115	45	Live!	
Pop Vocals	Haa	8	32	39	S.Art!
	Doo	8	38	40	S.Art!
	Wah	8	38	39	S.Art!
	Yoo	8	42	40	S.Art!
	Baa	8	41	39	S.Art!
	Ooh Boys	8	34	40	S.Art!
	Daa	8	45	39	S.Art!
	Ooh Girls	8	36	40	S.Art!
	Ooh	8	32	40	S.Art!

CVP-709

Main Category: STRINGS&VOCAL

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Pop Vocals	Pop Vocal Ensemble	8	40	55	S.Art!	
	Haa Vibrato	8	33	39	S.Art!	
	Doo Vibrato	8	39	40	S.Art!	
	Wah Vibrato	8	39	39	S.Art!	
	Yoo Vibrato	8	43	40	S.Art!	
	Baa Vibrato	8	42	39	S.Art!	
	Ooh Boys Vibrato	8	35	40	S.Art!	
	Daa Vibrato	8	46	39	S.Art!	
	Ooh Girls Vibrato	8	37	40	S.Art!	
	Ooh Vibrato	8	33	40	S.Art!	
	Bee Vibrato	104	4	52	Live!	
	Haa	104	9	52	Live!	
	Doo	104	16	53	Live!	
	Wah	104	10	52	Live!	
	Yoo	104	18	53	Live!	
	Baa	104	12	52	Live!	
	Doo Boys	8	40	40	S.Art!	
	Daa	104	13	52	Live!	
	Doo Girls	8	41	40	S.Art!	
	Ooh	104	17	53	Live!	
	Hoo Wah	8	39	55	S.Art!	
	Aah-Ooh Auto	8	49	40	S.Art!	
	Soft Wah	8	40	39	S.Art!	
	Accomp Aah	104	15	52	Live!	
	Haa Boys	8	34	39	S.Art!	
	Accomp Ooh	104	15	53	Live!	
	Haa Girls	8	35	39	S.Art!	
	Mmh	0	117	52	Live!	
	HooWee Auto	8	56	55	S.Art!	
	Jazz Vocals	Shoo-Bee-Doo-Bah 1	8	32	55	S.Art!
		DoBeDoBe	8	48	55	S.Art!
		Shoo-Bee-Doo-Bah 2	8	47	55	S.Art!
		YaBaDaBa	8	51	55	S.Art!
BaDaYah		8	36	55	S.Art!	
Who Are You?		8	54	55	S.Art!	
What Should We Do?		8	53	55	S.Art!	
DoWeYoBe		8	52	55	S.Art!	
ShooBeeDynamic		8	35	55	S.Art!	
ShooBaDooBa		8	55	55	S.Art!	
Scat Vocalists		8	42	55	S.Art!	
Latin Vocals		8	41	55	S.Art!	
Jazz Singers Shoo		8	45	55	S.Art!	
Baroque Scat		8	43	55	S.Art!	
Jazz Singers Dwee		8	46	55	S.Art!	
Scatman Legato		8	50	55	S.Art!	
Gospel Choir		Gospel Hmm	8	32	54	S.Art!
		Wow Hey Hmm	8	35	54	S.Art!
		Gospel Wow	8	33	54	S.Art!
		Gospel Hmm	104	12	53	Live!
	Gospel Hey	8	34	54	S.Art!	
	Gospel Wow	104	13	53	Live!	
	Gospel Hmm Aah (Pedal)	8	36	54	S.Art!	
	Gospel Hey	104	7	52	Live!	
	Gospel Wow Hey (Pedal)	8	37	54	S.Art!	
	Classical Choir	Boys Choir Ooh	8	32	51	S.Art!
Boys Choir Aah		8	33	51	S.Art!	
Soft Choir Ooh		8	35	51	S.Art!	
Soft Choir Aah		8	36	51	S.Art!	
Boys Choir Oh-Ah (Pedal)		8	34	51	S.Art!	
Boys Choir Oh-Ah		8	49	55	S.Art!	
Choir		0	122	52	Natural!	
Choir & Organ		0	123	52	Natural!	
Gothic Vox		0	113	53	Regular	

Main Category: BRASS&WOODWIND

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Brass Solo	Mute Trumpet	8	64	64	S.Art2!	
	Trumpet	8	66	65	S.Art2!	
	Big Band Trumpet	8	67	65	S.Art2!	
	Trombone	8	65	73	S.Art2!	
	Jazz Trumpet	8	64	65	S.Art2!	
	Classic Trumpet	8	65	65	S.Art2!	
	Bright Trumpet	8	32	64	S.Art!	
	Cornet	0	119	56	Sweet!	
	Silver Trumpet	8	33	64	S.Art!	
	Muted Trumpet	0	114	59	Sweet!	
	Golden Trumpet	8	34	64	S.Art!	
	Flugel Horn	0	118	56	Sweet!	
	Big Band Trumpet	8	37	64	S.Art!	
	Trombone	0	117	57	Sweet!	
	Trumpet Fall	8	38	64	S.Art!	
	Trumpet	0	115	56	Sweet!	
	Trumpet Shake	8	35	64	S.Art!	
	Mellow Trumpet	0	120	56	Sweet!	
	Silver Trumpet	0	121	56	Sweet!	
	Muted Cornet	104	0	59	Sweet!	
	Golden Trumpet	0	122	56	Sweet!	
	Baritone Horn	0	113	58	Regular	
	Tuba	104	0	58	Regular	
	Bright Trombone	104	0	57	Sweet!	
	Baritone Hit	0	114	58	Regular	
	Alp Bass	0	113	33	Regular	
	Brass Ensemble	Orchestral Trumpets	104	3	56	Live!
		Orchestral Trombones	104	3	57	Live!
		Orch Trumpets & Trombones 1	104	9	61	Live!
		Orch Trumpets & Trombones 2	104	10	61	Live!
		Symphony Horns 1	104	1	60	Live!
		Orch Octave Brass	104	12	61	Live!
		Symphony Horns 2	104	2	60	Live!
		Warm Horns	8	33	60	S.Art!
		Symphony Horns 3	104	8	61	Live!
		Stopped Horns	104	3	60	Live!
		Pop Horns Dynamic	104	0	61	Live!
		Pop Horns Dynamic Shake	104	4	61	Live!
		Pop Horns Mellow	8	43	56	S.Art!
		Pop Horns Bright	8	44	56	S.Art!
		Pop Horns Accent	104	3	61	Live!
		Pop Horns Cresc	104	5	61	Live!
		Horns Fall Doit (Pedal)	8	46	56	S.Art!
		Horns Falls (Pedal)	8	47	56	S.Art!
		Swing Horns Warm	104	1	61	Live!
Swing Horns Mute		104	2	61	Live!	
Orch Trumpets Fast		104	4	56	Live!	
Orch Trombones Fast		104	4	57	Live!	
Orch Horns Fast		104	4	60	Live!	
Orch Horns & Trombones		104	13	61	Live!	
Symphony Horns Fast		104	15	61	Live!	
Orch Horn Pad		104	11	61	Live!	
Warm Horns Section		8	41	56	S.Art!	
Bright Horns Section		8	42	56	S.Art!	
Ballad Brass		104	6	61	Live!	
Colliery Band		104	14	61	Live!	
Horns	104	0	60	Live!		
Big Band Brass	8	37	56	S.Art!		
Soft Horns	8	32	60	S.Art!		
Smooth Brass	8	36	56	S.Art!		
Dynamic Brass	0	127	61	Live!		
Power Brass	0	121	62	Live!		

CVP-709

Main Category: BRASS&WOODWIND

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Brass Ensemble	Accent Brass	0	109	61	Live!
	Brass Falls f	8	34	56	S.Art!
	Muted Horns	8	34	60	S.Art!
	Brass Falls mf	8	35	56	S.Art!
	Brass f	0	108	61	Live!
	Brass Band	0	123	56	Live!
	Brass mf	0	110	61	Live!
	Soft Horns	0	117	60	Live!
	Brass p	0	111	61	Live!
	Soft Trombones	0	118	60	Live!
	Brass Shake	8	32	56	S.Art!
	Pop Brass	0	117	62	Live!
	Accent Falls	8	38	56	S.Art!
	Hyper Brass	0	118	62	Live!
	Sforzando	0	105	61	Live!
	Small Brass	0	120	60	Live!
	Sforzando Fall	0	107	61	Live!
	Ballroom Brass	0	113	59	Regular
Brass Dynamics	0	106	61	Live!	
Octave Brass	0	116	62	Live!	
Sax Solo	Tenor Sax	8	66	80	S.Art2!
	Jazz Tenor Sax	8	65	80	S.Art2!
	Pop Soprano	8	64	84	S.Art2!
	Breathy Tenor Sax	8	64	80	S.Art2!
	Ballad Soprano	8	65	84	S.Art2!
	Saxophone	8	32	82	S.Art!
	Alto Sax	8	32	66	S.Art!
	Big Band Sax	8	35	82	S.Art!
	Soft Alto Sax	8	34	66	S.Art!
	Rock Sax	8	33	82	S.Art!
	Growl Sax	0	111	66	Sweet!
	Soprano Sax	0	113	64	Sweet!
	Pop Tenor Sax	0	127	66	Sweet!
	Pop Alto Sax	104	0	65	Sweet!
	Ballad Tenor Sax	0	126	66	Sweet!
	Breathy Tenor Sax	0	117	66	Sweet!
	Jazz Tenor Sax	0	125	66	Sweet!
	Baritone Sax	104	0	67	Regular
Sax Ensemble	Sax Section Fast Attack	0	116	66	Live!
	Big Band Octave	0	108	66	Live!
	Sax Section Unison	8	38	82	S.Art!
	Big Band Unison	0	109	66	Live!
	Sax Section	8	36	82	S.Art!
	Big Band Saxes	0	110	66	Live!
	Sax Section Octave	8	37	82	S.Art!
	Ballad Section	0	119	66	Regular
	Soft Saxes	8	39	82	S.Art!
	Sax Appeal	0	123	66	Live!
	Sax Section Hard	0	122	66	Live!
	Moonlight	0	115	71	Regular
	Sax Section Soft	0	121	66	Live!
	Woodwind Solo	Classical Flute	8	64	74
Jazz Flute		8	65	74	S.Art2!
Clarinet		8	65	92	S.Art2!
Orchestral Flute		8	32	73	S.Art!
Romance Clarinet		8	66	92	S.Art2!
Jazz Flute		0	114	73	Sweet!
Ballad Clarinet		8	64	92	S.Art2!
Orchestral Oboe		8	32	68	S.Art!
Orchestral Clarinet		104	0	71	Live!
Jazz Clarinet		0	114	71	Sweet!
German Clarinet		104	2	71	Regular
Orchestral Bassoon		104	0	70	Sweet!
Classical Flute		0	115	73	Sweet!

Main Category: BRASS&WOODWIND

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Woodwind Solo	Classical Oboe	0	113	68	Sweet!
	Piccolo	0	112	72	Regular
	English Horn	0	112	69	Regular
Woodwind Ens	Flutes & Oboes	104	2	73	Regular
	Orchestral Woodwind	104	1	70	Regular
	Clarinet & Flutes	104	1	71	Regular
	Alto Flutes	104	1	73	Regular
	Clarinet & Oboe	104	1	68	Regular
	Flute Ensemble	0	116	73	Regular
Woodwind World	Oboe & Bassoon	104	2	68	Regular
	Irish Pipe Air	8	64	108	S.Art2!
	Ballad Pan Flute	0	113	75	Sweet!
	Irish Pipe Dance	8	65	108	S.Art2!
	Ocarina	0	112	79	Regular
	Celtic Duo	0	120	73	Regular
	Shakuhachi	0	112	77	Regular
	Bagpipe	0	112	109	Regular
	Recorder	0	112	74	Regular
	Whistle	0	112	78	Regular
	Chiff Pan Flute	0	113	73	Regular

Main Category: PERC&DRUMS

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Chromatic Perc	Vibraphone	104	1	11	Sweet!	
	Xylophone	104	0	13	Regular	
	Jazz Vibraphone	0	113	11	Regular	
	Marimba	104	0	12	Regular	
	Tremolo Vibraphone	0	124	11	Natural!	
	Orchestral Marimba	0	122	12	Natural!	
	Vibraphone & JazzGt	8	33	11	S.Art!	
	Glockenspiel	104	0	9	Regular	
	Vibraphone & Flutes	0	114	11	Regular	
	Steel Drums	0	112	114	Regular	
	Vibraphone	0	122	11	Natural!	
	Steel Drums	0	122	114	Natural!	
	Music Box	0	112	10	Regular	
	Kalimba	0	112	108	Regular	
	Orchestral Perc	Orchestral Harp	104	1	46	Regular
		Tubular Bells	0	112	14	Regular
Mellow Harp		104	0	46	Regular	
Timpani		0	112	47	Regular	
Celesta		0	112	8	Regular	
Orchestra Hit		0	112	55	Regular	
Concert Celesta		0	122	8	Natural!	
Drum Kits	Real Drums	127	0	91	Live!Drums	
	Power Kit 1	127	0	87	Live!Drums	
	Real Brushes	127	0	41	Live!Drums	
	Power Kit 2	127	0	88	Live!Drums	
	Acoustic Kit	127	0	89	Live!Drums	
	House Kit	127	0	60	Drums	
	Rock Kit	127	0	90	Live!Drums	
	Drum Machine	127	0	61	Drums	
	Studio Kit	127	0	86	Live!Drums	
	Analog T8 Kit	127	0	58	Drums	
	Analog T9 Kit	127	0	59	Drums	
	Jazz Kit	127	0	32	Drums	
	Break Kit	127	0	57	Drums	
	Hit Kit	127	0	4	Drums	
Hip Hop Kit	127	0	56	Drums		
Room Kit	127	0	8	Drums		
Dance Kit	127	0	27	Drums		
Electro Kit	127	0	24	Drums		

CVP-709**Main Category: PERC&DRUMS**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Drum Kits	Analog Kit	127	0	25	Drums
	Symphony Kit	127	0	48	Live!Drums
World Perc Kits	Pop Latin Kit 2	126	0	44	Live!SFX
	Cymbal Kit	126	0	49	Live!SFX
	Turkish Kit	126	0	67	Live!SFX
	Cuban Kit	126	0	40	Live!SFX
	Pop Latin Kit	126	0	43	Live!SFX
Vocal Effects	Gospel AdLibs	126	0	110	Live!SFX
	Vocal Effects Kit	126	0	109	Live!SFX
SFX	New SFX Kit 1	126	0	2	Live!SFX
	Helicopter	104	0	125	Live!
	New SFX Kit 2	126	0	3	Live!SFX
	Applause 1	104	0	126	Live!
	Noises Kit	126	0	8	SFX
	Applause 2	104	1	126	Live!
	Sea Shore	104	0	122	Live!
	Gun Shot	104	0	127	Live!

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Lead	Square Stack (Pedal)	8	32	123	S.Art!
	Nasty Saw	104	10	90	Regular
	Growling Hook	104	11	90	Regular
	Loony Lead	104	15	90	Regular
	Ten Percent	104	18	90	Regular
	Cool HiPa (Pedal)	8	34	123	S.Art!
	Wheel Tech (Pedal)	8	36	123	S.Art!
	Redoubling (Pedal)	8	37	123	S.Art!
	Hard Teeth	104	16	90	Regular
	Cyclist	104	17	90	Regular
	Crowds	104	19	90	Regular
	Gemini	104	20	90	Regular
	Hands Up!	104	21	90	Regular
	Straight Raver	104	22	90	Regular
	Trance Artist	104	23	90	Regular
	Punchy Chordz	104	24	90	Regular
	Trancy Chordz	104	25	90	Regular
	Trancy Noise	104	1	122	Regular
	Unison Strings	104	9	50	Regular
	Med Det Strings	104	10	50	Regular
	Four Stack (Pedal)	8	33	123	S.Art!
	Nu Line (Pedal)	8	35	123	S.Art!
	Yipping	104	12	90	Regular
	Unstable Lead	104	13	90	Regular
	Persecutor	104	14	90	Regular
	Short Unison	104	4	84	Regular
	Brite Decay	104	5	84	Regular
	Tekk Tune	104	6	84	Regular
	Stacc Melody	104	7	84	Regular
	Pitchy Patch	104	8	84	Regular
	Soft Chordsyn	104	9	84	Regular
	Chord Buddy	104	10	84	Regular
	Tune Comp	104	11	84	Regular
	Arpeggio Line	104	12	84	Regular
	Soft Stepper	104	24	88	Regular
	PWM Picks	104	25	88	Regular
	Square Stepz	104	26	88	Regular
	Dyna Sequence	104	27	88	Regular
	Tri Picks	104	28	88	Regular
	Cracky	104	29	88	Regular
	Sub Lead	104	0	80	Regular
	Wire Lead	0	120	81	Regular

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Synth Lead	Soft Saw	104	16	81	Regular	
	Soft R&B	0	119	80	Regular	
	Fusion Lead	104	15	81	Regular	
	Early Lead	0	118	81	Regular	
	Oxygen	0	122	81	Regular	
	Soft Square	104	5	80	Regular	
	Matrix	0	123	81	Regular	
	Detuned Vintage	104	1	84	Regular	
	PWM Lead	104	1	81	Regular	
	Hipa Lead	0	118	84	Regular	
	Brassy Lead	104	5	62	Regular	
	Punchy Hook	0	127	81	Regular	
	Punch Lead	104	7	81	Regular	
	Crying Lead	0	114	87	Regular	
	Flange Filter	104	2	81	Regular	
	Hip Lead	0	113	80	Regular	
	Mouth Lead	104	0	81	Regular	
	Hop Lead	0	117	80	Regular	
	Tech Lead	0	117	84	Regular	
	Analogon	0	115	81	Regular	
	Tekkline	0	116	84	Regular	
	Skyline	0	115	84	Regular	
	Soft Mini	0	124	80	Regular	
	Bleep Lead	104	0	84	Regular	
	Fire Wire	0	116	81	Regular	
	Synth Perc	New Heaven	104	10	88	Regular
		Heaven Pad	104	3	91	Regular
		Fantasy Bells	104	11	88	Regular
		Breath Bells	104	15	88	Regular
		Itopia Bells	104	13	88	Regular
		Next Generation	104	9	51	Regular
		Sinesphere	104	18	88	Regular
		Organ Bells	104	12	88	Regular
Spectrum Theme		104	14	88	Regular	
Sky Bells		104	16	88	Regular	
Flying Harmonics		104	1	99	Regular	
Perc Pad		104	0	101	Regular	
Nylon Heaven		104	2	99	Regular	
Mediterrain		0	114	99	Regular	
Airy Harp		104	17	88	Regular	
Lektro Codes		104	2	84	Regular	
Nylon Pad		104	0	99	Regular	
Simple Comp		104	12	81	Regular	
Bellsphere		104	5	88	Regular	
Ballad Comp		104	6	88	Regular	
Heaven Bell		104	0	100	Regular	
Digital Sequenced		104	2	87	Regular	
Bright Pad Bell		104	7	88	Regular	
Analog Sequenced		104	3	87	Regular	
Wild PWM		104	4	80	Regular	
Perc Sequence FS		104	6	87	Regular	
Resonant Clavi		104	2	90	Regular	
Perc Sequence FM 1		104	7	87	Regular	
Resonance Comp		104	4	62	Regular	
Perc Sequence FM 2		104	8	87	Regular	
Synth Sticks		104	0	106	Regular	
Attack		104	4	81	Regular	
Saz Feeze		104	0	97	Regular	
PWM Percussion	104	6	81	Regular		
Eastern Air	104	1	97	Regular		
Nomad	104	1	104	Regular		
Xtune	104	1	87	Regular		
Stack Bell	104	8	88	Regular		

CVP-709

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Perc	Perc Sequence Saw	104	11	81	Regular
	Nice Bell	104	9	88	Regular
Synth Strings	Synth Strings 1	0	112	50	Regular
	Butter Strings	104	2	50	Regular
	Synth Strings 2	0	113	50	Regular
	Bright Saw Pad	0	113	90	Regular
	Ober Strings	0	113	51	Regular
	Soft Ensemble	104	1	50	Regular
	Hipa Strings	0	114	95	Regular
	80s Pad	104	1	51	Regular
	Octave Strings	104	4	50	Regular
	Bright Pop Pad	104	3	50	Regular
	Doux Flange	104	3	95	Regular
	Premium Pad	104	0	51	Regular
	Light Pad	104	2	51	Regular
	Bright Pad Classic	104	3	90	Regular
	Medium Tune Pad	104	0	50	Regular
Synth Brass	Analog Brass	0	112	63	Regular
	1984 Synth	104	20	81	Regular
	Fat Synth Brass	0	116	63	Regular
	80s Brass	0	113	62	Regular
	Thinth Brass	104	0	62	Regular
	Funky Analog	0	115	62	Regular
	Brass Profit	104	1	62	Regular
	Techno Brass	0	114	62	Regular
	Ober Brass	0	113	63	Regular
	Ober Horns	0	115	63	Regular
	Slow PWM Brass	104	2	62	Regular
	Soft Velo Brass	0	120	62	Regular
	Fast PWM Brass	104	6	62	Regular
	Soft Analog	0	114	63	Regular
	Synth Pad	All or Nothing	104	6	101
Whisper Gallery		104	0	92	Regular
Disisweeper		104	7	101	Regular
Hybrid Lines		104	4	91	Regular
Spectrum Pad		104	5	94	Regular
Midnight Special		104	3	101	Regular
Hybrid Pad		104	22	88	Regular
Atmo 5th		104	6	89	Regular
Deep Motion		104	4	95	Regular
Pad Voices		104	6	95	Live!
Skydiver		0	112	101	Regular
Aerosphere		104	1	94	Regular
Cross Phase		104	1	101	Regular
New Atmosphere		104	4	89	Regular
Galaxy Pad		104	3	88	Regular
VP Soft		104	0	89	Regular
Night Motion		104	4	88	Regular
Hot Swell		104	2	95	Regular
Morning Dew		104	0	94	Regular
Dark Fat Saw		104	2	89	Regular
Vapor Pad		104	1	89	Regular
Dark Light		104	3	89	Regular
Space Rider		104	1	95	Regular
Ambient Pad		104	0	88	Regular
Pearls Pad		104	2	88	Regular
Bright Fat Saw		104	5	90	Regular
Breath Pad		104	0	91	Regular
Early Digital		104	0	93	Regular
Noble Man		104	1	88	Regular
Super Dark Pad		0	119	89	Regular
Analog Pad		0	120	89	Regular
Analog Swell		0	119	95	Regular
Dark Angel Pad		0	121	89	Regular

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Synth Pad	Big Octave Pad	0	115	90	Regular	
	Lite Pad	0	122	89	Regular	
	Golden Age	0	115	88	Regular	
	Pop Pad	0	112	90	Regular	
	Solaris	0	114	94	Regular	
	Glorious Phase	0	114	90	Regular	
	Insomnia	0	113	94	Regular	
	Ober Sweep	0	115	95	Regular	
	Neo Warm Pad	0	115	89	Regular	
	Time Travel	0	116	88	Regular	
	Cyber Pad	0	113	99	Regular	
	Bubblespace	0	113	101	Regular	
	Bright Ober	0	113	95	Regular	
	Mellow Pad	0	117	95	Regular	
	Dark Pad	0	118	95	Regular	
Synth Dance	Ana Dayz	104	3	51	Regular	
	HPF Dance	104	0	90	Regular	
	Bright Pad Trance	104	4	90	Regular	
	Detuned Saw Octave	104	8	81	Regular	
	Chillin Chords	104	6	51	Regular	
	Dancy Hook	104	9	81	Regular	
	Trance (Pedal)	104	0	95	Regular	
	Vinalog Saw	104	3	81	Regular	
	Club Lead	104	3	62	Regular	
	Talk Mod Lead	104	0	87	Regular	
	Trance Perc	104	5	81	Regular	
	Chorus Saw Lead	104	10	81	Regular	
	Chordmaster	104	13	81	Regular	
	Faaat Comp	104	4	51	Regular	
	Trance Sequence 1	104	4	87	Regular	
	Fat Saw Hook	104	7	51	Regular	
	Trance Sequence 2	104	5	87	Regular	
	Tech Glide	104	14	81	Regular	
	Trance Sequence 3	104	1	90	Regular	
	Dance Chords	104	5	51	Regular	
	Dance Hook	0	112	86	Regular	
	Trance Lead	0	121	80	Regular	
	Octave Hook	0	113	86	Regular	
	Synth Effects	Water Games	104	4	101	Regular
		Spectralis	104	4	94	Regular
My Generation		104	5	101	Regular	
Metallic Rain		104	8	101	Regular	
Rainy Day		104	5	89	Regular	
Ambient Theme		104	20	88	Regular	
Warped Waves		104	2	94	Regular	
Reflecting Zone		104	21	88	Regular	
Sound Pictures		104	3	94	Regular	
The Fog		104	9	101	Regular	
Mystic Pad		104	6	94	Regular	
Sixth Sense		104	2	101	Regular	
Randomizer		104	10	101	Regular	
Pitch Fall		104	0	103	Regular	
Atlantis		104	11	101	Regular	
Perc Sequence Hipa	104	9	87	Regular		
Tric-Trac	104	2	97	Regular		

CVP-709

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
Legacy	Piano	Studio Grand	0	115	0	Live!
		Grand Piano	0	113	0	Live!
		Pop Grand 2	104	11	0	Natural!
		Pop Grand	104	5	0	Live!
		Stage Piano	104	10	0	Natural!
		Rock Piano	104	4	0	Live!
		Warm Grand	0	114	0	Live!
		Bright Piano	0	112	1	Live!
		Ambient Piano	104	9	0	Natural!
		Ambient Piano	104	3	0	Live!
		Cocktail Piano	104	1	3	Natural!
		Cocktail Piano	104	0	3	Live!
		Honky Tonk	0	122	3	Natural!
		Honky Tonk	0	112	3	Regular
		Grand Piano 1octave	104	2	3	Natural!
		Grand Piano 2octaves	104	3	3	Natural!
		Octave Piano 1	0	113	3	Live!
		Octave Piano 2	0	114	3	Live!
		MIDI Grand	0	112	2	Regular
		MIDI Grand	104	0	2	Live!
		MIDI GrandPad	104	1	2	Live!
		MIDI GrandSyn	104	1	0	Live!
		Piano Orchestra	104	2	0	Live!
	Harpsichord	0	112	6	Live!	
	E.Piano	Ballad Stack	0	114	2	Regular
		Jazz Chorus	0	118	5	Regular
		Hyper Tines	0	113	5	Regular
		Venus EP	0	114	5	Regular
		Super DX	0	117	5	Regular
		Polaris EP	0	115	4	Regular
		DX Modern	0	112	5	Regular
		New Tines	0	116	5	Regular
		Phase EP	0	120	4	Regular
		Modern EP	0	115	5	Regular
		Funk EP	0	112	4	Regular
		Chorus Bell	0	120	5	Regular
		Stereo Clavi	0	114	7	Regular
	Organ	Dance Organ	0	113	17	Regular
		Click Organ	0	112	17	Regular
		Rotary Switch	0	110	17	Cool!
		Rotary Drive	0	116	18	Regular
		Full Rocker 2	104	3	18	Cool!
		Gospel Organ	0	119	16	Regular
Purple Organ		0	114	18	Regular	
Percussive Organ		0	119	17	Regular	
Drawbar Organ 1		0	120	17	Regular	
Drawbar Organ 2		0	115	16	Regular	
Rock Organ 1		0	112	18	Regular	
Jazz Organ 1		0	112	16	Regular	
Rock Organ 2		0	119	18	Regular	
Jazz Organ 2		0	113	16	Regular	
Rock Organ 3		0	113	18	Regular	
Jazz Organ 3		0	120	16	Regular	
Bright Drawbar		0	116	16	Regular	
Electric Organ		0	118	17	Regular	
60s Organ		0	116	17	Regular	
Reed Organ		0	112	20	Regular	
Tibia 8'&4' Accomp		0	122	16	Regular	
Tibia 16'&4' Accomp		0	114	16	Regular	
Tibia Full Accomp		0	114	17	Regular	
Tibia 8' Accomp		0	122	17	Regular	
Vox 8' Accomp		0	123	17	Regular	
Vox & Tibia Accomp		0	125	16	Regular	
Classic Jazz		0	126	16	OrganFlutes	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
Legacy	A.Guitar	Flamenco Guitar	8	33	0	S.Art!
		Folk Guitar	0	112	25	Regular
		Campfire Guitar	0	115	25	Regular
		18String Guitar	0	119	25	Regular
	E.Guitar	Vintage Amp	8	40	3	S.Art!
		70s Solid Guitar	104	1	27	Cool!
		Warm Solid	104	2	27	Cool!
		Clean Solid	104	3	27	Cool!
		Muted Guitar	0	112	28	Regular
		Funk Guitar	0	113	28	Regular
		Solid Chord	0	121	27	Regular
		Solid Guitar	0	118	27	Regular
		Electric 12String	0	119	27	Regular
		Tremolo Guitar	0	113	27	Regular
		Wah Guitar	0	122	27	Regular
		Chorus Guitar	0	124	27	Regular
		Vintage Trem	0	120	27	Regular
		Deep Chorus	0	114	27	Regular
		Bright Clean	0	116	27	Regular
		DX Jazz Guitar	0	117	26	Regular
		Half Drive	104	0	29	Cool!
		Smooth Lead	0	119	26	Regular
		Rock Guitar	0	116	29	Regular
		Lead Guitar	0	114	29	Regular
		Overdrive Guitar	0	112	29	Regular
		Guitar Hero	104	0	30	Cool!
		Heavy Rock	104	1	30	Cool!
		Power Chord	0	117	30	Regular
		Voodoo Lead	0	116	30	Regular
		Distortion Guitar	0	112	30	Regular
		Feedback Guitar	0	113	29	Regular
	Bass	Click Bass	0	115	38	Regular
		Punchy Bass	0	117	38	Regular
		Analog Bass	0	112	39	Regular
		DX Funk Bass	0	113	37	Regular
		Dry Synth Bass	0	116	39	Regular
		80s Synth Bass	0	115	39	Regular
		HiQ Bass	0	113	38	Regular
		Acoustic Bass	0	112	32	Regular
	Accordion	Accordion	0	116	21	Regular
		Small Accordion	0	115	21	Regular
		Modern Harp	0	113	22	Regular
		Blues Harp	0	114	22	Regular
		Ballroom Accordion	0	112	23	Regular
		Soft Accordion	0	114	21	Regular
		Tutti Accordion	0	113	21	Regular
	Musette Accordion	0	112	21	Regular	
	Strings	Orchestra Strings	0	116	49	Live!
		Orch Strings	0	113	48	Regular
		Symphonic	0	114	48	Regular
		Concerto Strings	0	115	48	Regular
		Slow Strings	0	113	49	Regular
		Strings	0	112	48	Regular
Tremolo Strings		0	112	44	Regular	
Bow Strings		0	116	48	Regular	
Marcato		0	115	49	Regular	
Pizzicato		0	112	45	Regular	
String Falls		0	121	48	Live!	
Analogue Strings		0	112	51	Regular	
Orch & Flute		0	119	49	Regular	
Orch & Oboe		0	121	49	Regular	
Orch & Horns	0	118	49	Regular		
String Quartet	0	114	49	Regular		
Harp	0	112	46	Regular		

CVP-709

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Strings	Hackbrett 2	0	113	46	Regular	
		Banjo 2	0	112	105	Regular	
		Sitar 2	0	112	104	Regular	
	Brass	Brass Section	0	112	61	Regular	
		Brass Combo	0	115	66	Regular	
		Natural Brass	0	124	61	Regular	
		Bright Brass	0	120	61	Regular	
		French Horns	0	112	60	Live!	
		Mellow Horns	0	119	61	Regular	
		Symphony Horns	0	115	60	Live!	
		Symphony Brass	0	119	60	Live!	
		Big Band Brass	0	113	61	Regular	
		Mellow Brass	0	116	61	Regular	
		Big Brass	0	121	61	Regular	
		Small Brass	0	117	61	Regular	
		Soft Brass	0	123	61	Regular	
		Sforzando	0	125	61	Regular	
		High Brass	0	115	61	Regular	
		Breath Brass	0	116	60	Regular	
		Full Horns	0	114	61	Regular	
		Trumpet Ensemble	0	122	61	Regular	
		Brass Hit	0	126	61	Regular	
		Trombone Section	0	113	57	Regular	
		Smooth Trombone	0	118	57	Regular	
		Solo Trombone	0	112	57	Regular	
		Trombone	0	116	57	Regular	
		Soft Trombone	0	115	57	Regular	
		Mellow Trombone	0	114	57	Regular	
		Solo Trumpet	0	112	56	Regular	
		Jazz Trumpet	0	116	56	Regular	
		Muted Trumpet	0	112	59	Regular	
		Flugel Horn	0	113	56	Regular	
		Tuba 2	0	112	58	Regular	
		Hybrid Comp	0	119	62	Regular	
		Hybrihorn	0	113	60	Regular	
		Hybripad	0	114	60	Regular	
	Pop Brass	0	118	61	Regular		
	Synth Brass	0	112	62	Regular		
	Woodwind	Soprano Sax	0	112	64	Regular	
		Alto Sax	0	112	65	Regular	
		Tenor Sax	0	112	66	Regular	
		Baritone Sax	0	112	67	Regular	
		Alto Sax	0	114	65	Sweet!	
		Saxophone	104	0	66	Sweet!	
		Growl Sax	0	118	66	Regular	
		Sax Stack	0	124	66	Regular	
		Saxy Mood	0	120	66	Regular	
		Flute	0	112	73	Regular	
		Oboe	0	112	68	Regular	
		Clarinet	0	112	71	Regular	
		Bassoon	0	112	70	Regular	
		Ethnic Flute	0	112	75	Regular	
		Orch Flute	104	0	73	Sweet!	
		Orch Oboe	104	0	68	Sweet!	
		Woodwinds Ensemble	0	113	66	Regular	
		Choir	Voices	0	113	54	Regular
			Choir	0	112	52	Regular
	Air Choir		0	112	54	Regular	
	Hah Choir		0	114	52	Regular	
	Uuh Choir		0	115	52	Regular	
	Boys Choir Aah		104	8	52	Live!	
	Boys Choir Ooh		104	8	53	Live!	
	Gospel Voices		0	116	52	Live!	
	Humming		0	118	52	Live!	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Choir	Vox Humana	0	112	53	Regular	
		Sweet Heaven	0	118	88	Regular	
		Dream Heaven	0	121	88	Regular	
		Bell Heaven	0	119	88	Regular	
		Pan Heaven	0	120	88	Regular	
		Pro Heaven	0	122	88	Regular	
		Sunbeam	0	123	88	Regular	
		Hah Pad	0	116	94	Regular	
		Percussion	Vibraphone	0	112	11	Regular
			Marimba	0	112	12	Regular
			Xylophone	0	112	13	Regular
	Glockenspiel		0	112	9	Regular	
	Drum Kit	Standard Kit 1	127	0	0	Live!Drums	
		Standard Kit 2	127	0	1	Live!Drums	
		Rock Kit	127	0	16	Drums	
		Brush Kit	127	0	40	Live!Drums	
		SFX Kit 1	126	0	0	SFX	
		SFX Kit 2	126	0	1	SFX	
		Arabic Kit	126	0	35	SFX	
		Pad	Psycho Pad	0	118	101	Regular
	Far East		0	112	97	Regular	
	Disclosure		0	116	89	Regular	
	Mystery		0	113	97	Regular	
	Sirius		0	114	101	Regular	
	S&H Groove		0	115	101	Regular	
	Velo Ashrams		0	116	101	Regular	
	Evening Stars		0	117	101	Regular	
	Angel Vibes		0	114	98	Regular	
	Glass Pad		0	114	93	Regular	
	DX Pad		0	112	92	Regular	
	Symbiont		0	113	88	Regular	
	Dark Moon		0	113	89	Regular	
	Ionosphere		0	115	94	Regular	
	Millennium		0	117	88	Regular	
	Atmosphere		0	112	99	Regular	
	Equinox		0	112	94	Regular	
	Fantasia		0	112	88	Regular	
	Stargate		0	114	88	Regular	
	Area 51		0	112	89	Regular	
	Digital Pad		0	115	93	Regular	
	Dunes		0	114	89	Regular	
	Messenger		0	116	95	Regular	
	Wave 2001		0	112	95	Regular	
	Xenon Pad		0	112	91	Regular	
	Magic Bell		8	32	120	S.Art!	
	Synth		Pro Lead	0	113	83	Regular
			Funky Lead	0	121	81	Regular
			Portatone	0	112	84	Regular
			Adrenaline	0	113	84	Regular
		Stardust	0	112	98	Regular	
		Aero Lead	0	112	83	Regular	
		Mini Lead	0	114	80	Regular	
		Sun Bell	0	113	98	Regular	
Hi Bias		0	116	80	Regular		
Vinyl Lead		0	115	80	Regular		
Pan Lead		0	122	80	Regular		
String Bells		0	124	88	Regular		
Padbells	0	126	88	Regular			
Big Tune	0	118	89	Regular			
Trumpet Saw	0	125	81	Regular			
Paraglide	0	114	84	Regular			
Robolead	0	124	81	Regular			
Fargo	0	119	81	Regular			
Big Lead	0	113	81	Regular			

CVP-709

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
Legacy	Synth	Warp	0	117	81	Regular
		Impact	0	113	87	Regular
		Under Heim	0	112	87	Regular
		Crystal Eyes	0	125	88	Regular
		Melody Maker	0	117	89	Regular
		Attack Saw	0	126	81	Regular
		Perc Square	0	123	80	Regular
		Square Lead	0	112	80	Regular
		Saw Lead	0	112	81	Regular
		Pop Lead	0	120	80	Regular
		Bright Mini	0	125	80	Regular
		Orbit Sine	0	126	80	Regular
		Blaster	0	114	81	Regular
		Tiny Lead	0	118	80	Regular
MegaVoices	A.Guitar	Nylon Guitar	8	0	0	MegaVoice
		Flamenco Guitar	8	3	0	MegaVoice
		Spanish Medium Guitar	8	4	0	MegaVoice
		Spanish Hard Guitar	8	5	0	MegaVoice
		Steel Acoustic Guitar	8	1	1	MegaVoice
		Steel Acoustic Guitar Slap	8	2	1	MegaVoice
		Steel Guitar Twin 1	8	5	1	MegaVoice
		Steel Guitar Twin 2	8	6	1	MegaVoice
		Steel Guitar	8	0	1	MegaVoice
		12String Guitar	8	1	2	MegaVoice
		12String Guitar Twin 1	8	7	1	MegaVoice
		12String Guitar Twin 2	8	8	1	MegaVoice
		Hi String Guitar	8	0	2	MegaVoice
		E.Guitar	Solid Guitar 1	8	1	3
	Solid Guitar 2		8	2	3	MegaVoice
	Finger Guitar		8	4	3	MegaVoice
	Finger Slap Guitar		8	5	3	MegaVoice
	Vintage Pick Guitar		8	6	3	MegaVoice
	Vintage Slap Guitar		8	7	3	MegaVoice
	Clean Guitar		8	0	3	MegaVoice
	Single Coil Guitar		8	3	3	MegaVoice
	Slap Amp Guitar		8	8	3	MegaVoice
	Jazz Guitar		8	0	6	MegaVoice
	Overdrive Guitar		8	0	4	MegaVoice
	Distortion Guitar	8	0	5	MegaVoice	
	Bass	Acoustic Bass	8	0	16	MegaVoice
		Vintage Round	8	1	17	MegaVoice
		Vintage Flat	8	2	17	MegaVoice
		Vintage Pick	8	1	18	MegaVoice
		Electric Bass	8	0	17	MegaVoice
		Pick Bass	8	0	18	MegaVoice
	Fretless Bass	8	0	19	MegaVoice	
	Strings	Classical Strings	8	1	48	MegaVoice
		Real Strings	8	1	49	MegaVoice
		Large Strings	8	0	49	MegaVoice
		Small Strings	8	0	48	MegaVoice
	Vocal	Gospel Choir	8	0	54	MegaVoice
		Male Voice Choir	8	0	51	MegaVoice
		Pop Haa	8	0	100	MegaVoice
		Pop Daa	8	0	101	MegaVoice
		Pop Baa	8	0	102	MegaVoice
		Pop Hee	8	0	110	MegaVoice
		Pop Bee	8	0	107	MegaVoice
		Pop Hoo	8	0	105	MegaVoice
		Pop Doo	8	0	106	MegaVoice
		Pop Shoo	8	0	103	MegaVoice
		Pop Haa Legato 2	8	0	115	MegaVoice
		Pop Hoo Legato 2	8	0	120	MegaVoice
Pop Hee Legato 2		8	0	125	MegaVoice	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
MegaVoices	Brass	Pop Horns 1	8	1	56	MegaVoice
		Pop Horns 2	8	2	56	MegaVoice
		Trumpet	8	0	64	MegaVoice
		Brass	8	0	56	MegaVoice
	Woodwind	Tenor Sax	8	0	82	MegaVoice

CVP-705

Main Category: PIANO

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
VRM Piano	CFX Grand	108	0	0	VRM
	Bösendorfer	108	6	0	VRM
	Pop Grand	108	17	1	VRM
	Mellow Piano	108	18	0	VRM
	Studio Grand	108	30	0	VRM
	Themic Grand	108	6	1	VRM
	Bright Piano	108	16	1	VRM
	Ambient Piano	108	27	3	VRM
	Rock Piano	108	16	2	VRM
	Stage Piano	108	31	0	VRM
	Grand Piano 1octave	108	22	1	VRM
	Grand Piano 2octaves	108	23	1	VRM
	Cocktail Piano	108	28	3	VRM
Grand Piano	CFX Grand	0	122	0	Natural!
	Bösendorfer	104	18	0	Natural!
	Pop Grand	104	6	0	Natural!
	Mellow Piano	0	124	0	Natural!
	Studio Grand	104	19	0	Natural!
	Themic Grand	104	18	1	Natural!
	Bright Piano	0	123	0	Natural!
	Ambient Piano	104	19	3	Natural!
	Rock Piano	0	124	2	Natural!
	Stage Piano	104	20	0	Natural!
	Grand Piano 1octave	0	123	3	Natural!
	Grand Piano 2octaves	0	124	3	Natural!
	Cocktail Piano	104	20	3	Natural!
Upright Piano	Upright Piano	104	13	0	Natural!
	Pop Upright	104	13	1	Natural!
	70s Ballad Piano	104	14	0	Natural!
	Chill Out Piano	104	15	0	Natural!
	Honky Tonk Upright	104	13	3	Natural!
	Saloon Upright	104	14	1	Natural!
	Upright 1octave	104	14	3	Natural!
	Upright 2octaves	104	15	3	Natural!
Piano Layer	Superstar Grand	108	25	4	Natural!
	Imperial Ballad	108	26	4	Natural!
	MIDI Grand	104	2	2	Natural!
	MIDI Grand Pad	104	3	2	Natural!
	Bright Grand Pad	104	8	0	Natural!
	Grand Pad Layer	108	32	2	Natural!
	Piano & EP	108	25	2	Natural!
	Grand Piano & Strings	108	23	0	Natural!
Grand Piano & Orchestra	104	12	0	Natural!	
Electric Piano	Suitcase EP	0	118	4	Cool!
	Vintage EP	0	116	4	Regular
	Electric Piano 1	0	119	4	Cool!
	Electric Piano 2	0	122	4	Natural!
	Stage EP	0	117	4	Regular
	Funky EP	0	123	4	Natural!
	Tremolo Suitcase EP	0	113	4	Cool!
	Tremolo Stage EP	0	124	4	Natural!
	Smooth Tine	0	119	5	Regular
	CP80 Stage	0	113	2	Regular
	Magnetics	104	0	4	Regular
FM E.Piano	Studio Ballad DX	104	9	5	Regular
	Sparkle Stack	0	121	5	Cool!
	Sweet DX	104	0	5	Cool!
	Ballad DX	0	124	5	Cool!
	DX Dynamics	0	123	5	Cool!
	Ballad Bells	104	2	5	Cool!
	Galaxy EP	0	114	4	Cool!
	DX7 EP	0	122	5	Natural!
	Dream DX	104	3	5	Cool!
	Midnight DX	104	1	5	Cool!

Main Category: PIANO

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
FM E.Piano	Piano Sweeper	104	3	99	Regular
	Pianosphere	104	19	88	Regular
Clavi	Clavi Bright	0	112	7	Regular
	Wah Clavi	0	113	7	Regular
	Phase Clavi	0	115	7	Regular
Harpsichord	Harpsichord 1	0	122	6	Natural!
	Harpsichord 2	8	32	112	S.Art!
	Harpsichord Coupler	0	123	6	Natural!
	Grand Harpsichord	0	113	6	Live!
	Harpsichord & Strings	0	124	6	Natural!

Main Category: ORGAN

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Tonewheel Organ	Whiter Bars	8	32	29	S.Art!
	Curved Bars	0	121	16	Cool!
	All Bars Out	8	32	30	S.Art!
	Even Bars	0	111	16	Cool!
	Jazz Rotary	8	32	113	S.Art!
	Vintage Fast	0	127	16	Cool!
	Classic Bars	8	34	29	S.Art!
	Scanner Jazz	0	118	18	Cool!
	Rock Rotary	8	33	113	S.Art!
	Organ-a-Go-Go	104	0	16	Cool!
	Prog Rock Organ	8	33	29	S.Art!
	Organ Accomp 1	0	108	17	Regular
	R&B Tremolo	0	111	18	Cool!
	Organ Accomp 2	0	107	17	Regular
	Classic Jazz	0	117	16	Cool!
	Organ Accomp 3	0	106	17	Regular
	Hold It Fast	0	111	17	Cool!
	Organ Accomp 4	0	105	17	Regular
	Full Rocker	0	115	18	Cool!
	Organ Accomp 5	0	104	17	Regular
	Whiter Bars Slow	104	1	17	Cool!
Whiter Bars Fast	104	0	17	Cool!	
Jazz Organ Slow	0	126	17	Cool!	
Jazz Organ Fast	0	127	17	Cool!	
All Bars Out Slow	104	1	18	Cool!	
All Bars Out Fast	104	0	18	Cool!	
All Bars Phase	104	2	18	Cool!	
Rotor Organ	0	117	18	Cool!	
Mellow Drawbar	0	115	17	Regular	
Two Channels Organ	0	109	17	Cool!	
Transistor Organ	60s Combo 1	104	32	16	Cool!
	60s Combo 2	104	33	16	Cool!
	60s Combo 3	104	34	16	Cool!
	60s Combo 4	104	35	16	Cool!
	Euro Organ	0	118	16	Regular
Classical Pipe	Pipe Organ Principal	0	123	19	Natural!
	Chapel Organ	0	113	19	Regular
	Full Organ	0	112	19	Regular
	Hymn Organ	0	114	19	Regular
	Pipe Organ Tutti	0	122	19	Natural!
	Church Organ	0	115	19	Regular
Theatre Pipe	Full Theatre	0	127	18	Regular
	Tibia 8'	104	6	17	Regular
	Sweet Theatre	0	126	18	Regular
	Tibia 8'&4'	104	9	16	Regular
	Ballroom Organ	0	115	3	Regular
	Tibia 16'&4'	104	8	16	Regular
	Tibia Chorus	104	5	17	Regular
	Vox Humana 8'	104	7	17	Regular

CVP-705

Main Category: ORGAN

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Theatre Pipe	Vox Humana & Tibia	104	10	16	Regular	
	Theatre Trumpet 8'	0	124	16	Regular	
	Theatre Kinura 8'	0	123	16	Regular	
	Theatre Trumpet & Kinura	0	125	17	Regular	
	Theatre Trumpet 16'&8'	0	124	17	Regular	
Organ Flutes	Organ Flutes	10	0	8	OrganFlutes	
	USD Smile	10	1	8	OrganFlutes	
	Reggae Bars	10	2	8	OrganFlutes	
	Warm Theatre	10	3	8	OrganFlutes	
	Organ Pops	10	4	8	OrganFlutes	
	Rock Organ	10	5	8	OrganFlutes	
	Soul Percussion	10	6	8	OrganFlutes	
	Gospel Truth	10	7	8	OrganFlutes	
	Pad Organ	10	8	8	OrganFlutes	
	Full Organ	10	9	8	OrganFlutes	
	String Bars	10	0	9	OrganFlutes	
	Latin Spin	10	1	9	OrganFlutes	
	Shady Bars	10	2	9	OrganFlutes	
	Funk Organ	10	3	9	OrganFlutes	
	Ballad Organ	10	4	9	OrganFlutes	
	Rich Bars	10	5	9	OrganFlutes	
	Trumpet Bars	10	6	9	OrganFlutes	
	Soul Bars	10	7	9	OrganFlutes	
	Clari Bars	10	8	9	OrganFlutes	
	Jazz Squabble	10	9	9	OrganFlutes	
	Euro Perc	10	0	10	OrganFlutes	
	Ballad Euro	10	1	10	OrganFlutes	
	Euro Reeds	10	2	10	OrganFlutes	
	Even Warmth	10	3	10	OrganFlutes	
	Bright Euro	10	4	10	OrganFlutes	
	Euro Accomp 1	10	7	10	OrganFlutes	
	Full Euro	10	6	10	OrganFlutes	
	Euro Accomp 2	10	8	10	OrganFlutes	
	Euro Pops	10	5	10	OrganFlutes	
	Euro Accomp 3	10	9	10	OrganFlutes	
	Harmonica	Harmonica	0	112	22	Sweet!
		Modern Harp	0	113	22	Regular
		Blues Harp	0	114	22	Regular
Accordion	Full Accordion Register	104	2	21	Regular	
	French Musette Acc.	0	119	21	Regular	
	Master Accordion	0	118	21	Regular	
	Steirische	0	117	21	Regular	
	Jazz Accordion	0	120	21	Regular	
	Cassotto	104	0	21	Regular	
	Cajun	104	3	21	Regular	
	Accordion Clarinet	104	1	21	Regular	
	Bandoneon	0	113	23	Regular	
	Tango Accordion	0	114	23	Regular	
	Full Register Bass	104	5	21	Regular	
	Musette Bass	0	123	21	Regular	
	Master Bass	0	122	21	Regular	
	Cajun Bass	104	6	21	Regular	
	Accordion Bass	0	121	21	Regular	
	Tango Bass	0	115	23	Regular	

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Nylon Acoustic	Concert Guitar	8	32	0	S.Art!
	Dynamic Nylon	0	116	24	Live!
	Flamenco Guitar	8	33	0	S.Art!
	Hard Flamenco	0	118	24	Live!
	Nylon Guitar	8	34	0	S.Art!
	Classical Guitar	0	115	24	Live!
	Slide Nylon	0	117	24	Live!
	Nylon Mute	0	119	24	Live!
	Electro Acoustic Guitar	8	35	0	S.Art!
Steel Acoustic	Steel Guitar	8	32	1	S.Art!
	Slide Steel	0	118	25	Live!
	Folk Guitar Harmonics	8	33	1	S.Art!
	Dynamic Steel	0	116	25	Live!
	Steel Guitar Strum	0	117	25	Live!
	Steel Guitar Mute	0	120	25	Live!
	12String Guitar	0	113	25	Live!
Clean Solid	Bright Chorus	8	45	3	S.Art!
	Vintage Slap	8	48	3	S.Art!
	Ballad Delay	8	46	3	S.Art!
	Vintage Pure	8	47	3	S.Art!
	Finger Bright	8	50	3	S.Art!
	Cool Wah Guitar	104	4	27	Regular
	Semi Acoustic	8	33	6	S.Art!
	Jazz Vintage	8	38	6	S.Art!
	Jazz Artist	8	39	6	S.Art!
	Smooth Jazz Guitar	8	35	6	S.Art!
	Shadowed Guitar	8	56	3	S.Art!
	Finger Chorus	8	42	3	S.Art!
	Vintage Spring	8	54	3	S.Art!
	Light Chorus	8	53	3	S.Art!
	Country Pick	8	44	3	S.Art!
	Finger Slap Slide	8	51	3	S.Art!
	Warm Solid	8	33	3	S.Art!
	Warm Electric	8	32	3	S.Art!
	Clean Solid	8	34	3	S.Art!
	Clean Electric	8	35	3	S.Art!
	Slap Solid	0	108	27	Cool!
	Lounge Guitar	104	1	26	Regular
	Funk Slap	8	49	3	S.Art!
	Single Coil Clean	8	39	3	S.Art!
	70s Solid Guitar	8	38	3	S.Art!
	Pure Vintage	8	42	5	S.Art!
	Vintage Open	0	123	27	Regular
	Chorus Solid	0	107	27	Cool!
	Clean Guitar	0	112	27	Cool!
	Jazz Clean	8	32	6	S.Art!
	Slide Clean	0	117	28	Cool!
	Muted Guitar	0	119	28	Cool!
	Slide Solid	0	110	27	Cool!
Dynamic Mute	0	118	28	Cool!	
Slide Pick	104	7	27	Cool!	
Vintage Muted Guitar	104	0	28	Cool!	
Slide Finger	104	5	27	Cool!	
Vintage Muted Echo	0	115	28	Regular	
Slide Warm	104	6	27	Cool!	
Slide Jazz	104	0	26	Cool!	
Funk Guitar	0	116	28	Cool!	
Vintage Strum	0	126	27	Regular	
Tremolo Solid	0	111	27	Cool!	
Ballad Solid	0	109	27	Cool!	
Jazz Guitar	0	115	26	Cool!	
Jazz Solo Guitar	0	116	26	Cool!	
Octave Guitar	0	113	26	Regular	

CVP-705

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Clean Solid	Electric Guitar	0	114	28	Cool!	
	60s Clean	0	117	27	Regular	
Distortion Solid	Rock Hero	8	35	5	S.Art!	
	Overdrive Wah	8	39	5	S.Art!	
	Vintage Rock	8	36	5	S.Art!	
	Vintage Blues	8	37	5	S.Art!	
	Stage Lead	8	38	5	S.Art!	
	Blues Slap Slide	8	36	4	S.Art!	
	Heavy Rock	8	32	4	S.Art!	
	Blues Bright	8	35	4	S.Art!	
	Classic Stack	8	41	5	S.Art!	
	Blues Warm	8	34	4	S.Art!	
	Guitar Hero	8	32	5	S.Art!	
	Vintage Amp	8	41	3	S.Art!	
	Feedbacker	8	33	4	S.Art!	
	Finger Amp	8	43	3	S.Art!	
	Rock Legend	8	34	5	S.Art!	
	Slide Pick Amp	104	8	27	Cool!	
	Crunch Guitar	8	33	5	S.Art!	
	Bluesy Night	8	55	3	S.Art!	
	Stereo Rock	104	2	30	Cool!	
	Half Drive	8	37	3	S.Art!	
	Blues Guitar	0	117	29	Cool!	
	Grunge Guitar	8	40	5	S.Art!	
	Metal Master	0	120	30	Regular	
World	Pedal Steel Amp	8	52	3	S.Art!	
	Mandolin	0	114	25	Sweet!	
	Pedal Steel	8	36	3	S.Art!	
	Zither 1	104	1	15	Regular	
	Banjo	104	0	105	Regular	
	Zither 2	104	0	15	Regular	
	Shamisen	0	112	106	Regular	
	Dulcimer	0	112	15	Regular	
	Koto	0	112	107	Regular	
	Hackbrett	104	2	46	Regular	
	Aloha Guitar	0	118	26	Regular	
	Sitar	104	0	104	Regular	
	Pedal Steel	0	115	27	Regular	
	Bass	Vintage Round Bass	8	32	17	S.Art!
		Acoustic Bass	8	32	16	S.Art!
		Vintage Flatwound Bass	8	33	17	S.Art!
		Soft Acoustic Bass	8	33	16	S.Art!
Vintage Mute Bass		8	32	18	S.Art!	
Fretless Bass		8	32	19	S.Art!	
Soft Acoustic Bass		104	2	32	Regular	
Acoustic Bass		104	1	32	Regular	
Ballroom Bass		104	0	32	Regular	
Vintage Round Bass		104	1	33	Cool!	
Vintage Flatwound Bass		104	2	33	Cool!	
Acoustic Bass & Cymbal		0	114	32	Regular	
Vintage Mute Bass		104	3	33	Cool!	
Fusion Bass		0	113	36	Regular	
Vintage Pick Bass		104	1	34	Regular	
Vintage Dyno Bass		104	2	34	Cool!	
Fretless Bass		0	112	35	Cool!	
Slap Bass		0	112	36	Regular	
Rock Bass		0	114	34	Regular	
Mellow Finger Bass		0	112	33	Regular	
Pick Bass		0	112	34	Regular	
Pick Dyno Bass		0	113	34	Cool!	
Electric Bass		0	114	33	Cool!	
Half Mute Bass		0	115	33	Cool!	
Super Fretless Bass		0	113	35	Regular	

Main Category: GUITAR&BASS

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Bass	Vintage Pick Mute Bass	104	0	34	Cool!
	Funk Bass	0	112	37	Regular
Synth Bass	Lo Bass	104	0	39	Regular
	Fat Pulse	104	2	39	Regular
	Dark Bass	104	1	39	Regular
	Wazzo Saw	104	3	80	Regular
	Moon Bass	104	0	38	Regular
	Deep Point	104	3	38	Regular
	Kick Bass	104	1	38	Regular
	Tight Bass	104	3	39	Regular
	Club Bass	104	2	38	Regular
	Competitor	104	4	38	Regular
	1o1 Sub	104	5	38	Regular
	Trance Bass	104	9	38	Regular
	Little Bass Synth	104	6	38	Regular
	Sub Cut Bass	104	5	39	Regular
	Tekno Bass	104	7	38	Regular
	Dyno Acid Bass	104	10	38	Regular
	Perc Punch	104	8	38	Regular
	Mini Sub	104	6	39	Regular
	Square Bass	104	4	39	Regular
	Fat Sine Resonance	104	11	38	Regular
	Ballad Bass	104	7	39	Regular
	House Bass	0	116	38	Regular
	Velo Master	104	17	81	Regular
	Big Drone	0	118	38	Regular
	Sub Bass	0	114	39	Regular
	Hard Bass	0	114	38	Regular
	Resonance Bass	0	112	38	Regular
TB Bass	0	117	39	Regular	

Main Category: STRINGS&VOCAL

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
String Solo	Violin	0	113	40	Sweet!
	Solo Violin	0	112	40	Regular
	Viola	0	112	41	Regular
	Fiddle	0	112	110	Regular
	Cello	0	112	42	Regular
String Ensemble	Contrabass	0	112	43	Regular
	Real Strings	8	33	49	S.Art!
	Classical Strings	8	36	48	S.Art!
	Concert Strings	8	32	49	S.Art!
	Theatre Strings	8	37	48	S.Art!
	Pizzicato	0	113	45	Live!
	Lush Strings	8	41	48	S.Art!
	Real Tremolo Strings	104	0	44	Live!
	Ballroom Strings	8	35	49	S.Art!
	Real Spiccato	104	6	48	Live!
	Studio Strings	8	32	48	S.Art!
	Movie Strings	0	123	48	Live!
	Disco Strings 1	0	123	49	Live!
	Ballad Strings	8	34	49	S.Art!
	Disco Strings 2	0	124	49	Live!
	Warm Strings	8	39	48	S.Art!
	Tremolo Strings	0	113	44	Live!
	Big Strings	8	40	48	S.Art!
	Strings	0	117	49	Live!
	Real Strings f	8	40	49	S.Art!
	Allegro	0	122	49	Live!
	Real Strings mf	8	41	49	S.Art!
	Dynamic Strings	0	124	48	Live!
	Real Strings p	8	42	49	S.Art!

CVP-705**Main Category: STRINGS&VOCAL**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
String Ensemble	Chamber Strings	0	112	49	Regular
	Real Tremolo Storzando	104	1	44	Live!
	Tremolo Bowing	8	34	48	S.Art!
	Spiccato	8	33	48	S.Art!
	Spiccato	0	120	48	Live!
	Real Strings f	104	4	49	Live!
	Strings f	0	119	48	Live!
	Real Strings mf	104	5	49	Live!
	Strings mf	0	118	48	Live!
	Real Strings p	104	6	49	Live!
Strings p	0	117	48	Live!	
Orchestral Layers	Tutti	0	120	49	Regular
	Theatre Orchestra	104	1	49	Regular
	Symphonic Unison	104	0	49	Regular
	Pizzicato Glocken	0	115	45	Live!
Choir	Boys Choir Aah	8	33	51	S.Art!
	Boys Choir Ooh	8	32	51	S.Art!
	Boys Choir Aah	104	8	52	Live!
	Boys Choir Ooh	104	8	53	Live!
	Soft Choir Ooh	8	35	51	S.Art!
	Soft Choir Aah	8	36	51	S.Art!
	Boys Choir Oh-Ah (Pedal)	8	34	51	S.Art!
	Boys Choir Oh-Ah	8	49	55	S.Art!
	Gothic Vox	0	113	53	Regular
	Gospel Voices	0	116	52	Live!
	Humming	0	118	52	Live!
	Hah Choir	0	114	52	Regular
Mmh	0	117	52	Live!	

Main Category: BRASS&WOODWIND

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Brass Solo	Bright Trumpet	8	32	64	S.Art!
	Cornet	0	119	56	Sweet!
	Silver Trumpet	8	33	64	S.Art!
	Muted Trumpet	0	114	59	Sweet!
	Golden Trumpet	8	34	64	S.Art!
	Flugel Horn	0	118	56	Sweet!
	Big Band Trumpet	8	37	64	S.Art!
	Trombone	0	117	57	Sweet!
	Trumpet Fall	8	38	64	S.Art!
	Trumpet	0	115	56	Sweet!
	Trumpet Shake	8	35	64	S.Art!
	Mellow Trumpet	0	120	56	Sweet!
	Silver Trumpet	0	121	56	Sweet!
	Muted Cornet	104	0	59	Sweet!
	Golden Trumpet	0	122	56	Sweet!
	Baritone Horn	0	113	58	Regular
	Tuba	104	0	58	Regular
	Bright Trombone	104	0	57	Sweet!
	Baritone Hit	0	114	58	Regular
	Alp Bass	0	113	33	Regular
Brass Ensemble	Horns	104	0	60	Live!
	Big Band Brass	8	37	56	S.Art!
	Soft Horns	8	32	60	S.Art!
	Smooth Brass	8	36	56	S.Art!
	Symphony Horns 1	104	1	60	Live!
	Dynamic Brass	0	127	61	Live!
	Symphony Horns 2	104	2	60	Live!
	Power Brass	0	121	62	Live!
	Warm Horns	8	33	60	S.Art!
	Accent Brass	0	109	61	Live!
	Stopped Horns	104	3	60	Live!

Main Category: BRASS&WOODWIND

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Brass Ensemble	Brass Falls f	8	34	56	S.Art!	
	Muted Horns	8	34	60	S.Art!	
	Brass Falls mf	8	35	56	S.Art!	
	Brass f	0	108	61	Live!	
	Brass Band	0	123	56	Live!	
	Brass mf	0	110	61	Live!	
	Soft Horns	0	117	60	Live!	
	Brass p	0	111	61	Live!	
	Soft Trombones	0	118	60	Live!	
	Brass Shake	8	32	56	S.Art!	
	Pop Brass	0	117	62	Live!	
	Accent Falls	8	38	56	S.Art!	
	Hyper Brass	0	118	62	Live!	
	Sforzando	0	105	61	Live!	
	Small Brass	0	120	60	Live!	
	Sforzando Fall	0	107	61	Live!	
	Ballroom Brass	0	113	59	Regular	
	Brass Dynamics	0	106	61	Live!	
	Octave Brass	0	116	62	Live!	
	Sax Solo	Saxophone	8	32	82	S.Art!
Alto Sax		8	32	66	S.Art!	
Big Band Sax		8	35	82	S.Art!	
Soft Alto Sax		8	34	66	S.Art!	
Rock Sax		8	33	82	S.Art!	
Growl Sax		0	111	66	Sweet!	
Soprano Sax		0	113	64	Sweet!	
Pop Tenor Sax		0	127	66	Sweet!	
Pop Alto Sax		104	0	65	Sweet!	
Ballad Tenor Sax		0	126	66	Sweet!	
Breathy Tenor Sax		0	117	66	Sweet!	
Jazz Tenor Sax		0	125	66	Sweet!	
Baritone Sax		104	0	67	Regular	
Sax Ensemble		Sax Section	8	36	82	S.Art!
		Big Band Octave	0	108	66	Live!
		Sax Section Unison	8	38	82	S.Art!
	Big Band Unison	0	109	66	Live!	
	Sax Section Fast Attack	0	116	66	Live!	
	Big Band Saxes	0	110	66	Live!	
	Sax Section Octave	8	37	82	S.Art!	
	Ballad Section	0	119	66	Regular	
	Soft Saxes	8	39	82	S.Art!	
	Sax Appeal	0	123	66	Live!	
	Sax Section Hard	0	122	66	Live!	
	Moonlight	0	115	71	Regular	
	Sax Section Soft	0	121	66	Live!	
	Woodwind Solo	Orchestral Flute	8	32	73	S.Art!
Jazz Flute		0	114	73	Sweet!	
Orchestral Oboe		8	32	68	S.Art!	
Classical Oboe		0	113	68	Sweet!	
Orchestral Clarinet		104	0	71	Live!	
Jazz Clarinet		0	114	71	Sweet!	
Orchestral Bassoon		104	0	70	Sweet!	
Bassoon		0	112	70	Regular	
German Clarinet		104	2	71	Regular	
Classical Flute		0	115	73	Sweet!	
Piccolo		0	112	72	Regular	
Oboe		0	112	68	Regular	
Clarinet		0	112	71	Regular	
English Horn		0	112	69	Regular	
Woodwind Ends	Flutes & Oboes	104	2	73	Regular	
	Orchestral Woodwind	104	1	70	Regular	
	Clarinet & Flutes	104	1	71	Regular	
	Alto Flutes	104	1	73	Regular	
	Clarinet & Oboe	104	1	68	Regular	

CVP-705**Main Category: BRASS&WOODWIND**

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Woodwind Ens	Flute Ensemble	0	116	73	Regular
	Oboe & Bassoon	104	2	68	Regular
Woodwind World	Ballad Pan Flute	0	113	75	Sweet!
	Chiff Pan Flute	0	113	73	Regular
	Celtic Duo	0	120	73	Regular
	Ethnic Flute	0	112	75	Regular
	Bagpipe	0	112	109	Regular
	Ocarina	0	112	79	Regular
	Recorder	0	112	74	Regular
	Shakuhachi	0	112	77	Regular
	Whistle	0	112	78	Regular

Main Category: PERC&DRUMS

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Chromatic Perc	Vibraphone	104	1	11	Sweet!	
	Xylophone	104	0	13	Regular	
	Jazz Vibraphone	0	113	11	Regular	
	Marimba	104	0	12	Regular	
	Tremolo Vibraphone	0	124	11	Natural!	
	Vibraphone	0	122	11	Natural!	
	Vibraphone & JazzGt	8	33	11	S.Art!	
	Glockenspiel	104	0	9	Regular	
	Vibraphone & Flutes	0	114	11	Regular	
	Steel Drums	0	112	114	Regular	
	Music Box	0	112	10	Regular	
	Kalimba	0	112	108	Regular	
	Orchestral Perc	Orchestral Harp	104	1	46	Regular
		Tubular Bells	0	112	14	Regular
Mellow Harp		104	0	46	Regular	
Timpani		0	112	47	Regular	
Orchestra Hit		0	112	55	Regular	
Celesta		0	112	8	Regular	
Drum Kits	Real Drums	127	0	91	Live!Drums	
	Power Kit 1	127	0	87	Live!Drums	
	Real Brushes	127	0	41	Live!Drums	
	Power Kit 2	127	0	88	Live!Drums	
	Acoustic Kit	127	0	89	Live!Drums	
	House Kit	127	0	60	Drums	
	Rock Kit	127	0	90	Live!Drums	
	Drum Machine	127	0	61	Drums	
	Studio Kit	127	0	86	Live!Drums	
	Analog T8 Kit	127	0	58	Drums	
	Analog T9 Kit	127	0	59	Drums	
	Jazz Kit	127	0	32	Drums	
	Break Kit	127	0	57	Drums	
	Hit Kit	127	0	4	Drums	
	Hip Hop Kit	127	0	56	Drums	
	Room Kit	127	0	8	Drums	
	Dance Kit	127	0	27	Drums	
	Electro Kit	127	0	24	Drums	
	Analog Kit	127	0	25	Drums	
	Symphony Kit	127	0	48	Live!Drums	
	Brush Kit	127	0	40	Live!Drums	
	World Perc Kits	Turkish Kit	126	0	67	Live!SFX
Cuban Kit		126	0	40	Live!SFX	
Pop Latin Kit		126	0	43	Live!SFX	
SFX	New SFX Kit 1	126	0	2	Live!SFX	
	Helicopter	104	0	125	Live!	
	New SFX Kit 2	126	0	3	Live!SFX	
	Applause 1	104	0	126	Live!	
	Noises Kit	126	0	8	SFX	
	Applause 2	104	1	126	Live!	

Main Category: PERC&DRUMS

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
SFX	Sea Shore	104	0	122	Live!
	Gun Shot	104	0	127	Live!
	SFX Kit 1	126	0	0	SFX
	SFX Kit 2	126	0	1	SFX
	Magic Bell	8	32	120	S.Art!

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Synth Lead	Sub Lead	104	0	80	Regular	
	Wire Lead	0	120	81	Regular	
	Soft Saw	104	16	81	Regular	
	Soft R&B	0	119	80	Regular	
	Fusion Lead	104	15	81	Regular	
	Early Lead	0	118	81	Regular	
	Oxygen	0	122	81	Regular	
	Soft Square	104	5	80	Regular	
	Matrix	0	123	81	Regular	
	Detuned Vintage	104	1	84	Regular	
	PWM Lead	104	1	81	Regular	
	Hipa Lead	0	118	84	Regular	
	Brassy Lead	104	5	62	Regular	
	Punchy Hook	0	127	81	Regular	
	Punch Lead	104	7	81	Regular	
	Crying Lead	0	114	87	Regular	
	Flange Filter	104	2	81	Regular	
	Hip Lead	0	113	80	Regular	
	Mouth Lead	104	0	81	Regular	
	Hop Lead	0	117	80	Regular	
	Tech Lead	0	117	84	Regular	
	Analogon	0	115	81	Regular	
	Tekkline	0	116	84	Regular	
	Skyline	0	115	84	Regular	
	Soft Mini	0	124	80	Regular	
	Bleep Lead	104	0	84	Regular	
	Fire Wire	0	116	81	Regular	
	Orbit Sine	0	126	80	Regular	
	Synth Perc	New Heaven	104	10	88	Regular
		Heaven Pad	104	3	91	Regular
		Fantasy Bells	104	11	88	Regular
		Breath Bells	104	15	88	Regular
Itopia Bells		104	13	88	Regular	
Next Generation		104	9	51	Regular	
Sinesphere		104	18	88	Regular	
Organ Bells		104	12	88	Regular	
Spectrum Theme		104	14	88	Regular	
Sky Bells		104	16	88	Regular	
Flying Harmonics		104	1	99	Regular	
Nylon Heaven		104	2	99	Regular	
Airy Harp		104	17	88	Regular	
Nylon Pad		104	0	99	Regular	
Simple Comp		104	12	81	Regular	
Bellsphere		104	5	88	Regular	
Ballad Comp		104	6	88	Regular	
Perc Pad		104	0	101	Regular	
Heaven Bell		104	0	100	Regular	
Mediterrain		0	114	99	Regular	
Bright Pad Bell		104	7	88	Regular	
Lektro Codes		104	2	84	Regular	
Wild PWM		104	4	80	Regular	
Resonant Clavi		104	2	90	Regular	
Perc Sequence FM 1		104	7	87	Regular	
Resonance Comp		104	4	62	Regular	

CVP-705

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Perc	Perc Sequence FM 2	104	8	87	Regular
	Digital Sequenced	104	2	87	Regular
	Synth Sticks	104	0	106	Regular
	Analog Sequenced	104	3	87	Regular
	Saz Feeze	104	0	97	Regular
	Perc Sequence FS	104	6	87	Regular
	Eastern Air	104	1	97	Regular
	Xtune	104	1	87	Regular
	Nomad	104	1	104	Regular
	Perc Sequence Saw	104	11	81	Regular
	Stack Bell	104	8	88	Regular
	Attack	104	4	81	Regular
	Nice Bell	104	9	88	Regular
	PWM Percussion	104	6	81	Regular
	Synth Strings	Synth Strings 1	0	112	50
Butter Strings		104	2	50	Regular
Synth Strings 2		0	113	50	Regular
Bright Saw Pad		0	113	90	Regular
Light Pad		104	2	51	Regular
Ober Strings		0	113	51	Regular
Hipa Strings		0	114	95	Regular
80s Pad		104	1	51	Regular
Octave Strings		104	4	50	Regular
Bright Pop Pad		104	3	50	Regular
Medium Tune Pad		104	0	50	Regular
Doux Flange		104	3	95	Regular
Premium Pad		104	0	51	Regular
Bright Pad Classic		104	3	90	Regular
Soft Ensemble		104	1	50	Regular
Synth Brass	Analog Brass	0	112	63	Regular
	1984 Synth	104	20	81	Regular
	Fat Synth Brass	0	116	63	Regular
	80s Brass	0	113	62	Regular
	Thin Brass	104	0	62	Regular
	Funky Analog	0	115	62	Regular
	Brass Profit	104	1	62	Regular
	Techno Brass	0	114	62	Regular
	Ober Brass	0	113	63	Regular
	Ober Horns	0	115	63	Regular
	Slow PWM Brass	104	2	62	Regular
	Soft Velo Brass	0	120	62	Regular
	Fast PWM Brass	104	6	62	Regular
	Soft Analog	0	114	63	Regular
	Synth Pad	All or Nothing	104	6	101
Whisper Gallery		104	0	92	Regular
Disisweeper		104	7	101	Regular
Hybrid Lines		104	4	91	Regular
Spectrum Pad		104	5	94	Regular
Midnight Special		104	3	101	Regular
Hybrid Pad		104	22	88	Regular
Atmo 5th		104	6	89	Regular
Deep Motion		104	4	95	Regular
Pad Voices		104	6	95	Live!
Skydiver		0	112	101	Regular
Aerosphere		104	1	94	Regular
Cross Phase		104	1	101	Regular
New Atmosphere		104	4	89	Regular
Galaxy Pad		104	3	88	Regular
VP Soft		104	0	89	Regular
Night Motion		104	4	88	Regular
Hot Swell		104	2	95	Regular
Morning Dew		104	0	94	Regular
Dark Fat Saw		104	2	89	Regular
Vapor Pad		104	1	89	Regular

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type	
		MSB	LSB	Prg		
Synth Pad	Dark Light	104	3	89	Regular	
	Space Rider	104	1	95	Regular	
	Ambient Pad	104	0	88	Regular	
	Pearls Pad	104	2	88	Regular	
	Bright Fat Saw	104	5	90	Regular	
	Breath Pad	104	0	91	Regular	
	Early Digital	104	0	93	Regular	
	Noble Man	104	1	88	Regular	
	Super Dark Pad	0	119	89	Regular	
	Analog Pad	0	120	89	Regular	
	Analog Swell	0	119	95	Regular	
	Dark Angel Pad	0	121	89	Regular	
	Big Octave Pad	0	115	90	Regular	
	Lite Pad	0	122	89	Regular	
	Golden Age	0	115	88	Regular	
	Pop Pad	0	112	90	Regular	
	Solaris	0	114	94	Regular	
	Glorious Phase	0	114	90	Regular	
	Insomnia	0	113	94	Regular	
	Ober Sweep	0	115	95	Regular	
	Neo Warm Pad	0	115	89	Regular	
	Time Travel	0	116	88	Regular	
	Cyber Pad	0	113	99	Regular	
	Bubblespace	0	113	101	Regular	
	Bright Ober	0	113	95	Regular	
	Mellow Pad	0	117	95	Regular	
	Dark Pad	0	118	95	Regular	
	Synth Dance	Ana Dayz	104	3	51	Regular
		HPF Dance	104	0	90	Regular
		Bright Pad Trance	104	4	90	Regular
		Detuned Saw Octave	104	8	81	Regular
		Chillin Chords	104	6	51	Regular
		Dancy Hook	104	9	81	Regular
		Trance (Pedal)	104	0	95	Regular
		Vinalog Saw	104	3	81	Regular
Club Lead		104	3	62	Regular	
Talk Mod Lead		104	0	87	Regular	
Trance Perc		104	5	81	Regular	
Chorus Saw Lead		104	10	81	Regular	
Chordmaster		104	13	81	Regular	
Faaat Comp		104	4	51	Regular	
Trance Sequence 1		104	4	87	Regular	
Fat Saw Hook		104	7	51	Regular	
Trance Sequence 2		104	5	87	Regular	
Tech Glide		104	14	81	Regular	
Trance Sequence 3		104	1	90	Regular	
Dance Chords		104	5	51	Regular	
Dance Hook	0	112	86	Regular		
Trance Lead	0	121	80	Regular		
Octave Hook	0	113	86	Regular		
Synth Effects	Water Games	104	4	101	Regular	
	Spectralis	104	4	94	Regular	
	My Generation	104	5	101	Regular	
	Metallic Rain	104	8	101	Regular	
	Rainy Day	104	5	89	Regular	
	Ambient Theme	104	20	88	Regular	
	Warped Waves	104	2	94	Regular	
	Reflecting Zone	104	21	88	Regular	
	Sound Pictures	104	3	94	Regular	
	The Fog	104	9	101	Regular	
	Mystic Pad	104	6	94	Regular	
	Randomizer	104	10	101	Regular	
	Atlantis	104	11	101	Regular	
	Tric-Trac	104	2	97	Regular	

CVP-705

Main Category: SYNTH

Sub Category 1	Voice Name	Voice Number			Voice Type
		MSB	LSB	Prg	
Synth Effects	Sixth Sense	104	2	101	Regular
	Perc Sequence Hipa	104	9	87	Regular
	Pitch Fall	104	0	103	Regular

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Piano	Stage Piano	104	10	0	Natural!	
		Studio Grand	0	115	0	Live!	
		Grand Piano	0	113	0	Live!	
		Rock Piano	104	4	0	Live!	
		Pop Grand	104	5	0	Live!	
		Pop Grand 2	104	11	0	Natural!	
		Warm Grand	0	114	0	Live!	
		Bright Piano	0	112	1	Live!	
		Ambient Piano	104	3	0	Live!	
		Cocktail Piano	104	0	3	Live!	
		Honky Tonk	0	122	3	Natural!	
		Honky Tonk	0	112	3	Regular	
		Grand Piano 1octave	104	2	3	Natural!	
		Grand Piano 2octaves	104	3	3	Natural!	
		Octave Piano 1	0	113	3	Live!	
		Octave Piano 2	0	114	3	Live!	
		Piano Orchestra	104	2	0	Live!	
		MIDI Grand	0	112	2	Regular	
		Harpichord	0	112	6	Live!	
		E.Piano	Ballad Stack	0	114	2	Regular
			Chorus Bell	0	120	5	Regular
			Funk EP	0	112	4	Regular
			Hyper Tines	0	113	5	Regular
			Jazz Chorus	0	118	5	Regular
			Modern EP	0	115	5	Regular
			New Tines	0	116	5	Regular
			Phase EP	0	120	4	Regular
			DX Modern	0	112	5	Regular
	Polaris EP		0	115	4	Regular	
	Super DX		0	117	5	Regular	
	Venus EP		0	114	5	Regular	
	Stereo Clavi		0	114	7	Regular	
	Organ		Bright Drawbar	0	116	16	Regular
			Click Organ	0	112	17	Regular
			Dance Organ	0	113	17	Regular
			Drawbar Organ 1	0	120	17	Regular
			Drawbar Organ 2	0	115	16	Regular
			Electric Organ	0	118	17	Regular
			Full Rocker 2	104	3	18	Cool!
			Gospel Organ	0	119	16	Regular
			Jazz Organ 1	0	112	16	Regular
		Jazz Organ 2	0	113	16	Regular	
		Jazz Organ 3	0	120	16	Regular	
		Percussive Organ	0	119	17	Regular	
		Purple Organ	0	114	18	Regular	
		Rock Organ 1	0	112	18	Regular	
		Rock Organ 2	0	119	18	Regular	
		Rock Organ 3	0	113	18	Regular	
		Rotary Drive	0	116	18	Regular	
		Rotary Switch	0	110	17	Cool!	
		60s Organ	0	116	17	Regular	
		Reed Organ	0	112	20	Regular	
		Tibia 8'&4' Accomp	0	122	16	Regular	
		Tibia 16'&4' Accomp	0	114	16	Regular	
		Tibia Full Accomp	0	114	17	Regular	
		Tibia 8' Accomp	0	122	17	Regular	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Organ	Vox 8' Accomp	0	123	17	Regular	
		Vox & Tibia Accomp	0	125	16	Regular	
		Classic Jazz	0	126	16	OrganFlutes	
	A.Guitar	Folk Guitar	0	112	25	Regular	
		Campfire Guitar	0	115	25	Regular	
		18String Guitar	0	119	25	Regular	
	E.Guitar	70s Solid Guitar	104	1	27	Cool!	
		Bright Clean	0	116	27	Regular	
		Chorus Guitar	0	124	27	Regular	
		Clean Solid	104	3	27	Cool!	
		Deep Chorus	0	114	27	Regular	
		Electric 12String	0	119	27	Regular	
		Funk Guitar	0	113	28	Regular	
		Muted Guitar	0	112	28	Regular	
		Slapback	104	0	27	Cool!	
		Solid Chord	0	121	27	Regular	
		Solid Guitar	0	118	27	Regular	
		Tremolo Guitar	0	113	27	Regular	
		Vintage Amp	8	40	3	S.Art!	
		Warm Solid	104	2	27	Cool!	
		DX Jazz Guitar	0	117	26	Regular	
		Crunch Guitar	0	113	30	Regular	
		Distortion Guitar	0	112	30	Regular	
		Guitar Hero	104	0	30	Cool!	
		Heavy Rock	104	1	30	Cool!	
		Heavy Stack	0	114	30	Regular	
		Lead Guitar	0	114	29	Regular	
		Power Chord	0	117	30	Regular	
		Power Lead	0	115	30	Cool!	
		Rock Guitar	0	116	29	Regular	
		Feedback Guitar	0	113	29	Regular	
		Half Drive	104	0	29	Cool!	
		Overdrive Guitar	0	112	29	Regular	
		Smooth Lead	0	119	26	Regular	
		Vintage Amp	0	115	29	Regular	
		Vintage Lead	0	125	27	Cool!	
		Vintage Trem	0	120	27	Regular	
		Voodoo Lead	0	116	30	Regular	
		Wah Guitar	0	122	27	Regular	
		Bass	Acoustic Bass	0	112	32	Regular
			80s Synth Bass	0	115	39	Regular
			Analog Bass	0	112	39	Regular
			Click Bass	0	115	38	Regular
			Dry Synth Bass	0	116	39	Regular
			DX Funk Bass	0	113	37	Regular
			HiQ Bass	0	113	38	Regular
			Punchy Bass	0	117	38	Regular
			Accordion	Accordion	0	116	21
	Ballroom Accordion			0	112	23	Regular
	Musette Accordion	0		112	21	Regular	
	Small Accordion	0		115	21	Regular	
	Soft Accordion	0		114	21	Regular	
	Tutti Accordion	0		113	21	Regular	
	Strings	Bow Strings		0	116	48	Regular
		Concerto Strings	0	115	48	Regular	
		Marcato	0	115	49	Regular	
		Orch Strings	0	113	48	Regular	
		Orchestra Strings	0	116	49	Live!	
		Pizzicato	0	112	45	Regular	
		Slow Strings	0	113	49	Regular	
		String Falls	0	121	48	Live!	
		Strings	0	112	48	Regular	
		Symphonic	0	114	48	Regular	
		Tremolo Strings	0	112	44	Regular	

CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
Legacy	Strings	Orch & Flute	0	119	49	Regular	
		Orch & Oboe	0	121	49	Regular	
		String Quartet	0	114	49	Regular	
		Orch & Horns	0	118	49	Regular	
		Analog Strings	0	112	51	Regular	
		Harp	0	112	46	Regular	
		Hackbrett 2	0	113	46	Regular	
		Banjo 2	0	112	105	Regular	
	Sitar 2	0	112	104	Regular		
	Brass	Solo Trumpet	0	112	56	Regular	
		Jazz Trumpet	0	116	56	Regular	
		Muted Trumpet	0	112	59	Regular	
		Flugel Horn	0	113	56	Regular	
		Solo Trombone	0	112	57	Regular	
		Trombone	0	116	57	Regular	
		Soft Trombone	0	115	57	Regular	
		Mellow Trombone	0	114	57	Regular	
		Smooth Trombone	0	118	57	Regular	
		Tuba 2	0	112	58	Regular	
		Big Band Brass	0	113	61	Regular	
		Big Brass	0	121	61	Regular	
		Brass Combo	0	115	66	Regular	
		Brass Hit	0	126	61	Regular	
		Brass Section	0	112	61	Regular	
		Breath Brass	0	116	60	Regular	
		Bright Brass	0	120	61	Regular	
		Full Horns	0	114	61	Regular	
		High Brass	0	115	61	Regular	
		Mellow Brass	0	116	61	Regular	
		Natural Brass	0	124	61	Regular	
		Sforzando	0	125	61	Regular	
		Small Brass	0	117	61	Regular	
		Soft Brass	0	123	61	Regular	
		Symphony Brass	0	119	60	Live!	
		Trumpet Ensemble	0	122	61	Regular	
		French Horns	0	112	60	Live!	
		Mellow Horns	0	119	61	Regular	
		Symphony Horns	0	115	60	Live!	
		Trombone Section	0	113	57	Regular	
		Hybrid Comp	0	119	62	Regular	
		Hybrihorn	0	113	60	Regular	
		Hybripad	0	114	60	Regular	
		Pop Brass	0	118	61	Regular	
		Synth Brass	0	112	62	Regular	
		Woodwind	Soprano Sax	0	112	64	Regular
			Alto Sax	0	114	65	Sweet!
			Alto Sax	0	112	65	Regular
Saxophone			104	0	66	Sweet!	
Tenor Sax			0	112	66	Regular	
Growl Sax	0		118	66	Regular		
Baritone Sax	0		112	67	Regular		
Orch Flute	104		0	73	Sweet!		
Orch Oboe	104		0	68	Sweet!		
Flute	0		112	73	Regular		
Sax Stack	0		124	66	Regular		
Saxy Mood	0		120	66	Regular		
Woodwinds Ensemble	0		113	66	Regular		
Choir	Air Choir		0	112	54	Regular	
	Choir		0	112	52	Regular	
	Uuh Choir	0	115	52	Regular		
	Voices	0	113	54	Regular		
	Vox Humana	0	112	53	Regular		
	Bell Heaven	0	119	88	Regular		
	Dream Heaven	0	121	88	Regular		

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
Legacy	Choir	Sweet Heaven	0	118	88	Regular
		Hah Pad	0	116	94	Regular
		Pan Heaven	0	120	88	Regular
		Pro Heaven	0	122	88	Regular
		Sunbeam	0	123	88	Regular
	Percussion	Xylophone	0	112	13	Regular
		Marimba	0	112	12	Regular
		Vibraphone	0	112	11	Regular
		Glockenspiel	0	112	9	Regular
	Drum Kit	Standard Kit 1	127	0	0	Live!Drums
		Standard Kit 2	127	0	1	Live!Drums
		Rock Kit	127	0	16	Drums
	Pad	Arabic Kit	126	0	35	SFX
		Angel Vibes	0	114	98	Regular
		Area 51	0	112	89	Regular
		Atmosphere	0	112	99	Regular
		Dark Moon	0	113	89	Regular
		Digital Pad	0	115	93	Regular
		Disclosure	0	116	89	Regular
		Dunes	0	114	89	Regular
		DX Pad	0	112	92	Regular
		Equinox	0	112	94	Regular
		Evening Stars	0	117	101	Regular
		Fantasia	0	112	88	Regular
		Far East	0	112	97	Regular
		Glass Pad	0	114	93	Regular
		Ionosphere	0	115	94	Regular
		Messenger	0	116	95	Regular
		Millennium	0	117	88	Regular
		Mystery	0	113	97	Regular
		Psycho Pad	0	118	101	Regular
		S&H Groove	0	115	101	Regular
		Sirius	0	114	101	Regular
		Stargate	0	114	88	Regular
		Symbiont	0	113	88	Regular
		Velo Ashrami	0	116	101	Regular
		Wave 2001	0	112	95	Regular
		Xenon Pad	0	112	91	Regular
	Synth	Adrenaline	0	113	84	Regular
		Aero Lead	0	112	83	Regular
		Attack Saw	0	126	81	Regular
		Big Lead	0	113	81	Regular
		Big Tune	0	118	89	Regular
		Blaster	0	114	81	Regular
		Bright Mini	0	125	80	Regular
		Crystal Eyes	0	125	88	Regular
		Fargo	0	119	81	Regular
		Funky Lead	0	121	81	Regular
		Hi Bias	0	116	80	Regular
		Impact	0	113	87	Regular
		Melody Maker	0	117	89	Regular
		Mini Lead	0	114	80	Regular
Padbells		0	126	88	Regular	
Pan Lead		0	122	80	Regular	
Paraglide		0	114	84	Regular	
Perc Square		0	123	80	Regular	
Pop Lead		0	120	80	Regular	
Portatone		0	112	84	Regular	
Pro Lead	0	113	83	Regular		
Robolead	0	124	81	Regular		
Saw Lead	0	112	81	Regular		
Square Lead	0	112	80	Regular		
Stardust	0	112	98	Regular		
String Bells	0	124	88	Regular		

CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
Legacy	Synth	Sun Bell	0	113	98	Regular
		Tiny Lead	0	118	80	Regular
		Trumpet Saw	0	125	81	Regular
		Under Heim	0	112	87	Regular
		Vinyl Lead	0	115	80	Regular
		Warp	0	117	81	Regular
MegaVoices	A.Guitar	Nylon Guitar	8	0	0	MegaVoice
		Steel Guitar	8	0	1	MegaVoice
		12String Guitar	8	1	2	MegaVoice
		Hi String Guitar	8	0	2	MegaVoice
	E.Guitar	Finger Guitar	8	4	3	MegaVoice
		Finger Slap Guitar	8	5	3	MegaVoice
		Vintage Pick Guitar	8	6	3	MegaVoice
		Vintage Slap Guitar	8	7	3	MegaVoice
		Slap Amp Guitar	8	8	3	MegaVoice
		Single Coil Guitar	8	3	3	MegaVoice
		Solid Guitar 1	8	1	3	MegaVoice
		Solid Guitar 2	8	2	3	MegaVoice
		Clean Guitar	8	0	3	MegaVoice
		Jazz Guitar	8	0	6	MegaVoice
		Overdrive Guitar	8	0	4	MegaVoice
		Distortion Guitar	8	0	5	MegaVoice
	Bass	Vintage Round	8	1	17	MegaVoice
		Vintage Flat	8	2	17	MegaVoice
		Vintage Pick	8	1	18	MegaVoice
		Electric Bass	8	0	17	MegaVoice
		Pick Bass	8	0	18	MegaVoice
		Acoustic Bass	8	0	16	MegaVoice
	Strings	Fretless Bass	8	0	19	MegaVoice
		Classical Strings	8	1	48	MegaVoice
		Real Strings	8	1	49	MegaVoice
		Large Strings	8	0	49	MegaVoice
	Brass	Small Strings	8	0	48	MegaVoice
		Trumpet	8	0	64	MegaVoice
		Brass	8	0	56	MegaVoice
	Woodwind	Tenor Sax	8	0	82	MegaVoice

CVP-709/CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Piano	GrandPiano	0	0	0	Regular	
		GrndPianoKSP	0	1	0	Regular	
		MellowGrPno	0	18	0	Regular	
		PianoStrings	0	40	0	Regular	
		Dream	0	41	0	Regular	
		BrightPiano	0	0	1	Regular	
		BritePnoKSP	0	1	1	Regular	
		ElecGrandPno	0	0	2	Regular	
		ElecGrPnoKSP	0	1	2	Regular	
		DetunedCP80	0	32	2	Regular	
		LayeredCP1	0	40	2	Regular	
		LayeredCP2	0	41	2	Regular	
		Honkytonk	0	0	3	Regular	
		HonkytonkKSP	0	1	3	Regular	
		El.Piano1	0	0	4	Regular	
		El.Piano1KSP	0	1	4	Regular	
		MellowEP1	0	18	4	Regular	
		ChorusEP1	0	32	4	Regular	
		HardEl.Piano	0	40	4	Regular	
		VXfadeEl.P1	0	45	4	Regular	
		60sEl.Piano1	0	64	4	Regular	
		El.Piano2	0	0	5	Regular	
		El.Piano2KSP	0	1	5	Regular	
		ChorusEP2	0	32	5	Regular	
		DXEPHard	0	33	5	Regular	
		DXLegend	0	34	5	Regular	
		DXPhaseEP	0	40	5	Regular	
		DX+AnalogEP	0	41	5	Regular	
		DXKotoEP	0	42	5	Regular	
		VXfadeEl.P2	0	45	5	Regular	
		Harpsichord	0	0	6	Regular	
		Harpsi.KSP	0	1	6	Regular	
		Harpsichord2	0	25	6	Regular	
		Harpsichord3	0	35	6	Regular	
		Clavi.	0	0	7	Regular	
		Clavi.KSP	0	1	7	Regular	
		Clavi.Wah	0	27	7	Regular	
		PulseClavi.	0	64	7	Regular	
		PierceClavi.	0	65	7	Regular	
		Chromatic Perc	Celesta	0	0	8	Regular
			Glockenspiel	0	0	9	Regular
			MusicBox	0	0	10	Regular
			Orgel	0	64	10	Regular
			Vibraphone	0	0	11	Regular
			VibesKSP	0	1	11	Regular
			HardVibes	0	45	11	Regular
			Marimba	0	0	12	Regular
			MarimbaKSP	0	1	12	Regular
			SineMarimba	0	64	12	Regular
			Balimba	0	97	12	Regular
			LogDrums	0	98	12	Regular
			Xylophone	0	0	13	Regular
			TubularBells	0	0	14	Regular
			ChurchBells	0	96	14	Regular
			Carillon	0	97	14	Regular
			Dulcimer	0	0	15	Regular
			Dulcimer2	0	35	15	Regular
			Cimbalom	0	96	15	Regular
			Santur	0	97	15	Regular
		Organ	DrawbarOrgan	0	0	16	Regular
			DetDrawOrgan	0	32	16	Regular
			60sDrawOrg1	0	33	16	Regular
60sDrawOrg2	0		34	16	Regular		
70sDrawOrg1	0		35	16	Regular		

CVP-709/CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Organ	DrawbarOrg2	0	36	16	Regular	
		60sDrawOrg3	0	37	16	Regular	
		EvenBarOrg	0	38	16	Regular	
		16+2'2_3Org	0	40	16	Regular	
		OrganBass	0	64	16	Regular	
		70sDrawOrg2	0	65	16	Regular	
		CheezyOrgan	0	66	16	Regular	
		DrawbarOrg3	0	67	16	Regular	
		Perc.Organ	0	0	17	Regular	
		70sPercOrg1	0	24	17	Regular	
		DetPercOrgan	0	32	17	Regular	
		LightOrgan	0	33	17	Regular	
		Perc.Organ2	0	37	17	Regular	
		RockOrgan	0	0	18	Regular	
		RotaryOrgan	0	64	18	Regular	
		SlowRotary	0	65	18	Regular	
		FastRotary	0	66	18	Regular	
		ChurchOrgan	0	0	19	Regular	
		ChurchOrgan3	0	32	19	Regular	
		ChurchOrgan2	0	35	19	Regular	
		NotreDame	0	40	19	Regular	
		OrganFlute	0	64	19	Regular	
		Trem.OrganFl	0	65	19	Regular	
		ReedOrgan	0	0	20	Regular	
		PuffOrgan	0	40	20	Regular	
		Accordion	0	0	21	Regular	
		Accordlt	0	32	21	Regular	
		Harmonica	0	0	22	Regular	
		Harmonica2	0	32	22	Regular	
		TangoAccord	0	0	23	Regular	
		TangoAccord2	0	64	23	Regular	
		Guitar	NylonGuitar	0	0	24	Regular
			NylonGuitar2	0	16	24	Regular
	NylonGuitar3		0	25	24	Regular	
	VelGtrHarmo		0	43	24	Regular	
	Ukulele		0	96	24	Regular	
	SteelGuitar		0	0	25	Regular	
	SteelGuitar2		0	16	25	Regular	
	12StrGuitar		0	35	25	Regular	
	Nylon&Steel		0	40	25	Regular	
	Steel&Body		0	41	25	Regular	
	Mandolin		0	96	25	Regular	
	JazzGuitar		0	0	26	Regular	
	MellowGuitar		0	18	26	Regular	
	JazzAmp		0	32	26	Regular	
	CleanGuitar		0	0	27	Regular	
	ChorusGuitar		0	32	27	Regular	
	MutedGuitar		0	0	28	Regular	
	FunkGuitar1		0	40	28	Regular	
	MuteSteelGtr		0	41	28	Regular	
	FunkGuitar2		0	43	28	Regular	
	JazzMan		0	45	28	Regular	
	Overdriven		0	0	29	Regular	
GuitarPinch	0		43	29	Regular		
Distortion	0		0	30	Regular		
FeedbackGtr	0		40	30	Regular		
FeedbackGtr2	0		41	30	Regular		
GtrHarmonics	0		0	31	Regular		
GtrFeedback	0		65	31	Regular		
GtrHarmonic2	0		66	31	Regular		
Bass	AcousticBass		0	0	32	Regular	
	JazzRhythm		0	40	32	Regular	
	VXUpgrhtBass		0	45	32	Regular	
	FingerBass		0	0	33	Regular	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Bass	FingerDark	0	18	33	Regular	
		FlangeBass	0	27	33	Regular	
		Bass&DistEG	0	40	33	Regular	
		FingerSlap	0	43	33	Regular	
		FingerBass2	0	45	33	Regular	
		Mod.Bass	0	65	33	Regular	
		PickBass	0	0	34	Regular	
		MutePickBass	0	28	34	Regular	
		FretlessBass	0	0	35	Regular	
		Fretless2	0	32	35	Regular	
		Fretless3	0	33	35	Regular	
		Fretless4	0	34	35	Regular	
		Syn.Fretless	0	96	35	Regular	
		SmthFretless	0	97	35	Regular	
		SlapBass1	0	0	36	Regular	
		ResonantSlap	0	27	36	Regular	
		PunchThumb	0	32	36	Regular	
		SlapBass2	0	0	37	Regular	
		Velo.Sw.Slap	0	43	37	Regular	
		SynthBass1	0	0	38	Regular	
		SynBass1Dark	0	18	38	Regular	
		FastResoBass	0	20	38	Regular	
		AcidBass	0	24	38	Regular	
		ClaviBass	0	35	38	Regular	
		TechnoBass	0	40	38	Regular	
		Orbiter	0	64	38	Regular	
		SquareBass	0	65	38	Regular	
		RubberBass	0	66	38	Regular	
		Hammer	0	96	38	Regular	
		SynthBass2	0	0	39	Regular	
		MellowSyBass	0	6	39	Regular	
		SequenceBass	0	12	39	Regular	
		ClickSynBass	0	18	39	Regular	
		SynBass2Dark	0	19	39	Regular	
		SmoothSyBass	0	32	39	Regular	
		ModulrSyBass	0	40	39	Regular	
		DXBass	0	41	39	Regular	
		XWireBass	0	64	39	Regular	
		Strings	Violin	0	0	40	Regular
			SlwAtkViolin	0	8	40	Regular
			Viola	0	0	41	Regular
	Cello		0	0	42	Regular	
	Contrabass		0	0	43	Regular	
	Trem.Strings		0	0	44	Regular	
	SlwATremStr		0	8	44	Regular	
	SuspenseStr		0	40	44	Regular	
	PizzicatoStr		0	0	45	Regular	
	Orch.Harp		0	0	46	Regular	
	YangQin	0	40	46	Regular		
	Timpani	0	0	47	Regular		
	Ensemble	Strings1	0	0	48	Regular	
		StereoStrngs	0	3	48	Regular	
		SlwAtkStrngs	0	8	48	Regular	
		ArcoStrings	0	24	48	Regular	
		60'sStrings	0	35	48	Regular	
		Orchestra	0	40	48	Regular	
		Orchestra2	0	41	48	Regular	
		TremOrchestra	0	42	48	Regular	
		Velo.Strings	0	45	48	Regular	
		Strings2	0	0	49	Regular	
	S.SlowStrngs	0	3	49	Regular		
LegatoStrngs	0	8	49	Regular			
WarmStrings	0	40	49	Regular			
Kingdom	0	41	49	Regular			

CVP-709/CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Ensemble	70'sStrings	0	64	49	Regular	
		Strings3	0	65	49	Regular	
		SynStrings1	0	0	50	Regular	
		ResoStrings	0	27	50	Regular	
		SynStrings4	0	64	50	Regular	
		SynStrings5	0	65	50	Regular	
		SynStrings2	0	0	51	Regular	
		ChoirAahs	0	0	52	Regular	
		StereoChoir	0	3	52	Regular	
		ChoirAahs2	0	16	52	Regular	
		MellowChoir	0	32	52	Regular	
		ChoirStrings	0	40	52	Regular	
		VoiceOohs	0	0	53	Regular	
		SynthVoice	0	0	54	Regular	
		SynthVoice2	0	40	54	Regular	
		Choral	0	41	54	Regular	
		AnalogVoice	0	64	54	Regular	
		OrchestralHit	0	0	55	Regular	
		OrchestrHit2	0	35	55	Regular	
		Impact	0	64	55	Regular	
		Brass	Trumpet	0	0	56	Regular
			Trumpet2	0	16	56	Regular
			BriteTrumpet	0	17	56	Regular
			WarmTrumpet	0	32	56	Regular
			Trombone	0	0	57	Regular
			Trombone2	0	18	57	Regular
			Tuba	0	0	58	Regular
			Tuba2	0	16	58	Regular
	MutedTrumpet		0	0	59	Regular	
	FrenchHorn		0	0	60	Regular	
	Fr.HornSolo		0	6	60	Regular	
	FrenchHorn2		0	32	60	Regular	
	HornOrchestr		0	37	60	Regular	
	BrassSection		0	0	61	Regular	
	Tp&TbSection		0	35	61	Regular	
	BrassSect2		0	40	61	Regular	
	HighBrass		0	41	61	Regular	
	MellowBrass		0	42	61	Regular	
	SynthBrass1		0	0	62	Regular	
	QuackBrass		0	12	62	Regular	
	ResoSynBrass		0	20	62	Regular	
	PolyBrass		0	24	62	Regular	
	SynthBrass3		0	27	62	Regular	
	JumpBrass		0	32	62	Regular	
	AnaVelBrass1		0	45	62	Regular	
	AnalogBrass1		0	64	62	Regular	
	SynthBrass2		0	0	63	Regular	
	SoftBrass		0	18	63	Regular	
	SynthBrass4		0	40	63	Regular	
	ChoirBrass		0	41	63	Regular	
	AnaVelBrass2		0	45	63	Regular	
	AnalogBrass2		0	64	63	Regular	
	Reed		SopranoSax	0	0	64	Regular
			AltoSax	0	0	65	Regular
			SaxSection	0	40	65	Regular
			HyperAltoSax	0	43	65	Regular
			TenorSax	0	0	66	Regular
			BreathyTenor	0	40	66	Regular
			SoftTenorSax	0	41	66	Regular
			TenorSax2	0	64	66	Regular
			BaritoneSax	0	0	67	Regular
			Oboe	0	0	68	Regular
	EnglishHorn	0	0	69	Regular		

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Reed	Bassoon	0	0	70	Regular	
		Clarinet	0	0	71	Regular	
	Pipe	Piccolo	0	0	72	Regular	
		Flute	0	0	73	Regular	
		Recorder	0	0	74	Regular	
		PanFlute	0	0	75	Regular	
		BlownBottle	0	0	76	Regular	
		Shakuhachi	0	0	77	Regular	
		Whistle	0	0	78	Regular	
		Ocarina	0	0	79	Regular	
		Synth.Lead	SquareLead	0	0	80	Regular
			SquareLead2	0	6	80	Regular
	LMSquare		0	8	80	Regular	
	Hollow		0	18	80	Regular	
	Shroud		0	19	80	Regular	
	Mellow		0	64	80	Regular	
	SoloSine		0	65	80	Regular	
	SineLead		0	66	80	Regular	
	SawtoothLead		0	0	81	Regular	
	SawtoothLd2		0	6	81	Regular	
	ThickSaw		0	8	81	Regular	
	DynamicSaw		0	18	81	Regular	
	DigitalSaw		0	19	81	Regular	
	BigLead		0	20	81	Regular	
	HeavySynth		0	24	81	Regular	
	WaspySynth		0	25	81	Regular	
	PulseSaw		0	40	81	Regular	
	Dr.Lead		0	41	81	Regular	
	VelocityLead		0	45	81	Regular	
	Seq.Analog		0	96	81	Regular	
	CalliopeLead		0	0	82	Regular	
	PureLead		0	65	82	Regular	
	ChiffLead		0	0	83	Regular	
	Rubby		0	64	83	Regular	
	CharangLead		0	0	84	Regular	
	DistortedLd		0	64	84	Regular	
	WireLead		0	65	84	Regular	
	VoiceLead		0	0	85	Regular	
	SynthAahs		0	24	85	Regular	
	VoxLead		0	64	85	Regular	
	FifthsLead		0	0	86	Regular	
	BigFive		0	35	86	Regular	
	Bass&Lead	0	0	87	Regular		
	Big&Low	0	16	87	Regular		
	Fat&Perky	0	64	87	Regular		
	SoftWhirl	0	65	87	Regular		
	Synth.Pad	NewAgePad	0	0	88	Regular	
		Fantasy	0	64	88	Regular	
		WarmPad	0	0	89	Regular	
		ThickPad	0	16	89	Regular	
		SoftPad	0	17	89	Regular	
		SinePad	0	18	89	Regular	
		HornPad	0	64	89	Regular	
		RotaryStrngs	0	65	89	Regular	
		PolySynthPad	0	0	90	Regular	
		PolyPad80	0	64	90	Regular	
		ClickPad	0	65	90	Regular	
		AnalogPad	0	66	90	Regular	
		SquarePad	0	67	90	Regular	
		ChoirPad	0	0	91	Regular	
	Heaven	0	64	91	Regular		
	Itoptia	0	66	91	Regular		
	CCPad	0	67	91	Regular		
	BowedPad	0	0	92	Regular		

CVP-709/CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Synth.Pad	Glacier	0	64	92	Regular	
		GlassPad	0	65	92	Regular	
		MetallicPad	0	0	93	Regular	
		TinePad	0	64	93	Regular	
		PanPad	0	65	93	Regular	
		HaloPad	0	0	94	Regular	
		SweepPad	0	0	95	Regular	
		Shwimmer	0	20	95	Regular	
		Converge	0	27	95	Regular	
		PolarPad	0	64	95	Regular	
		Celestial	0	66	95	Regular	
		Synth.Effect	Rain	0	0	96	Regular
			ClaviPad	0	45	96	Regular
			HarmoRain	0	64	96	Regular
	AfricanWind		0	65	96	Regular	
	Carib		0	66	96	Regular	
	SoundTrack		0	0	97	Regular	
	Prologue		0	27	97	Regular	
	Ancestral		0	64	97	Regular	
	Crystal		0	0	98	Regular	
	SynthDr.Comp		0	12	98	Regular	
	Popcorn		0	14	98	Regular	
	TinyBells		0	18	98	Regular	
	RoundGlocken		0	35	98	Regular	
	GlockenChime		0	40	98	Regular	
	ClearBells		0	41	98	Regular	
	ChorusBells		0	42	98	Regular	
	SynthMallet		0	64	98	Regular	
	SoftCrystal		0	65	98	Regular	
	LoudGlocken		0	66	98	Regular	
	ChristmasBel		0	67	98	Regular	
	VibeBells		0	68	98	Regular	
	DigitalBells		0	69	98	Regular	
	AirBells		0	70	98	Regular	
	BellHarp		0	71	98	Regular	
	Gamelimba		0	72	98	Regular	
	Atmosphere		0	0	99	Regular	
	WarmAtmos.		0	18	99	Regular	
	HollwRelease		0	19	99	Regular	
	NylonElPiano		0	40	99	Regular	
	NylonHarp		0	64	99	Regular	
	HarpVox		0	65	99	Regular	
	Atmos.Pad		0	66	99	Regular	
	Planet		0	67	99	Regular	
	Brightness		0	0	100	Regular	
	FantasyBells		0	64	100	Regular	
	Smokey		0	96	100	Regular	
	Goblins		0	0	101	Regular	
	GoblinsSynth		0	64	101	Regular	
	Creeper		0	65	101	Regular	
	RingPad		0	66	101	Regular	
	Ritual	0	67	101	Regular		
	ToHeaven	0	68	101	Regular		
Night	0	70	101	Regular			
Glisten	0	71	101	Regular			
BellChoir	0	96	101	Regular			
Echoes	0	0	102	Regular			
Echoes2	0	8	102	Regular			
EchoPan	0	14	102	Regular			
EchoBells	0	64	102	Regular			
BigPan	0	65	102	Regular			
SynthPiano	0	66	102	Regular			
Creation	0	67	102	Regular			
StarDust	0	68	102	Regular			

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM&XG	Synth.Effect	Reso&Panning	0	69	102	Regular	
		Sci-Fi	0	0	103	Regular	
		Starz	0	64	103	Regular	
	Ethnic	Sitar	0	0	104	Regular	
		DetunedSitar	0	32	104	Regular	
		Sitar2	0	35	104	Regular	
		Tambra	0	96	104	Regular	
		Tamboura	0	97	104	Regular	
		Banjo	0	0	105	Regular	
		MutedBanjo	0	28	105	Regular	
		Rabab	0	96	105	Regular	
		Gopichant	0	97	105	Regular	
		Oud	0	98	105	Regular	
		Shamisen	0	0	106	Regular	
		Koto	0	0	107	Regular	
		Taisho-kin	0	96	107	Regular	
		Kanoon	0	97	107	Regular	
		Kalimba	0	0	108	Regular	
		Bagpipe	0	0	109	Regular	
		Fiddle	0	0	110	Regular	
		Shanai	0	0	111	Regular	
		Shanai2	0	64	111	Regular	
		Pungi	0	96	111	Regular	
		Hichiriki	0	97	111	Regular	
		Percussive	TinkleBell	0	0	112	Regular
			Bonang	0	96	112	Regular
			Altair	0	97	112	Regular
			GamelanGongs	0	98	112	Regular
			StereoGamlan	0	99	112	Regular
			RamaCymbal	0	100	112	Regular
	AsianBells		0	101	112	Regular	
	Agogo		0	0	113	Regular	
	SteelDrums		0	0	114	Regular	
	GlassPerc.		0	97	114	Regular	
	ThaiBells		0	98	114	Regular	
	Woodblock		0	0	115	Regular	
	Castanets		0	96	115	Regular	
	TaikoDrum		0	0	116	Regular	
	GranCassa		0	96	116	Regular	
	MelodicTom		0	0	117	Regular	
	MelodicTom2		0	64	117	Regular	
	RealTom		0	65	117	Regular	
	RockTom		0	66	117	Regular	
	SynthDrum		0	0	118	Regular	
	AnalogTom	0	64	118	Regular		
	ElectroPerc.	0	65	118	Regular		
	Rev.Cymbal	0	0	119	Regular		
	SoundEffect	GtrFretNoise	0	0	120	Regular	
		BreathNoise	0	0	121	Regular	
		Seashore	0	0	122	Regular	
		BirdTweet	0	0	123	Regular	
		TelephonRing	0	0	124	Regular	
Helicopter		0	0	125	Regular		
Applause		0	0	126	Regular		
Gunshot		0	0	127	Regular		
CuttingNoise		64	0	0	Regular		
CuttingNoiz2		64	0	1	Regular		
StringSlap		64	0	3	Regular		
Fl.KeyClick		64	0	16	Regular		
Shower		64	0	32	Regular		
Thunder		64	0	33	Regular		
Wind		64	0	34	Regular		
Stream		64	0	35	Regular		
Bubble	64	0	36	Regular			

CVP-709/CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type		
			MSB	LSB	Prg			
GM&XG	SoundEffect	Feed	64	0	37	Regular		
		Dog	64	0	48	Regular		
		Horse	64	0	49	Regular		
		BirdTweet2	64	0	50	Regular		
		Ghost	64	0	54	Regular		
		Maou	64	0	55	Regular		
		PhoneCall	64	0	64	Regular		
		DoorSqueak	64	0	65	Regular		
		DoorSlam	64	0	66	Regular		
		ScratchCut	64	0	67	Regular		
		ScratchSplit	64	0	68	Regular		
		WindChime	64	0	69	Regular		
		TelphonRing2	64	0	70	Regular		
		CarEngineIgn	64	0	80	Regular		
		CarTiresSql	64	0	81	Regular		
		CarPassing	64	0	82	Regular		
		CarCrash	64	0	83	Regular		
		Siren	64	0	84	Regular		
		Train	64	0	85	Regular		
		JetPlane	64	0	86	Regular		
		Starship	64	0	87	Regular		
		Burst	64	0	88	Regular		
		RollrCoaster	64	0	89	Regular		
		Submarine	64	0	90	Regular		
		Laugh	64	0	96	Regular		
		Scream	64	0	97	Regular		
		Punch	64	0	98	Regular		
		Heartbeat	64	0	99	Regular		
		FootSteps	64	0	100	Regular		
		MachineGun	64	0	112	Regular		
		LaserGun	64	0	113	Regular		
		Explosion	64	0	114	Regular		
		Firework	64	0	115	Regular		
		GM2	Piano	GrandPiano	121	0	0	Regular
				GrandPianoW	121	1	0	Regular
GrandPianoD	121			2	0	Regular		
BrightPiano	121			0	1	Regular		
BrightPianoW	121			1	1	Regular		
ElecGrandPno	121			0	2	Regular		
ElecGrandPW	121			1	2	Regular		
Honkytonk	121			0	3	Regular		
HonkytonkW	121			1	3	Regular		
El.Piano1	121			0	4	Regular		
DetunedEP1	121			1	4	Regular		
EP1VeloMix	121			2	4	Regular		
60'sEl.Piano	121			3	4	Regular		
El.Piano2	121			0	5	Regular		
DetunedEP2	121			1	5	Regular		
EP2VeloMix	121			2	5	Regular		
EPLegend	121			3	5	Regular		
EPPPhase	121			4	5	Regular		
Harpsichord	121			0	6	Regular		
Harpsi.OctMx	121			1	6	Regular		
HarpsichordW	121			2	6	Regular		
Harpsi.KOff	121			3	6	Regular		
Clavi.	121			0	7	Regular		
PulseClavi.	121			1	7	Regular		
Chromatic Perc	Celesta			121	0	8	Regular	
	Glockenspiel			121	0	9	Regular	
	MusicBox			121	0	10	Regular	
	Vibraphone			121	0	11	Regular	
	VibraphoneW			121	1	11	Regular	
	Marimba			121	0	12	Regular	
	MarimbaW			121	1	12	Regular	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM2	Chromatic Perc	Xylophone	121	0	13	Regular	
		TubularBells	121	0	14	Regular	
		ChurchBells	121	1	14	Regular	
		Carillon	121	2	14	Regular	
		Dulcimer	121	0	15	Regular	
	Organ	DrawbarOrgan	121	0	16	Regular	
		DetDrawOrgan	121	1	16	Regular	
		It60'sOrgan	121	2	16	Regular	
		DrawbarOrg2	121	3	16	Regular	
		Perc.Organ	121	0	17	Regular	
		DetPercOrgan	121	1	17	Regular	
		Perc.Organ2	121	2	17	Regular	
		RockOrgan	121	0	18	Regular	
		ChurchOrgan	121	0	19	Regular	
		ChrchOrgOctM	121	1	19	Regular	
		DetChurchOrg	121	2	19	Regular	
		ReedOrgan	121	0	20	Regular	
		PuffOrgan	121	1	20	Regular	
		Accordion	121	0	21	Regular	
		Accordion2	121	1	21	Regular	
		Harmonica	121	0	22	Regular	
		TangoAccord	121	0	23	Regular	
		Guitar	NylonGuitar	121	0	24	Regular
			Ukulele	121	1	24	Regular
			NylonGtrKOff	121	2	24	Regular
	NylonGuitar2		121	3	24	Regular	
	SteelGuitar		121	0	25	Regular	
	12StrGuitar		121	1	25	Regular	
	Mandolin		121	2	25	Regular	
	Steel&Body		121	3	25	Regular	
	JazzGuitar		121	0	26	Regular	
	PedlSteelGtr		121	1	26	Regular	
	CleanGuitar		121	0	27	Regular	
	DetCleanGtr		121	1	27	Regular	
	MidToneGtr		121	2	27	Regular	
	MutedGuitar		121	0	28	Regular	
	FunkGuitar		121	1	28	Regular	
	MutedV-SwGtr		121	2	28	Regular	
	JazzMan		121	3	28	Regular	
	Overdriven		121	0	29	Regular	
	GuitarPinch		121	1	29	Regular	
	Distortion		121	0	30	Regular	
	FeedbackGtr		121	1	30	Regular	
	DstRhythmGtr		121	2	30	Regular	
	GtrHarmonics		121	0	31	Regular	
	GtrFeedback		121	1	31	Regular	
	Bass		AcousticBass	121	0	32	Regular
		FingerBass	121	0	33	Regular	
		FingerSlap	121	1	33	Regular	
		PickBass	121	0	34	Regular	
		FretlessBass	121	0	35	Regular	
		SlapBass1	121	0	36	Regular	
		SlapBass2	121	0	37	Regular	
		SynthBass1	121	0	38	Regular	
		WarmSyBass	121	1	38	Regular	
ResoSynhBass		121	2	38	Regular		
ClaviBass		121	3	38	Regular		
Hammer		121	4	38	Regular		
SynthBass2		121	0	39	Regular		
AttackBass		121	1	39	Regular		
RubberBass		121	2	39	Regular		
AttackPulse	121	3	39	Regular			
Strings	Violin	121	0	40	Regular		
	SlwAtkViolin	121	1	40	Regular		

CVP-709/CVP-705

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM2	Strings	Viola	121	0	41	Regular	
		Cello	121	0	42	Regular	
		Contrabass	121	0	43	Regular	
		Trem.Strings	121	0	44	Regular	
		PizzicatoStr	121	0	45	Regular	
		Orch.Harp	121	0	46	Regular	
		YangQin	121	1	46	Regular	
	Timpani	121	0	47	Regular		
	Ensemble	Strings1	121	0	48	Regular	
		StringsBrass	121	1	48	Regular	
		60'sStrings	121	2	48	Regular	
		Strings2	121	0	49	Regular	
		SynStrings1	121	0	50	Regular	
		SynStrings3	121	1	50	Regular	
		SynStrings2	121	0	51	Regular	
		ChoirAahs	121	0	52	Regular	
		ChoirAahs2	121	1	52	Regular	
		VoiceOohs	121	0	53	Regular	
		Humming	121	1	53	Regular	
		SynthVoice	121	0	54	Regular	
		AnalogVoice	121	1	54	Regular	
		OrchestraHit	121	0	55	Regular	
		BassHitPlus	121	1	55	Regular	
		6thHit	121	2	55	Regular	
		EuroHit	121	3	55	Regular	
		Brass	Trumpet	121	0	56	Regular
			DarkTpSoft	121	1	56	Regular
			Trombone	121	0	57	Regular
	Trombone2		121	1	57	Regular	
	BriteTrombon		121	2	57	Regular	
	Tuba		121	0	58	Regular	
	MutedTrumpet		121	0	59	Regular	
	MuteTrumpet2		121	1	59	Regular	
	FrenchHorn		121	0	60	Regular	
	FrenchHorn2		121	1	60	Regular	
	BrassSection		121	0	61	Regular	
	BrassSect2		121	1	61	Regular	
	SynthBrass1		121	0	62	Regular	
	SynthBrass3		121	1	62	Regular	
	AnaSynBrass1		121	2	62	Regular	
	JumpBrass		121	3	62	Regular	
	SynthBrass2		121	0	63	Regular	
	SynthBrass4		121	1	63	Regular	
	AnaSynBrass2		121	2	63	Regular	
	Reed		SopranoSax	121	0	64	Regular
		AltoSax	121	0	65	Regular	
		TenorSax	121	0	66	Regular	
		BaritoneSax	121	0	67	Regular	
		Oboe	121	0	68	Regular	
		EnglishHorn	121	0	69	Regular	
		Bassoon	121	0	70	Regular	
		Clarinet	121	0	71	Regular	
		Pipe	Piccolo	121	0	72	Regular
			Flute	121	0	73	Regular
	Recorder		121	0	74	Regular	
	PanFlute		121	0	75	Regular	
	BlownBottle		121	0	76	Regular	
	Shakuhachi		121	0	77	Regular	
	Whistle		121	0	78	Regular	
	Ocarina		121	0	79	Regular	
	Synth.Lead		SquareLead	121	0	80	Regular
			SquareLead2	121	1	80	Regular
		SineLead	121	2	80	Regular	
		SawtoothLead	121	0	81	Regular	

Main Category: OTHERS

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type	
			MSB	LSB	Prg		
GM2	Synth.Lead	SawtoothLd2	121	1	81	Regular	
		SawPulseLead	121	2	81	Regular	
		DoublSawLead	121	3	81	Regular	
		Seq.Analog	121	4	81	Regular	
		CalliopeLead	121	0	82	Regular	
		ChiffLead	121	0	83	Regular	
		CharangLead	121	0	84	Regular	
		WireLead	121	1	84	Regular	
		VoiceLead	121	0	85	Regular	
		FifthsLead	121	0	86	Regular	
		Bass&Lead	121	0	87	Regular	
		SoftWhirl	121	1	87	Regular	
		Synth.Pad	NewAgePad	121	0	88	Regular
			WarmPad	121	0	89	Regular
			SinePad	121	1	89	Regular
			PolySynthPad	121	0	90	Regular
			ChoirPad	121	0	91	Regular
	ItopiaPad		121	1	91	Regular	
	BowedPad		121	0	92	Regular	
	MetallicPad		121	0	93	Regular	
	HaloPad		121	0	94	Regular	
	SweepPad		121	0	95	Regular	
	Synth.Effect		Rain	121	0	96	Regular
			SoundTrack	121	0	97	Regular
			Crystal	121	0	98	Regular
		SynthMallet	121	1	98	Regular	
		Atmosphere	121	0	99	Regular	
		Brightness	121	0	100	Regular	
		Goblins	121	0	101	Regular	
		Echoes	121	0	102	Regular	
		EchoBell	121	1	102	Regular	
		EchoPan	121	2	102	Regular	
		Sci-Fi	121	0	103	Regular	
		Ethnic	Sitar	121	0	104	Regular
			Sitar2	121	1	104	Regular
	Banjo		121	0	105	Regular	
	Shamisen		121	0	106	Regular	
	Koto		121	0	107	Regular	
	TaishoKoto		121	1	107	Regular	
	Kalimba		121	0	108	Regular	
	Bagpipe		121	0	109	Regular	
	Fiddle		121	0	110	Regular	
	Shanai		121	0	111	Regular	
	Percussive		TinkleBell	121	0	112	Regular
			Agogo	121	0	113	Regular
			SteelDrums	121	0	114	Regular
		Woodblock	121	0	115	Regular	
		Castanets	121	1	115	Regular	
		TaikoDrum	121	0	116	Regular	
		ConcertBD	121	1	116	Regular	
		MelodicTom	121	0	117	Regular	
		MelodicTom2	121	1	117	Regular	
		SynthDrum	121	0	118	Regular	
		RhythmBoxTom	121	1	118	Regular	
		ElectricDrum	121	2	118	Regular	
		Rev.Cymbal	121	0	119	Regular	
	SoundEffect	GtrFretNoise	121	0	120	Regular	
		GtrCutNoise	121	1	120	Regular	
		StringSlap	121	2	120	Regular	
		BreathNoise	121	0	121	Regular	
		Fl.KeyClick	121	1	121	Regular	
		Seashore	121	0	122	Regular	
		Rain	121	1	122	Regular	
	Thunder	121	2	122	Regular		

CVP-709/CVP-705**Main Category: OTHERS**

Sub Category 1	Sub Category 2	Voice Name	Voice Number			Voice Type
			MSB	LSB	Prg	
GM2	SoundEffect	Wind	121	3	122	Regular
		Stream	121	4	122	Regular
		Bubble	121	5	122	Regular
		BirdTweet	121	0	123	Regular
		Dog	121	1	123	Regular
		HorseGallop	121	2	123	Regular
		BirdTweet2	121	3	123	Regular
		TelephonRing	121	0	124	Regular
		TelRing2	121	1	124	Regular
		DoorCreaking	121	2	124	Regular
		Door	121	3	124	Regular
		Scratch	121	4	124	Regular
		WindChime	121	5	124	Regular
		Helicopter	121	0	125	Regular
		CarEngine	121	1	125	Regular
		CarStop	121	2	125	Regular
		CarPass	121	3	125	Regular
		CarCrash	121	4	125	Regular
		Siren	121	5	125	Regular
		Train	121	6	125	Regular
		Jetplane	121	7	125	Regular
		Starship	121	8	125	Regular
		BurstNoise	121	9	125	Regular
		Applause	121	0	126	Regular
		Laughing	121	1	126	Regular
		Screaming	121	2	126	Regular
		Punch	121	3	126	Regular
		HeartBeat	121	4	126	Regular
		Footsteps	121	5	126	Regular
		Gunshot	121	0	127	Regular
		MachineGun	121	1	127	Regular
		Lasergun	121	2	127	Regular
		Explosion	121	3	127	Regular
		Drum	StandardSet	120	0	0
	RoomSet		120	0	8	Drums
	PowerSet		120	0	16	Drums
	ElectroSet		120	0	24	Drums
	AnalogSet		120	0	25	Drums
	JazzSet		120	0	32	Drums
	BrushSet		120	0	40	Drums
	OrchestraSet		120	0	48	Drums
	SFXSet	120	0	56	SFX	

Mega Voice Map / Sound-Zuordnungen der Mega Voices / Carte des sonorités Mega Voice / Mapa de Mega Voice / Mapa de voz mega

CVP-709	CVP-705	MSB	LSB	PC#	Voice Name	Velocity Switch Points (under B5)												above C6	above C8
						1-20	21-40	41-60	61-75	76-90	91-105	106-120	121-127	1-89	1-71	72-115	116-127		
		0	0	0	Mega NylonGuitar	open soft	open med	open hard	dead	mute	hammer	slide	harmonics	1-127	1-127				
		0	0	1	Mega SteelGuitar	open soft	open med	open hard	dead	mute	hammer	slide	harmonics	1-127	1-127				
		0	0	2	Mega HiStringGtr			1-89	soft			90-127		1-127	1-127				
		0	1	2	Mega 12StringGtr Element1(Steel) Element2(HiString)		1-71	soft		72-115	med	hard	116-127	1-127	1-127				
		0	0	3	Mega CleanGuitar	open soft	open hard	41-60	slap	mute	hammer	slide	pick harmonics	1-127	1-127				
		0	1	3	Mega SolidGuitar1	open soft	open hard	41-60	slap	mute	hammer	slide	pick harmonics	1-127	1-127				
		0	2	3	Mega SolidGuitar2	open soft	open med	41-60	open hard	mute	hammer	slide	pick harmonics	1-127	1-127				
		0	3	3	Mega SingleCoil	open soft	open med	41-60	open hard	mute	hammer	slide	pick harmonics	1-127	1-127				
		0	4	3	Mega FingerGtr	open soft	open med	41-60	open hard	mute	hammer	slide	pick harmonics	1-127	1-127				
		0	5	3	Mega FingerSlapGtr	open soft	open med	41-60	open hard	mute	hammer	slide	pick harmonics	1-127	1-127				
		0	6	3	Mega VintagePickGtr	open soft	open med	41-60	open hard	mute	hammer	slide	pick harmonics	1-127	1-127				
		0	7	3	Mega VintageSlapGtr	open soft	open med	41-60	open hard	mute	hammer	slide	pick harmonics	1-127	1-127				
		0	8	3	Mega SlapAmpGtr	open soft	open med	41-50	open slap amp	mute rmp	mute mf	slide	pick harmonics	1-127	1-127				
		0	0	4	Mega OverdriveGtr		1-55	open		56-120	mute		121-127	1-127	1-127				
		0	0	5	Mega DistortionGtr		1-55	open		56-120	mute		121-127	1-127	1-127				

CVP-709	CVP-705	MSB	LSB	PC#	Voice Name	Velocity Switch Points (under B5)										above C6	above C8
						1-20	21-40	41-60	61-75	76-90	91-105	106-120	121-127	1-127	1-127		
○	○	8	0	6	Mega JazzGuitar	open soft	open med	open hard	dead soft	dead hard	hammer	slide	pick harmonics	strum noise	1-127	fret noise	
○	○	8	0	16	Mega AcousticBass	1-60	open soft	open hard	61-80	dead	81-120	slap	harmonics	EFX	1-127		
○	○	8	0	17	Mega ElectricBass	1-60	open soft	open hard	61-80	dead	81-120	slap	harmonics	EFX	1-127		
○	○	8	1	17	Mega VintageRound	1-60	open soft	open hard	61-80	dead	81-120	slap	harmonics	EFX	1-127		
○	○	8	2	17	Mega VintageFlat	1-60	open soft	open hard	61-80	dead	81-120	slap	harmonics	EFX	1-127		
○	○	8	0	18	Mega PickBass	1-40	open soft	open hard	41-80	dead	81-120	slap	harmonics	EFX	1-127		
○	○	8	1	18	Mega VintagePick	1-40	open	open	41-80	dead	81-120	slap	harmonics	EFX	1-127		
○	○	8	0	19	Mega FretlessBass	1-80	open	open	1-80	dead	81-120	slap	harmonics	EFX	1-127		
○	○	8	0	48	Mega SmallStrings	1-20	mf	f	61-80	spicato f	96-110	tremolo	glissando down				
○	○	8	1	48	Mega ClassicalStrings	1-20	mf	f	61-80	spicato f	96-110	tremolo	glissando down				
○	○	8	0	49	Mega LargeStrings	1-20	mf	f	61-80	spicato f	96-110	tremolo	glissando down				
○	○	8	1	49	Mega RealStrings	1-20	mf	f	61-80	spicato f	96-110	tremolo	glissando down				
○	○	8	0	51	Mega MaleVoiceChoir	1-15	Ooh p	Ooh mf legato	Aah p	Aah p legato	Aah mf	Aah mf legato					
○	○	8	0	54	Mega GospelChoir	1-15	Hmm	Wow	Hey	Hey legato	Aaa	Aaa legato					
○	○	8	0	56	Mega Brass	1-20	mf	f	61-80	attack	81-100	glissando up					
○	○	8	0	64	Mega Trumpet	1-20	mf	f	61-80	legato	81-100	glissando up					

CVP-709	CVP-705	MSB	LSB	PC#	Voice Name	Velocity Switch Points (under B5)												above C6	above C8
						1-20	21-40	41-60	61-80	81-100	101-127	1-127							
O	—	8	0	82	Mega TenorSax	mp			f		legato			growl		falls	valve noise (C6 - B6 key on noise C7 - B7 key off noise)	breath noise	
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	110-127	1-127	
O	—	8	0	100	PopHaa	Haa p	Aa p	Haa vib p	Haa vib p	Haa vib p	Haa vib f	Aa f	Aa vib f	Waa vib p	Waa vib p	Waa vib f	breath noise		
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	110-127		
O	—	8	0	101	PopDaa	Daa p	Aa p	Daa vib p	Daa vib p	Daa vib f	Aa f	Aa vib f	Waa vib p	Waa vib p	Waa vib f	breath noise			
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	110-127		
O	—	8	0	102	PopBaa	Baa p	Aa p	Baa vib p	Baa vib p	Baa vib f	Aa f	Aa vib f	Yaa vib p	Yaa vib p	Yaa vib f	breath noise			
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	110-127		
O	—	8	0	105	PopHoo	Hoo p	Oo p	Hoo vib p	Hoo vib p	Hoo vib f	Oo f	Oo vib f	Yoo vib p	Yoo vib p	Yoo vib f	breath noise			
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	110-127		
O	—	8	0	106	PopDoo	Doo p	Oo p	Doo vib p	Doo vib p	Doo vib f	Oo f	Oo vib f	Yoo vib p	Yoo vib p	Yoo vib f	breath noise			
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	110-127		
O	—	8	0	103	PopShoo	Shoo p	Oo p	Shoo vib p	Shoo vib p	Shoo vib f	Oo f	Oo vib f	Yoo vib p	Yoo vib p	Yoo vib f	breath noise			
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	110-127		
O	—	8	0	110	PopHee	Hee vib p	Oo p	Hee vib p	Hee vib p	Hee vib f	Oo f	Oo vib f	Wee vib p	Wee vib p	Wee vib f	vocal breath			
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	110-127		

CVP-709	CVP-705	MSB	LSB	PC#	Voice Name	Velocity Switch Points (under B5)												above C6	above C8	
						1-10	11-20	21-30	31-40	41-50	51-60	61-70	71-80	81-90	91-100	101-110	110-127			
O	—	8	0	107	PopBee	Bee vib p	Ee vib p legato	Bee vib p	Ee vib p legato	Bee vib p	Ee vib p legato	Bee vib p	Ee vib p legato	Bee vib p	Wee vib p	Wee vib p	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127	breath noise	
O	—	8	0	115	PopHaa L2	Haa p	Aa p legato2	Haa vib p	Aa vib p legato2	Haa f legato2	Aa f legato2	Haa vib f	Aa vib f legato2	Waa p	Waa vib p	Waa vib f	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127	breath noise	
O	—	8	0	120	PopHoo L2	Hoo p	Oo p legato2	Hoo vib p	Oo vib p legato2	Hoo f legato2	Oo f legato2	Hoo vib f	Oo vib f legato2	Yoo p	Yoo vib p	Yoo vib f	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127	breath noise	
O	—	8	0	125	PopHee L2	Hee vib p	Ee vib p legato2	Hee vib p	Ee vib p legato2	Hee vib p	Ee vib p legato2	Hee vib p	Ee vib p legato2	Wee vib p	Wee vib p	Wee vib p	110-127	C6 - D#6: 1-60, 61-127 E6 - B6: 1-30, 31-60, 61-90, 91-127	breath noise	
O	—	8	1	1	SteelAcoustic	pick p	pick p	pick mf	pick mf	pick f	pick f	dead p	dead f	mute soft	mute hard	hammer	slide	harmonics	pick noise	
O	—	8	2	1	SteelAcGrSlap	pick p	pick p	pick mf	pick mf	slap soft	slap hard	dead p	dead f	mute soft	mute hard	hammer	slide	harmonics	pick noise	
O	—	8	3	0	FlamencoGuitar	finger soft	finger soft	finger soft/med	finger soft/med	finger med	finger med	finger hard	finger hard	mute	mute	hammer	slide up	key off	noise 1 noise 2	shout
O	—	8	4	0	SpanishMedium	finger soft	finger soft	finger soft/med	finger soft/med	finger med	finger med	dead	dead	mute	mute	hammer	slide up	harmonics	stnum noise	
O	—	8	5	0	SpanishHard	finger soft/med	finger soft/med	finger med	finger med	finger hard	finger hard	dead	dead f	mute soft	mute hard	hammer	slide up	harmonics	stnum noise	
O	—	8	5	1	SteelGrTwin1	pick p	pick p	pick mf	pick mf	pick f	pick f	dead p	dead f	mute soft	mute hard	hammer	slide	harmonics	pick noise	
O	—	8	5	1	Element1	soft	soft	med	med	hard	hard	dead	dead	mute	mute	hammer	slide	harmonics	pick noise	
O	—	8	6	1	SteelGrTwin2	pick p	pick p	pick mf	pick mf	pick f	pick f	dead p	dead f	mute soft	mute hard	hammer	slide	harmonics	pick noise	
O	—	8	6	1	Element1	soft	soft	med	med	hard	hard	dead	dead	mute	mute	hammer	slide	harmonics	pick noise	
O	—	8	6	1	Element2	soft	soft	med	med	hard	hard	dead	dead	mute	mute	hammer	slide	harmonics	pick noise	

CVP-709	CVP-705	MSB	LSB	PC#	Voice Name	Velocity Switch Points (under B5)																above C6	above C8
						1-20	21-40	41-60	61-67	68-75	76-83	84-90	91-105	106-120	121-127	1-20	21-40	41-60	61-67	68-75	76-83		
O	—	8	7	1	12StringTwin1 Element1 Element2	pick p	pick mf	pick f	dead p	dead f	mute soft	mute hard	hammer	slide	harmonics	1-127							
						soft	med	hard	61-75	dead	mute	hammer	slide	harmonics	1-127	SFX							
						pick p	pick mf	pick f	61-67	dead f	mute soft	mute hard	hammer	slide	harmonics	pick noise							
O	—	8	8	1	12StringTwin2 Element1 Element2	soft	med	hard	61-75	dead	mute	hammer	slide	harmonics	1-127	SFX							
						1-20	21-40	41-60	61-80	attack	scoops	91-100	101-110	111-120	121-127								
						p	mp	mf	61-70	61-80	61-90	91-100	101-110	111-120	121-127								
O	—	8	1	56	PopHorns1	1-20	21-40	41-60	61-70	71-80	81-90	91-100	101-110	111-120	121-127								
						p	mp	mf	sus ff	legato p	legato mp	legato mf	shake	falls	doit								
						1-20	21-40	41-60	61-70	71-80	81-90	91-100	101-110	111-120	121-127								
O	—	8	2	56	PopHorns2	p	mp	mf	sus ff	legato p	legato mp	legato mf	shake	falls	doit								
						1-20	21-40	41-60	61-70	71-80	81-90	91-100	101-110	111-120	121-127								
						p	mp	mf	sus ff	legato p	legato mp	legato mf	shake	falls	doit								

Drum/key Assignment List / Liste der Tastenzuordnungen der Schlaginstrumente / Liste des affectations d'instrument de batterie/touche de clavier / Lista de asignación de teclas/batería / Lista de atribuições de bateria/tecla

CVP-709			○ (Live!)			○ (Live!)			○			○			○		
CVP-705			○ (Live!)			○ (Live!)			○			○			○		
Kit Name			Standard Kit 1			Standard Kit 2			Hit Kit			Room Kit			Rock Kit		
MSB-LSB-PC#			127-0-0			127-0-1			127-0-4			127-0-8			127-0-16		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1	Surdo Mute		3												
14	D-1	D1	Surdo Open		3												
15	D#-1	D#1	Hi Q														
16	E-1	E1	Whip Slap														
17	F-1	F1	Scratch H		4												
18	F#-1	F#1	Scratch L		4												
19	G-1	G1	Finger Snap														
20	G#-1	G#1	Click Noise														
21	A-1	A1	Metronome Click														
22	A#-1	A#1	Metronome Bell														
23	B-1	B1	Seq Click L														
24	C0	C2	Seq Click H														
25	C#0	C#2	Brush Tap														
26	D0	D2	Brush Swirl	●													
27	D#0	D#2	Brush Slap														
28	E0	E2	Brush Tap Swirl	●													
29	F0	F2	Snare Roll	●													
30	F#0	F#2	Castanet														
31	G0	G2	Snare Soft			Snare Soft 2			Snare Electro						Snare Noisy		
32	G#0	G#2	Sticks														
33	A0	A2	Kick Soft						Kick Tight L								
34	A#0	A#2	Open Rim Shot			Open Rim Shot H Short			Snare Pitched								
35	B0	B2	Kick Tight						Kick Wet						Kick 2		
36	C1	C3	Kick			Kick Short			Kick Tight H						Kick Gate		
37	C#1	C#3	Side Stick			Side Stick Light			Stick Ambient								
38	D1	D3	Snare			Snare Short			Snare Ambient			Snare Snappy			Snare Rock		
39	D#1	D#3	Hand Clap														
40	E1	E3	Snare Tight			Snare Tight H			Snare Tight 2			Snare Tight Snappy			Snare Rock Tight		
41	F1	F3	Floor Tom L						Hybrid Tom 1			Tom Room 1			Tom Rock 1		
42	F#1	F#3	Hi-Hat Closed		1				Hi-Hat Closed 2		1						
43	G1	G3	Floor Tom H						Hybrid Tom 2			Tom Room 2			Tom Rock 2		
44	G#1	G#3	Hi-Hat Pedal		1				Hi-Hat Pedal 2		1						
45	A1	A3	Low Tom						Hybrid Tom 3			Tom Room 3			Tom Rock 3		
46	A#1	A#3	Hi-Hat Open		1				Hi-Hat Open 2		1						
47	B1	B3	Mid Tom L						Hybrid Tom 4			Tom Room 4			Tom Rock 4		
48	C2	C4	Mid Tom H						Hybrid Tom 5			Tom Room 5			Tom Rock 5		
49	C#2	C#4	Crash Cymbal 1														
50	D2	D4	High Tom						Hybrid Tom 6			Tom Room 6			Tom Rock 6		
51	D#2	D#4	Ride Cymbal 1														
52	E2	E4	Chinese Cymbal														
53	F2	F4	Ride Cymbal Cup														
54	F#2	F#4	Tambourine						Tambourine Light								
55	G2	G4	Splash Cymbal														
56	G#2	G#4	Cowbell														
57	A2	A4	Crash Cymbal 2														
58	A#2	A#4	Vibraslap														
59	B2	B4	Ride Cymbal 2														
60	C3	C5	Bongo H														
61	C#3	C#5	Bongo L														
62	D3	D5	Conga H Mute														
63	D#3	D#5	Conga H Open														
64	E3	E5	Conga L														
65	F3	F5	Timbale H														
66	F#3	F#5	Timbale L														
67	G3	G5	Agogo H														
68	G#3	G#5	Agogo L														
69	A3	A5	Cabasa														
70	A#3	A#5	Maracas														
71	B3	B5	Samba Whistle H	●													
72	C4	C6	Samba Whistle L	●													
73	C#4	C#6	Guiro Short														
74	D4	D6	Guiro Long	●													
75	D#4	D#6	Claves														
76	E4	E6	Wood Block H														
77	F4	F6	Wood Block L														
78	F#4	F#6	Cuica Mute														
79	G4	G6	Cuica Open														
80	G#4	G#6	Triangle Mute		2												
81	A4	A6	Triangle Open		2												
82	A#4	A#6	Shaker														
83	B4	B6	Jingle Bells														
84	C5	C7	Bell Tree														
85	C#5	(C#7)															
86	D5	(D7)															
87	D#5	(D#7)															
88	E5	(E7)															
89	F5	(F7)															
90	F#5	(F#7)															
91	G5	(G7)															

Same as Standard Kit 1

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

CVP-709			○	○	○	○	○ (Live!)										
CVP-705			○	○	○	○	○ (Live!)										
Kit Name			Electro Kit			Analog Kit			Dance Kit			Jazz Kit			Brush Kit		
MSB-LSB-PC#			127-0-24			127-0-25			127-0-27			127-0-32			127-0-40		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1							Kick Dance 1								
14	D-1	D1							Kick Dance 2								
15	D#-1	D#1															
16	E-1	E1															
17	F-1	F1							Scratch Dance 1	●							
18	F#-1	F#1							Scratch Dance 2	●							
19	G-1	G1															
20	G#-1	G#1															
21	A-1	A1							Dance Perc 1								
22	A#-1	A#1							Reverse Dance 1								
23	B-1	B1							Dance Perc 2								
24	C0	C2							Hi Q Dance 1								
25	C#0	C#2							Snare Analog 3								
26	D0	D2							Vinyl Noise	●							
27	D#0	D#2							Snare Analog 4								
28	E0	E2	Reverse Cymbal	●		Reverse Cymbal	●		Reverse Cymbal	●							
29	F0	F2							Reverse Dance 2	●							
30	F#0	F#2	Hi Q 2			Hi Q 2			Hi Q 2								
31	G0	G2	Snare Snappy Electro			Snare Noisy 4			Snare Techno			Snare Jazz H			Brush Slap 2		
32	G#0	G#2							Snare Dance 1								
33	A0	A2	Kick 3			Kick 3			(Kick Techno Q)								
34	A#0	A#2							Rim Gate								
35	B0	B2	Kick Gate			Kick Analog Short			Kick Techno L								
36	C1	C3	Kick Gate Heavy			Kick Analog			Kick Techno			Kick Jazz			Kick Jazz		
37	C#1	C#3				Side Stick Analog			Side Stick Analog			Side Stick Light			Side Stick Light		
38	D1	D3	Snare Noisy 2			Snare Analog			Snare Clap			Snare Jazz L			Brush Slap 3		
39	D#1	D#3							Dance Clap								
40	E1	E3	Snare Noisy 3			Snare Analog 2			Snare Dry			Snare Jazz M			Brush Tap 2		
41	F1	F3	Tom Electro 1			Tom Analog 1			Tom Dance 1						Tom Brush 1		
42	F#1	F#3				Hi-Hat Closed Analog	1		Hi-Hat Closed 3	1							
43	G1	G3	Tom Electro 2			Tom Analog 2			Tom Dance 2						Tom Brush 2		
44	G#1	G#3				Hi-Hat Closed Analog 2	1		Hi-Hat Closed Analog 3	1							
45	A1	A3	Tom Electro 3			Tom Analog 3			Tom Dance 3						Tom Brush 3		
46	A#1	A#3				Hi-Hat Open Analog	1		Hi-Hat Open 3	1							
47	B1	B3	Tom Electro 4			Tom Analog 4			Tom Dance 4						Tom Brush 4		
48	C2	C4	Tom Electro 5			Tom Analog 5			Tom Dance 5						Tom Brush 5		
49	C#2	C#4				Crash Analog			Crash Analog								
50	D2	D4	Tom Electro 6			Tom Analog 6			Tom Dance 6						Tom Brush 6		
51	D#2	D#4															
52	E2	E4															
53	F2	F4															
54	F#2	F#4							Tambourine Analog								
55	G2	G4															
56	G#2	G#4				Cowbell Analog			Cowbell Dance								
57	A2	A4															
58	A#2	A#4							Vibraslap Analog								
59	B2	B4							Ride Analog								
60	C3	C5							Bongo Analog H								
61	C#3	C#5							Bongo Analog L								
62	D3	D5				Conga Analog H			Conga Analog H								
63	D#3	D#5				Conga Analog M			Conga Analog M								
64	E3	E5				Conga Analog L			Conga Analog L								
65	F3	F5															
66	F#3	F#5															
67	G3	G5															
68	G#3	G#5															
69	A3	A5															
70	A#3	A#5				Maracas 2			Maracas 2								
71	B3	B5															
72	C4	C6															
73	C#4	C#6															
74	D4	D6															
75	D#4	D#6				Claves 2			Claves 2								
76	E4	E6							Dance Perc 3								
77	F4	F6							Dance Perc 4	●							
78	F#4	F#6	Scratch H 2			Scratch H 2			Dance Breath 1								
79	G4	G6	Scratch L 2			Scratch L 2			Dance Breath 2	●							
80	G#4	G#6															
81	A4	A6															
82	A#4	A#6															
83	B4	B6															
84	C5	C7															
85	C#5	(C#7)															
86	D5	(D7)															
87	D#5	(D#7)															
88	E5	(E7)															
89	F5	(F7)															
90	F#5	(F#7)															
91	G5	(G7)															

Same as Standard Kit 1

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

CVP-709			○ (Live)			○ (Live)			○ (Live)			○ (Live)		
CVP-705			○ (Live)			○ (Live)			○ (Live)			○ (Live)		
Kit Name			Power Kit 2			Acoustic Kit			Rock Kit			Real Drums		
MSB-LSB-PC#			127-0-88			127-0-89			127-0-90			127-0-91		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1												
14	D-1	D1												
15	D#-1	D#1												
16	E-1	E1												
17	F-1	F1												
18	F#-1	F#1												
19	G-1	G1												
20	G#-1	G#1												
21	A-1	A1												
22	A#-1	A#1												
23	B-1	B1												
24	C0	C2												
25	C#0	C#2												
26	D0	D2										Brush Tap Swirl		●
27	D#0	D#2												
28	E0	E2												
29	F0	F2				Snare Roll Acoustic	●		Snare Roll Rock	●		Snare Roll Rock	●	
30	F#0	F#2												
31	G0	G2	Snare Soft Power 2			Snare Soft Acoustic			Snare Soft Rock			Snare Tight		
32	G#0	G#2												
33	A0	A2	Kick Ambient+			Kick Soft Acoustic			Kick Soft Rock			Kick Genuine		
34	A#0	A#2	Open Rim Power 2			Rim Acoustic			Rim Rock			Rim Real		
35	B0	B2	Kick Power Open			Kick Mute Acoustic			Kick Rock Heavy			Kick Real 1		
36	C1	C3	Kick Power Mute			Kick Open Acoustic			Kick Rock			Kick Real 2		
37	C#1	C#3	Side Stick Power			Stick Acoustic			Stick Rock			Stick Real		
38	D1	D3	Snare Power 2			Snare Acoustic			Snare Rock			Snare Real 1		
39	D#1	D#3	Hand Clap Power			Hand Clap Power			Hand Clap Power			Clap Power		
40	E1	E3	Snare Loose			Snare Rough Acoustic			Snare Dry Rock			Snare Real 2		
41	F1	F3	Tom Power 1			Tom Acoustic 1			Tom Rock 1			Tom Real 1		
42	F#1	F#3	Hi-Hat Closed Power+Edge		1	Hi-Hat Closed Acoustic		1	Hi-Hat Closed Rock		1	Hi-Hat Closed Real		1
43	G1	G3	Tom Power 2			Tom Acoustic 2			Tom Rock 2			Tom Real 2		
44	G#1	G#3	Hi-Hat Pedal Power		1	Hi-Hat Pedal Acoustic		1	Hi-Hat Pedal Rock		1	Hi-Hat Pedal Real		1
45	A1	A3	Tom Power 3			Tom Acoustic 3			Tom Rock 3			Tom Real 3		
46	A#1	A#3	Hi-Hat Open Power		1	Hi-Hat Open Acoustic		1	Hi-Hat Open Rock		1	Hi-Hat Open Real		1
47	B1	B3	Tom Power 4			Tom Acoustic 4			Tom Rock 4			Tom Real 4		
48	C2	C4	Tom Power 5			Tom Acoustic 5			Tom Rock 5			Tom Real 5		
49	C#2	C#4	Crash Cymbal Acoustic 1			Crash Cymbal Acoustic 1			Crash Cymbal Acoustic 1			Crash Cymbal Real 1		
50	D2	D4	Tom Power 6			Tom Acoustic 6			Tom Rock 6			Tom Real 6		
51	D#2	D#4	Ride Cymbal Acoustic 1			Ride Cymbal Acoustic 1			Ride Cymbal Acoustic 1			Ride Cymbal Real 1		
52	E2	E4	China Cymbal Acoustic			China Cymbal Acoustic			China Cymbal Acoustic			China Cymbal Real		
53	F2	F4	Ride Cymbal Cup Acoustic			Ride Cymbal Cup Acoustic			Ride Cymbal Cup Acoustic			Ride Cymbal Cup Real		
54	F#2	F#4												
55	G2	G4	Splash Cymbal Acoustic			Splash Cymbal Acoustic			Splash Cymbal Acoustic			Splash Cymbal Real		
56	G#2	G#4												
57	A2	A4	Crash Cymbal Acoustic 2			Crash Cymbal Acoustic 2			Crash Cymbal Acoustic 2			Crash Cymbal Real 2		
58	A#2	A#4												
59	B2	B4	Ride Cymbal Acoustic 2			Ride Cymbal Acoustic 2			Ride Cymbal Acoustic 2			Ride Cymbal Real 2		
60	C3	C5												
61	C#3	C#5												
62	D3	D5												
63	D#3	D#5												
64	E3	E5												
65	F3	F5												
66	F#3	F#5												
67	G3	G5												
68	G#3	G#5												
69	A3	A5												
70	A#3	A#5												
71	B3	B5												
72	C4	C6												
73	C#4	C#6												
74	D4	D6												
75	D#4	D#6												
76	E4	E6												
77	F4	F6												
78	F#4	F#6												
79	G4	G6												
80	G#4	G#6												
81	A4	A6												
82	A#4	A#6												
83	B4	B6												
84	C5	C7	Wind Chime			Wind Chime			Wind Chime			Wind Chime		
85	C#5	(C#7)												
86	D5	(D7)												
87	D#5	(D#7)												
88	E5	(E7)												
89	F5	(F7)												
90	F#5	(F#7)												
91	G5	(G7)												

Same as Standard Kit 1

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

No Sound

CVP-709			○	○	○ (Live!)	○ (Live!)	○										
CVP-705			○	○	○ (Live!)	○ (Live!)	○										
Kit Name			SFX Kit 1 (*)			SFX Kit 2 (*)			New SFX Kit 1 (*)			New SFX Kit 2 (*)			Noises Kit (*)		
MSB-LSB-PC#			126-0-0			126-0-1			126-0-2			126-0-3			126-0-8		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C#-1	C#1															
14	D-1	D1															
15	D#-1	D#1															
16	E-1	E1															
17	F-1	F1															
18	F#-1	F#1															
19	G-1	G1															
20	G#-1	G#1															
21	A-1	A1															
22	A#-1	A#1															
23	B-1	B1															
24	C0	C2															
25	C#0	C#2															
26	D0	D2															
27	D#0	D#2															
28	E0	E2															
29	F0	F2															
30	F#0	F#2															
31	G0	G2															
32	G#0	G#2															
33	A0	A2															
34	A#0	A#2															
35	B0	B2															
36	C1	C3	Cutting Noise 1	●		Phone Call	●		Cutting Noise 1	●		Phone Call 2	●		White Noise	●	
37	C#1	C#3	Cutting Noise 2	●		Door Squeak	●		Cutting Noise 2	●		Door Squeak 2	●		Pink Noise	●	
38	D1	D3				Door Slam	●					Door Slam 2	●		White Noise Down 1	●	
39	D#1	D#3	String Slap	●		Scratch Cut	●		String Slap	●		Scratch Cut	●		Pink Noise Down 1	●	
40	E1	E3				Scratch Split	●					Scratch Split	●		White Noise Down 2	●	
41	F1	F3				Wind Chime	●					Wind Chime	●		Pink Noise Down 2	●	
42	F#1	F#3				Telephone Ring	●					Telephone Ring 2	●		White Noise Up 2	●	
43	G1	G3													White Noise Up 1	●	
44	G#1	G#3													Pink Noise Up	●	
45	A1	A3													White Noise Up Release	●	
46	A#1	A#3													Pink Noise Up Release	●	
47	B1	B3													White Noise Up LFO	●	
48	C2	C4													Pink Noise Up LFO	●	
49	C#2	C#4															
50	D2	D4															
51	D#2	D#4															
52	E2	E4	Flute Key Click	●		Car Engine Ignition	●		Flute Key Click	●		Car Engine Ignition	●				
53	F2	F4				Car Tires Squeal	●					Car Tires Squeal	●				
54	F#2	F#4				Car Passing	●					Car Passing	●				
55	G2	G4				Car Crash	●					Car Crash	●				
56	G#2	G#4				Siren	●					Siren 2	●				
57	A2	A4				Train	●					Train 2	●				
58	A#2	A#4				Jet Plane	●					Jet Plane 2	●				
59	B2	B4				Starship	●					Starship	●				
60	C3	C5				Burst	●					Burst	●				
61	C#3	C#5				Roller Coaster	●					Roller Coaster	●				
62	D3	D5				Submarine	●					Submarine	●				
63	D#3	D#5															
64	E3	E5															
65	F3	F5															
66	F#3	F#5															
67	G3	G5															
68	G#3	G#5	Shower	●		Laugh	●		Shower 2	●		Laugh	●				
69	A3	A5	Thunder	●		Scream	●		Thunder 2	●		Scream 2	●				
70	A#3	A#5	Wind	●		Punch	●		Wind 2	●		Punch 2	●				
71	B3	B5	Stream	●		Heart Beat	●		Stream 2	●		Heart Beat	●				
72	C4	C6	Bubble	●		Foot Steps	●		Bubble 2	●		Foot Steps 2	●				
73	C#4	C#6	Feed	●					Feed	●							
74	D4	D6															
75	D#4	D#6															
76	E4	E6															
77	F4	F6															
78	F#4	F#6															
79	G4	G6															
80	G#4	G#6															
81	A4	A6															
82	A#4	A#6															
83	B4	B6															
84	C5	C7	Dog	●		Machine Gun	●		Dog	●		Machine Gun 2	●				
85	C#5	(C#7)	Horse	●		Laser Gun	●		Horse	●		Laser Gun	●				
86	D5	(D7)	Bird Tweet	●		Explosion	●		Bird Tweet	●		Explosion 2	●				
87	D#5	(D#7)				Firework	●					Firework	●				
88	E5	(E7)															
89	F5	(F7)															
90	F#5	(F#7)	Ghost	●					Ghost	●							
91	G5	(G7)	Maou	●					Maou	●							

■ No Sound

*Actual Keyboard Notes are one octave lower than the ones described in the above list.

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

CVP-709			○	○ (Live!)	○ (Live!)	○ (Live!)	○ (Live!)										
CVP-705			○	○ (Live!)	○ (Live!)	○ (Live!)	○ (Live!)										
Kit Name			Arabic Kit			Cuban Kit			Pop Latin Kit			Pop Latin Kit 2			Cymbal Kit		
MSB-LSB-PC#			126-0-35			126-0-40			126-0-43			126-0-44			126-0-49		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C # -1	C # 1							Cajon Low			Cajon Low					
14	D -1	D 1							Cajon Slap			Cajon Slap					
15	D # -1	D # 1							Cajon Tip			Cajon Tip					
16	E -1	E 1							Claves High			Claves High					
17	F -1	F 1							Claves Low			Claves Low					
18	F # -1	F # 1							Hand Clap			Hand Clap					
19	G -1	G 1															
20	G # -1	G # 1							Finger Snap			Finger Snap					
21	A -1	A 1							Castanet			Castanet					
22	A # -1	A # 1						Conga H Tip			Conga H Tip						
23	B -1	B 1						Conga H Heel			Conga H Heel						
24	C 0	C 2	Nakarazan Dom					Conga H Open			Conga H Open						
25	C # 0	C # 2	Cabasa					Conga H Mute			Conga H Mute						
26	D 0	D 2	Nakarazan Edge					Conga H Slap Open			Conga H Slap Open						
27	D # 0	D # 2	Hager Dom					Conga H Slap			Conga H Slap						
28	E 0	E 2	Hager Edge					Conga H Slap Mute			Conga H Slap Mute						
29	F 0	F 2	Bongo H					Conga L Tip			Conga L Tip						
30	F # 0	F # 2	Bongo L					Conga L Heel			Conga L Heel						
31	G 0	G 2	Conga H Mute					Conga L Open			Conga L Open						
32	G # 0	G # 2	Conga H Open					Conga L Mute			Conga L Mute						
33	A 0	A 2	Conga L					Conga L Slap Open			Conga L Slap Open						
34	A # 0	A # 2	Zagrouda H					Conga L Slap			Conga L Slap						
35	B 0	B 2	Zagrouda L	●				Conga L Slide	●		Conga L Slide	●					
36	C 1	C 3	Kick Soft					Bongo H Open One Finger			Bongo H Open One Finger						
37	C # 1	C # 3	Side Stick					Bongo H Open Three Finger			Bongo H Open Three Finger						
38	D 1	D 3	Snare Soft					Bongo H Rim			Bongo H Rim						
39	D # 1	D # 3	Arabic Hand Clap					Bongo H Tip			Bongo H Tip						
40	E 1	E 3	Snare Drum					Bongo H Heel			Bongo H Heel						
41	F 1	F 3	Floor Tom L					Bongo H Slap			Bongo H Slap						
42	F # 1	F # 3	Hi-Hat Closed		1			Bongo L Open One Finger			Bongo L Open One Finger						
43	G 1	G 3	Floor Tom H					Bongo L Open Three Finger			Bongo L Open Three Finger						
44	G # 1	G # 3	Hi-Hat Pedal		1			Bongo L Rim			Bongo L Rim						
45	A 1	A 3	Low Tom					Bongo L Tip			Bongo L Tip						
46	A # 1	A # 3	Hi-Hat Open		1			Bongo L Heel			Bongo L Heel						
47	B 1	B 3	Mid Tom L					Bongo L Slap			Bongo L Slap						
48	C 2	C 4	Mid Tom H					Timbale L			Timbale L						
49	C # 2	C # 4	Crash Cymbal 1														
50	D 2	D 4	High Tom														
51	D # 2	D # 4	Ride Cymbal 1														
52	E 2	E 4	Crash Cymbal 2														
53	F 2	F 4	Duhulla Dom					Paila L			Paila L						
54	F # 2	F # 4	Tambourine					Timbale H			Timbale H						
55	G 2	G 4	Duhulla Tak														
56	G # 2	G # 4	Cowbell														
57	A 2	A 4	Duhulla Sak														
58	A # 2	A # 4	Claves														
59	B 2	B 4	Doff Dom					Paila H			Paila H						
60	C 3	C 5	Katam Dom					Cowbell Top			Cowbell Top						
61	C # 3	C # 5	Katam Tak					Cowbell 1			Cowbell 1						
62	D 3	D 5	Katam Sak					Cowbell 2			Cowbell 2						
63	D # 3	D # 5	Katam Tak					Cowbell 3			Cowbell 3						
64	E 3	E 5	Doff Tak					Guiro Short			Guiro Short						
65	F 3	F 5	Tabla Dom					Guiro Long	●		Guiro Long	●					
66	F # 3	F # 5	Tabla Tak 1					Metal Guiro Short			Metal Guiro Short						
67	G 3	G 5	Tabla Tik					Metal Guiro Long	●		Metal Guiro Long	●					
68	G # 3	G # 5	Tabla Tak 2					Tambourine			Tambourine						
69	A 3	A 5	Tabla Sak					Tambourim Open			Tambourim Open						
70	A # 3	A # 5	Tabla Roll Edge	●				Tambourim Mute			Tambourim Mute						
71	B 3	B 5	Tabla Flam					Tambourim Tip			Tambourim Tip						
72	C 4	C 6	Sagat 1					Maracas			Maracas						
73	C # 4	C # 6	Tabel Dom					Shaker			Shaker						
74	D 4	D 6	Sagat 3					Cabasa			Cabasa						
75	D # 4	D # 6	Tabel Tak					Cuica Mute			Cuica Mute						
76	E 4	E 6	Sagat 2					Cuica Open			Cuica Open						
77	F 4	F 6	Rik Dom					Cowbell High 1			Cowbell High 1						
78	F # 4	F # 6	Rik Tak 2					Cowbell High 2			Cowbell High 2						
79	G 4	G 6	Rik Finger 1					Shekere			Shekere						
80	G # 4	G # 6	Rik Tak 1					Shekere Tone			Shekere Tone						
81	A 4	A 6	Rik Finger 2					Triangle Mute		1	Triangle Mute		1				
82	A # 4	A # 6	Rik Brass Tremolo	●				Triangle Open		1	Triangle Open		1				
83	B 4	B 6	Rik Sak														
84	C 5	C 7	Rik Tik					Wind Chime			Wind Chime						
85	C # 5	(C # 7)															
86	D 5	(D 7)															
87	D # 5	(D # 7)															
88	E 5	(E 7)															
89	F 5	(F 7)															
90	F # 5	(F # 7)															
91	G 5	(G 7)															

No Sound

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

CVP-709			○ (Live!)			○ (Live!)			○ (Live!)		
CVP-705			○ (Live!)			—			—		
Kit Name			Turkish Kit			Vocal Effects Kit (*)			Gospel Ad Libs (*)		
MSB-LSB-PC#			126-0-67			126-0-109			126-0-110		
Note#	MIDI Note	Keyboard Note	Full Name	Key Off (*1)	Alt Grp (*2)	Full Name	Key Off	Alt Grp	Full Name	Key Off	Alt Grp
13	C # -1	C # 1	Asma Davul Left Side								
14	D -1	D1	Asma Davul Right Side								
15	D # -1	D # 1	Asma Davul Side Body								
16	E -1	E1	Asma Davul Both Sides								
17	F -1	F1	Koltuk Davul Flam								
18	F # -1	F # 1	Koltuk Davul Teke								
19	G -1	G1	Koltuk Davul Tek								
20	G # -1	G # 1	Koltuk Davul Dum								
21	A -1	A1	Bendir Teke Flam								
22	A # -1	A # 1	Bendir Teke Dead								
23	B -1	B1	Bendir Tek Dead								
24	C0	C2	Bendir Teke								
25	C # 0	C # 2	Bendir Tek								
26	D0	D2	Bendir Slap		2						
27	D # 0	D # 2	Bendir Dum		2						
28	E0	E2	Zil Right Close		3						
29	F0	F2	Zil Right Open		3						
30	F # 0	F # 2	Zil Left Close		4						
31	G0	G2	Zil Left Open		4						
32	G # 0	G # 2	Tef Teke Flam		5						
33	A0	A2	Tef Tek Mute		5						
34	A # 0	A # 2	Tef Teke Damped								
35	B0	B2	Tef Tek Mute Medium								
36	C1	C3	Tef Dum Mute			Male "Ha" 1	●				
37	C # 1	C # 3	Tef Cymbal		9	Female "Ha" 1	●				
38	D1	D3	Tef Cymbal Mute		9	Male "Ha" 2	●				
39	D # 1	D # 3	Tef Tremolo	●		Male "Ha" 3	●				
40	E1	E3	Tef Shake 1			Male "Bh" 1	●				
41	F1	F3	Tef Shake 2			Female "Bh" 1	●				
42	F # 1	F # 3	Tef Tek Flam			Male "Kh" 1	●				
43	G1	G3	Tef Full Open			Female "Kh" 1	●				
44	G # 1	G # 3	Tef Teke Open Short			Male "Ph" 1	●				
45	A1	A3	Tef Tek Open Short			Female "Ph" 1	●				
46	A # 1	A # 3	Tef Tek Open			Male "Th" 1	●				
47	B1	B3	Tef Dum Open			Female "Th" 1	●				
48	C2	C4	Hollo Finger Dead			Male "Bh" 2	●	C'mon		●	
49	C # 2	C # 4	Hollo Slap			Female "Bh" 2	●	Hoo!		●	
50	D2	D4	Hollo Dum			Male "Kh" 2	●	Aha!		●	
51	D # 2	D # 4	Kasik		1	Female "Kh" 2	●	Oh Yeah		●	
52	E2	E4	Kasik Flam		1	Male "Ph" 2	●	Yayayayayah		●	
53	F2	F4	Bass Darbuka Tek Dead			Female "Ph" 2	●	Put Your Hands Together		●	
54	F # 2	F # 4	Bass Darbuka Tek Flam			Male "Th" 2	●	C'mon Now		●	
55	G2	G4	Bass Darbuka Teke			Female "Th" 2	●	Heey		●	
56	G # 2	G # 4	Bass Darbuka Teke Other Finger			Male "Ha" 4	●	Everybody Now		●	
57	A2	A4	Bass Darbuka Teke Index Finger			Female "Ha" 2	●	Clap Your Hands, Everybody C'mon		●	
58	A # 2	A # 4	Bass Darbuka Tek			Male "Ha" 5	●	With All Your Soul		●	
59	B2	B4	Bass Darbuka Slap			Male "Ha" 6	●	Stand Up On Your Feet		●	
60	C3	C5	Bass Darbuka Slap Medium		7	Male "Bh" 3	●	Uhh Yeah		●	
61	C # 3	C # 5	Bass Darbuka Dum		7	Female "Bh" 3	●	Aaoh		●	
62	D3	D5	Darbuka Roll Close	●	6	Male "Kh" 3	●	Come On!		●	
63	D # 3	D # 5	Darbuka Roll Open	●	6	Female "Kh" 3	●	Yeah!		●	
64	E3	E5	Darbuka Teke Damped Flam			Male "Ph" 3	●	Alright Now!		●	
65	F3	F5	Darbuka Tek Dead			Female "Ph" 3	●	One		●	
66	F # 3	F # 5	Darbuka Tek Damped			Male "Th" 3	●	Two		●	
67	G3	G5	Darbuka Teke Open Flam			Female "Th" 3	●	Three		●	
68	G # 3	G # 5	Darbuka Teke Open			Male "Bh" 4	●	Four		●	
69	A3	A5	Darbuka Teke Other Finger 1			Female "Bh" 4	●	One!		●	
70	A # 3	A # 5	Darbuka Teke Index Finger 1			Male "Kh" 4	●	Two!		●	
71	B3	B5	Darbuka Tek 1			Female "Kh" 4	●	Three!		●	
72	C4	C6	Darbuka Teke Other Finger 2			Male "Ph" 4	●	Four!		●	
73	C # 4	C # 6	Darbuka Teke Index Finger 2			Female "Ph" 4	●	Five!		●	
74	D4	D6	Darbuka Tek 2			Male "Th" 4	●	Six!		●	
75	D # 4	D # 6	Darbuka Slap Medium			Female "Th" 4	●	Seven!		●	
76	E4	E6	Darbuka Slap		8			Eight!		●	
77	F4	F6	Darbuka Dum		8			Clap!		●	
78	F # 4	F # 6	Bongo Tek Roll	●				Gospel Clap 1		●	
79	G4	G6	Bongo Flam					Gospel Clap 2		●	
80	G # 4	G # 6	Bongo Tek Flam								
81	A4	A6	Bongo Tek								
82	A # 4	A # 6	Bongo Slap								
83	B4	B6	Bongo Flam Hi								
84	C5	C7	Bongo Dum								
85	C # 5	(C # 7)									
86	D5	(D7)									
87	D # 5	(D # 7)									
88	E5	(E7)									
89	F5	(F7)									
90	F # 5	(F # 7)									
91	G5	(G7)									

No Sound

*Actual Keyboard Notes are one octave lower than the ones described in the above list.

*1 Key Off: Keys marked "●" stop sounding the instant they are released.

*2 Alternate Group: Playing any instrument within a numbered group will immediately stop the sound of any other instrument in the same group of the same number.

Style List / Liste der Styles / Liste des styles / Lista de estilos / Lista de estilos

CVP-709

Category	Sub Category	Style Name		
Pop&Rock	Pop	Contemp Gtr Pop		
		Standard 8Beat		
		West Coast Beat		
		Cool 8Beat		
		80s American Pop		
		Live 8Beat		
		80s Guitar Pop		
		Classic 8Beat		
		80s Pop		
		80s 8Beat		
		Pop Evergreen		
		Chart Piano Shuffle		
		00s Boy Band		
		Chart Rock Shuffle		
		80s Boy Band		
		Chart Guitar Pop		
		90s Pop Shuffle		
		Contemp Pop		
		90s Guitar Pop		
		Jersey Pop		
		Easy Pop		
		Chart Pop		
		Pop Shuffle		
		Straight 8 Pop		
		Scand Pop Shuffle		
		Uptempo 8Beat		
		Brit Pop		
		8Beat Modern		
		Brit Pop Swing		
		West Coast Pop		
		Unplugged		
		8Beat Guitar Pop		
		Classic 16Beat		
		8Beat		
		Rock	Stadium Rock	
			Standard Rock	
			80s Power Rock	
			Contemp Rock	
			80s Pop Rock	
			Funk Pop Rock	
			80s Synth Rock	
			Acoustic Rock	
			Brit Rock Pop	
			Soft Rock	
			Slow Rock	
			70s Pop&Rock	70s Piano Hit
				70s Pop Duo 1
				70s Piano Rock
				70s Pop Duo 2
				70s Glam Piano
	70s Cool Ballad			
	70s Swing Piano			
	70s Easy Pop			
	Glam Piano Rock			
	70s 8Beat			
	70s Rock			
	Croco Twist			
	70s Rock Shuffle			
	Vintage Guitar Pop			
	70s Rock Bros			
	60s Pop&Rock	60s Big Hit		
		Surf Rock		
		60s Underground		
		Beach Rock		
		60s Rising Pop		
		Bubblegum Pop		
		60s Vintage Pop		
		60s Guitar Pop		
		60s Piano Pop		

Category	Sub Category	Style Name	
Pop&Rock	60s Pop&Rock	60s Chart Swing	
		60s Pop Rock	
		60s Rock & Roll	
		60s Vintage Rock	
		60s 8Beat	
		50s Rock&Roll	Vintage R&R
			Rock & Roll 1
			50s Rock & Roll
			Rock & Roll 2
			Oldies R&R
	Rock & Roll Shfl		
	Skiffle		
	Piano R&R		
	Pop&Rock Ballad		Easy 8Beat 1
			6-8 Soul Ballad
			Easy 8Beat 2
			6-8 Ballad Rock
			90s Piano Ballad
			Standard Piano Bld
			Smooth Ballad
		70s Piano Pop Bld	
		Mod 6-8 Piano Bld	
		70s R&B Pop Bld	
		Acoustic 8Bt Bld	
		Light Ballad	
		Orch Rock Ballad	
		Pop Ballad	
		Vocal Pop Ballad	
		Pop Guitar Ballad	
		Mod Orch Ballad	
		Epic Ballad	
		Boy Band Ballad	
		Modern Pop Ballad	
		70s Chart Ballad	
		80s Movie Ballad	
		80s Piano Ballad	
		80s Synth Piano	
		80s Smooth Ballad	
		90s Cool Ballad	
		80s Analog Ballad	
		90s Rock Ballad	
		80s EP Ballad	
		MOR 16Beat	
		8Beat Ballad 1	
		Power Ballad 1	
		8Beat Ballad 2	
		Power Ballad 2	
		Acoustic Gtr Ballad	
		Guitar Ballad	
		Easy Acoustic Bld	
Organ Ballad			
Pop Piano Ballad			
EP Ballad			
16Beat Pop			
Contemp Rock Bld			
16Beat Ballad			
Chart Ballad			
Modern 16Bt Ballad			
Slow & Easy			
Contemp Pop Bld			
Acoustic Ballad			
6-8 Modern			
Love Song			
Pop Waltz			
Slow Orch Ballad			
Piano Ballad			
8Beat Piano Ballad			
Worship	Worship Slow		
	Worship 6-8		

Category	Sub Category	Style Name
Pop&Rock	Worship	Worship Medium
		Worship Irish Rock
		Worship Fast
		Worship Power Bld
		Funky Shuffle
	Soul	Detroit Pop 1
		70s Cool Shuffle
		Detroit Pop 2
		70s Chart Soul
		Motor City
		Soul Brothers
		Frankly Soul
		Live Soul Band
		Kool Funk
		Soul
		Kool Shuffle
		Soul Shuffle
		Lovely Shuffle
		Soul Beat
		UK Soul Pop
	Disco	Funk Disco
		80s Disco
		70s Disco 1
		90s Disco
		70s Disco 2
		Disco Philly
		70s Disco Funk
		Disco House
		Saturday Night
		Pop Legend
		Synth Pop
		Disco Fox Rock
		80s Synth Disco
		Mallorca Disco
		Movie Disco
	Disco Chocolate	
	Dance	Global DJ's
		Clubdance 1
		Ibiza 2010
		Clubdance 2
		Club House
		Dream Dance
		Electronica
		Retro Pop
		Funky House
		Dancefloor
	Dancehall	
	Modern R&B	Cool R&B
		Modern Hip Hop
		R&B Soul Ballad
Euro Hip Hop		
New R&B Ballad		
US Hip Hop		
Soul R&B		
Classic Hip Hop		
Chart R&B		
New Hip Hop		
Pop R&B		
Trip Hop		
New R&B		
Groundbeat		
Modern R&B		
Analog Ballad		
Chill Out	Chill Performer	
	Chillout 1	
	Coudy Bay	
	Chillout 2	
	Night Walk	
Chillout Cafe		

CVP-709

Category	Sub Category	Style Name	
Pop&Rock	Chill Out	Play 4 Sofa	
		Ethereal Synth	
		Angel Sun	
	Trance	Celtic Trance	
		6-8 Trance	
		Euro Trance	
Trance Pop			
Country&Blues	Modern Country	Easy Country Pop	
		70s Country Pop	
		Country Blues	
		70s Chart Country	
		Modern Pickin'	
		New Country	
		Cali Country	
		Country Strum	
		Country Straits	
		Modern Bluegrass	
		Country Hits	
		Country Brothers	
		Country 8Beat	
		Modern Cntry Pop	
		Country Pop	
		Singer Song Writer	
		Country Rock	
		Hully Gully	
		Trad Country	70s Country Swing
			Country Swing 1
			Pickin' Swing
	Country Swing 2		
	Easy Country		
	Country Shuffle		
	Bluegrass		
	Country Sing-along		
	Hoedown		
	Standard Swing		
	Country 2-4		
	Finger Pickin'		
	Country Two Step		
	Folk Pop		
	Country Ballad		Slow Country Pop
			Country Ballad
			Mod Country Bld 1
		Country Rock Bld	
		Mod Country Bld 2	
		Country Waltz	
		Country Pop Ballad	
	Blues	The Blues	
		Modern Shuffle	
		Slow Blues	
		Let's Funk	
		Shuffle Blues	
		6-8 Rock	
		Blueberry Blues	
		6-8 Soul	
		Blues Rock	
		Soul Swing	
		Piano Blues 1	
		Piano Blues 2	
		Gospel	Hollywood Gospel
			Gospel Funk
			Amazing Gospel
Gospel Brothers			
Gospel Ballad			
Gospel Sisters			
Gospel Party			
Gospel Swing			
Southern Gospel			
Standards & Jazz	Jazz Combo	Cool Jazz Club	
		Jazz Guitar Club	

Category	Sub Category	Style Name
Standards & Jazz	Jazz Combo	Slow Jazz Ballad
		Instrumental Jazz
		Swing Medium
		Manhattan Swing
		Fast Jazz
		Trad Piano Jazz
		Acoustic Jazz
		Trad Piano Ballad
		Cool Piano Jazz
		French Jazz
		Modern Jazz Bld 1
		Organ Combo
		Modern Jazz Bld 2
		Piano Boogie
		Jazz Club
		Boogie Fast
		Bebop
		Boogie Woogie
		Piano Swing 1
		Jazz Ballad
		Piano Swing 2
	2Beat Swing	
	Big Band	Big Band Jazz
		The Jazz Singers
		Modern Big Band
		40s Swing Ballad
		Mod Big Band Shfl
		Classic Big Band
		Mod Big Band Bld
		Jump Jive
		Afro Cuban
		Swingin' Boogie
		Orch Big Band 1
		Big Band Medium 1
		Orch Big Band 2
	Big Band Medium 2	
	30s Big Band	
	Big Band Fast 1	
	40s Big Band	
	Big Band Fast 2	
	Swingin' Big Band	
	Moonlight Ballad	
	Orchestra Swing	Easy Swing
		Orchestra Swing 1
		MOR Swing
		Orchestra Swing 2
		Dreamy Ballad
		Easy Listening
		Cool Jazz Ballad
		Orchestral Ballad
		LA Cool Swing
		Midnight Swing
	Organ Groove	
	Jazz Waltz	Cool Jazz Waltz
Easy Waltz		
Jazz Waltz Slow		
MOR Waltz		
Jazz Waltz Medium		
Five-Four		
Jazz Waltz Fast 1		
Jazz Waltz		
Jazz Waltz Fast 2		
Dixie&Trad Jazz	Ragtime 1	
	Piano Rag 1	
	Ragtime 2	
	Piano Rag 2	
	Dixieland 1	
	Stride 1	
	Dixieland 2	

Category	Sub Category	Style Name		
Standards & Jazz	Dixie&Trad Jazz	Stride 2		
		Charleston		
		Saloon Piano		
		70s Scat Legend		
		Jazz Pop		
	Fusion	Fusion Shuffle		
		Jazz Funk		
		Entertainment	Movie&Show	Movie Soundtrack
				Mod Broadway Bld
				Ethereal Movie
Broadway Ballad				
On Broadway				
Movie Swing 1				
Cartoon Ballad				
Movie Swing 2				
Animation Ballad				
Tap Dance Swing				
Sci-fi March				
70s TV Theme				
Blockbuster				
Big Screen Classic				
Secret Service				
Movie Ballad				
Wild West				
Showtune				
Choir Soundtrack				
Animation Fantasy				
Movie Panther				
Musical				
Easy Listening	Classic Piano Bld			
	Easy Ballad			
	Romantic Ballad			
	Guitar Serenade			
	Romantic Waltz			
	Piano Orch Ballad			
	6-8 Slow Rock 1			
	6-8 Orchestral			
	6-8 Slow Rock 2			
	12-8 Ballad			
Tijuana				
French 50s				
Pub Piano				
Pop Classics				
Sing-a-long Piano				
Ballroom	Viennese Waltz 1			
	Slowfox			
	Viennese Waltz 2			
	Foxtrot			
	English Waltz			
	Swingfox			
	Slow Waltz			
	Vocal Foxtrot			
	Vocal Waltz			
	Quickstep			
	Tango 1			
	Cha Cha Cha			
	Tango 2			
	Jive			
	Pasodoble			
	Beguine			
	Samba			
	Twist			
	Rumba			
	Swing Waltz			
9-8 Waltz				
Piano Rumba				
Standard Waltz				
Piano Cha Cha				

CVP-709

Category	Sub Category	Style Name	Category	Sub Category	Style Name	Category	Sub Category	Style Name	
Entertainment	Ballroom	Standard Rumba	Latin&World	Brazil	Brazilian Samba	Latin&World	Classic	Romantic Ballet	
		Piano Beguine			Bossa Nova			Ethereal Voices	
	Organ	Toccata			Big Band Samba			Green Fantasia	
		Elec Organ Ballad			Slow Bossa			Baroque Air	
		Choral Hymn			Piano Samba			String Adagio	
		Euro Pop Organ			Fast Bossa			Classical Menuet	
		Theatre Foxtrot			Piano Bossa			Baroque Concerto	
		Organ Bossa			Cuba			Rumba Bolero	Moonlight 6-8
		Theatre Quickstep						Salsa	Classical Serenad
		Organ Samba						Guajira	Nocturne
		Theatre March		Big Band Salsa				String Concerto	
		Organ Cha Cha		Danzon				Traditional 1	
		Organ Swing		Big Band Mambo				Orchestral March	
		Organ Quickstep		Guaguanco				Traditional 2	
		Organ Rumba		Guitar Rumba				Orchestral Bolero	
		Holiday		Christmas Swing 1				Cuban Son	Traditional 3
	Celtic Xmas			Mexico				Arpeggio 1	
	Christmas Swing 2				Mariachi Waltz			Arpeggio 2	
	Christmas Ballad				Banda Polka			Arpeggio 3	
	Christmas Shuffle				Norteno			Learning 2-4	
	Christmas Waltz				Banda Vals			Trad Waltz	Highland Waltz
	Schlager	Modern Schlager			Mexican Dance				Scand Waltz
		Schlager Fever		Bolero Lento	French Waltz				
		Young Fox		Caribbean	Ober Walzer 1				
		Schlager Palace			Sheriff Reggae				Italian Waltz
		Young Ballad			Merengue				Ober Walzer 2
		Party Arena			Happy Reggae				German Waltz
		Hello Shuffle			Cumbia				French Musette
		Mallorca Party			Calypso				Bohemian Waltz
		Apres Ski Hit			Bomba				Alpen Land 3-4
		Alpen Schlager			Caribbean				Waltz
		Disco Fox			Bachata				Scand Hambo
		Soft Schlager			Zouk				Piano Slow Waltz
		German Rock		Vallenato 4-4	March&Polka				US March
		Schlager Fox		Rumba Island			Ober Polka 1		
		Synth Pop Duo		European			German March 1		
		Schlager Italia					Flamenco	Ober Polka 2	
		Alp Rock					Sirtaki	German March 2	
		Schlager Shuffle					Pop Flamenco	Italian Polka	
		70s French Hit					Tarantella	6-8 March	
		Schlager Waltz					Spanish Paso	Zither Polka	
		Alp Ballad 1		Italian Mazurka			Brass Band Hymn		
		Schlager Pop		Rumba Flamenco			Brass Band		
		Alp Ballad 2		Italian Tango			Piano March 1		
		Schlager Beat		Latin Pop			Orchestral Polka		
		Schlager Samba					Latin Party Pop	Piano March 2	
		Schlager Alp					Pop Bossa 1	4 Stroke	
		Schlager Polka			Pop Latin		6-8 Piano March		
		Schlager Rumba			Pop Bossa 2		Alpen Land 4-4		
		Schlager Rock			Pop Latin Ballad		World	Turkish Euro 1	
		Schlager 6-8		Latin Disco 1	J-Pop Hit 1				
		Scand Bugg		Rock Cha Cha	Turkish Euro 2				
		Scand Shuffle		Latin Disco 2	J-Pop Hit 2				
		Scand Slow Rock		Celtic	Oriental Pop				
		Party Polka			Celtic Dance 3-4			Hawaiian	
		Scand Country 1			Jig			Classic	Contemp Horns
		Polka Pop			Celtic Dance				Choral Symphony
		Scand Country 2			Reel				Proms March
		8Beat Adria			Irish Dance				Ethereal Hymn
		Latin&World		Brazil	Brazilian Bossa		World	Turkish Euro 1	
					Jazz Samba			J-Pop Hit 1	
					Cool Bossa			Turkish Euro 2	
					Bossa Brazil			J-Pop Hit 2	
					Bossa Slow			Oriental Pop	
					Lounge Bossa			Hawaiian	
					Bossa Fast			Classic	Contemp Horns
					Slow Bar Bossa				Choral Symphony
					Samba Fast				Proms March
					Orchestral Bossa				Ethereal Hymn

CVP-705

Category	Sub Category	Style Name		
Pop&Rock	Pop	Contemp Gtr Pop		
		Standard 8Beat		
		West Coast Beat		
		Cool 8Beat		
		80s American Pop		
		Live 8Beat		
		80s Guitar Pop		
		Classic 8Beat		
		80s Pop		
		Chart Piano Shuffle		
		Chart Rock Shuffle		
		80s Boy Band		
		Chart Guitar Pop		
		90s Guitar Pop		
		Easy Pop		
		Chart Pop		
		Straight 8 Pop		
		Scand Pop Shuffle		
		Uptempo 8Beat		
		Brit Pop		
		8Beat Modern		
		Brit Pop Swing		
		West Coast Pop		
		8Beat Guitar Pop		
		Classic 16Beat		
		8Beat		
		Rock	Standard Rock	
			80s Power Rock	
			Contemp Rock	
			80s Pop Rock	
			Funk Pop Rock	
			80s Synth Rock	
			Acoustic Rock	
			Brit Rock Pop	
			Soft Rock	
			Slow Rock	
			70s Pop&Rock	70s Piano Hit
				70s Piano Rock
				70s Pop Duo
				70s Glam Piano
	70s Swing Piano			
	Glam Piano Rock			
	70s 8Beat			
	70s Rock			
	Vintage Guitar Pop			
	60s Pop&Rock	60s Big Hit		
		60s Rising Pop		
		60s Guitar Pop		
		60s Vintage Pop		
		60s Chart Swing		
		60s Piano Pop		
		60s Rock & Roll		
		60s Pop Rock		
		Bubblegum Pop		
		60s Vintage Rock		
		60s 8Beat		
		50s Rock&Roll	Vintage R&R	
	Oldies R&R			
	Rock & Roll 1			
	Skiffle			
	Rock & Roll 2			
	Piano R&R			
	Rock & Roll Shfl			
	Pop&Rock Ballad	Easy 8Beat 1		
		6-8 Soul Ballad		

Category	Sub Category	Style Name		
Pop&Rock	Pop&Rock Ballad	Easy 8Beat 2		
		6-8 Ballad Rock		
		90s Piano Ballad		
		Standard Piano Bld		
		Smooth Ballad		
		70s Piano Pop Bld		
		Mod 6-8 Piano Bld		
		Orch Rock Ballad		
		Pop Ballad		
		Pop Guitar Ballad		
		Epic Ballad		
		Modern Pop Ballad		
		70s Chart Ballad		
		80s Movie Ballad		
		80s Synth Piano		
		80s Smooth Ballad		
		90s Cool Ballad		
		80s Analog Ballad		
		90s Rock Ballad		
		80s EP Ballad		
		Power Ballad 1		
		8Beat Ballad 1		
		Power Ballad 2		
		8Beat Ballad 2		
		MOR 16Beat		
		Acoustic Gtr Ballad		
		Easy Acoustic Bld		
		Organ Ballad		
		Pop Piano Ballad		
		EP Ballad		
		16Beat Pop		
		Contemp Rock Bld		
		16Beat Ballad		
		Modern 16Bt Ballad		
		Contemp Pop Bld		
		Acoustic Ballad		
		6-8 Modern		
		Love Song		
		Pop Waltz		
		Slow Orch Ballad		
		Piano Ballad		
		8Beat Piano Ballad		
		Worship	Worship Slow	
			Worship 6-8	
			Worship Medium	
			Worship Fast	
			Worship Power Bld	
			Soul	Funky Shuffle
				Detroit Pop 1
				70s Cool Shuffle
				Detroit Pop 2
				70s Chart Soul
		Motor City		
		Frankly Soul		
		Live Soul Band		
		Kool Funk		
		Soul		
		Disco	Funk Disco	
			80s Disco	
			70s Disco 1	
	90s Disco			

Category	Sub Category	Style Name	
Pop&Rock	Disco	70s Disco 2	
		Disco Philly	
		70s Disco Funk	
		Disco House	
		Saturday Night	
		Synth Pop	
		Disco Fox Rock	
		80s Synth Disco	
		Movie Disco	
		Disco Chocolate	
		Dance	Global DJ's
			Clubdance 1
			Ibiza 2010
			Clubdance 2
			Club House
	Dream Dance		
	Electronica		
	Retro Pop		
	Funky House		
	Dancefloor		
	Modern R&B		Modern Hip Hop
			R&B Soul Ballad
			Euro Hip Hop
			New R&B Ballad
			Soul R&B
		Classic Hip Hop	
		Chart R&B	
		New R&B	
		Analog Ballad	
		Chill Out	Chillout 1
	Coudy Bay		
	Chillout 2		
	Night Walk		
	Chillout Cafe		
	Trance	Play 4 Sofa	
		Ethereal Synth	
		Angel Sun	
		Celtic Trance	
		6-8 Trance	
	Country&Blues	Modern Country	Euro Trance
Easy Country Pop			
70s Country Pop			
Country Blues			
70s Chart Country			
Modern Pickin'			
New Country			
Country Strum			
Modern Bluegrass			
Country Hits			
Country Brothers			
Country 8Beat			
Modern Cntry Pop			
Country Pop			
Country Rock			
Hully Gully			
Trad Country		70s Country Swing	
		Country Swing	
		Pickin' Swing	
		Easy Country	
		Country Shuffle	
		Bluegrass	
		Country Sing-along	
		Hoedown	
		Standard Swing	
	Country 2-4		

CVP-705


Category	Sub Category	Style Name	Category	Sub Category	Style Name	Category	Sub Category	Style Name		
Country&Blues	Trad Country	Country Two Step	Standards & Jazz	Orchestra Swing	Midnight Swing	Entertainment	Ballroom	Rumba		
		Folk Pop			Organ Groove			Cha Cha Cha		
	Country Ballad	Slow Country Pop		Jazz Waltz	Cool Jazz Waltz			Standard Waltz		
		Mod Country Bld 1			Easy Waltz			Jive		
		Country Rock Bld			Jazz Waltz Slow			Standard Rumba		
		Mod Country Bld 2			MOR Waltz			Swingfox		
		Country Waltz			Jazz Waltz Medium			Piano Rumba		
		Country Pop Ballad			Five-Four			Beguine		
		Blues			The Blues			Dixie&Trad Jazz	Ragtime 1	Piano Cha Cha
	Modern Shuffle			Piano Rag 1	Twist					
	Slow Blues			Ragtime 2	Piano Beguine					
	Shuffle Blues			Piano Rag 2	Swing Waltz					
	6-8 Rock			Dixieland 1	9-8 Waltz					
	Blueberry Blues			Stride 1	Organ				Euro Pop Organ	
	6-8 Soul			Dixieland 2					Organ Bossa	
	Blues Rock			Stride 2					Organ Samba	
	Piano Blues 1			Charleston					Organ Cha Cha	
	Piano Blues 2			Saloon Piano					Organ Swing	
	Gospel			Gospel Funk	Fusion				Jazz Pop	Organ Quickstep
		Gospel Brothers		Fusion Shuffle				Organ Rumba		
		Gospel Sisters		Movie&Show				Movie Soundtrack	Holiday	Christmas Swing
		Gospel Swing						Mod Broadway Bld		Christmas Ballad
		Southern Gospel						Broadway Ballad		Christmas Shuffle
		Standards & Jazz					Jazz Combo	Cool Jazz Club		On Broadway
	Jazz Guitar Club				Movie Swing 1			Schlager Palace		
	Slow Jazz Ballad				Cartoon Ballad			Party Arena		
	Instrumental Jazz			Movie Swing 2	Mallorca Party					
	Swing Medium			Animation Ballad	Apres Ski Hit					
	Fast Jazz			Tap Dance Swing	Alpen Schlager					
	Trad Piano Jazz			Sci-fi March	Disco Fox					
	Acoustic Jazz			70s TV Theme	Soft Schlager					
	Trad Piano Ballad			Blockbuster	German Rock					
	Cool Piano Jazz			Big Screen Classic	Schlager Fox					
French Jazz	Secret Service		Schlager Italia							
Modern Jazz Bld 1	Movie Ballad		Schlager Shuffle							
Organ Combo	Wild West		70s French Hit							
Modern Jazz Bld 2	Showtune		Schlager Waltz							
Piano Boogie	Choir Soundtrack		Alp Ballad 1							
Jazz Club	Animation Fantasy		Schlager Pop							
Bebop	Musical		Alp Ballad 2							
Boogie Woogie	Easy Listening		Schlager Beat							
Piano Swing 1			Classic Piano Bld	Schlager Samba						
Piano Swing 2			Easy Ballad	Schlager Alp						
Jazz Ballad			Romantic Ballad	Schlager Polka						
2Beat Swing			Guitar Serenade	Schlager Rumba						
Big Band			Big Band Jazz	Romantic Waltz	Schlager Rock					
			Orch Big Band 1	Piano Orch Ballad	Schlager 6-8					
			Modern Big Band	6-8 Slow Rock	Schand Bugg					
			Orch Big Band 2	6-8 Orchestral	Scand Shuffle					
			Mod Big Band Shfl	12-8 Ballad	Scand Slow Rock					
			Big Band Fast 1	Tijuana	Party Polka					
	Mod Big Band Bld		French 50s	8Beat Adria						
	Big Band Fast 2		Pub Piano	Polka Pop						
	Classic Big Band		Pop Classics	Scand Country 1						
	Afro Cuban		Ballroom	Scand Country 2						
	Jump Jive			Viennese Waltz	Latin&World	Brazil	Brazilian Bossa			
40s Big Band	Quickstep	Cool Bossa								
Moonlight Ballad	English Waltz	Bossa Slow								
Orchestra Swing	Tango	Bossa Fast								
	Orchestra Swing 1	Slow Waltz		Slow Bar Bossa						
MOR Swing	Pasodoble	Samba Fast								
Orchestra Swing 2	Slowfox	Orchestral Bossa								
Easy Listening	Samba	Brazilian Samba								
Cool Jazz Ballad	Foxtrot	Bossa Nova								

CVP-705

Category	Sub Category	Style Name
Latin&World	Brazil	Piano Samba
		Piano Bossa
	Cuba	Rumba Bolero
		Salsa
		Guajira
		Danzon
		Guitar Rumba
		Cuban Son
	Mexico	Mariachi Waltz
		Norteno
		Bolero Lento
	Caribbean	Sheriff Reggae
		Merengue
		Happy Reggae
		Cumbia
		Bomba
		Bachata
		Zouk
		Rumba Island
		European
	Sirtaki	
	Pop Flamenco	
	Tarantella	
	Spanish Paso	
	Italian Mazurka	
	Rumba Flamenco	
	Latin Pop	Latin Party Pop
		Pop Bossa
		Pop Latin
		Pop Latin Ballad
		Latin Disco
		Rock Cha Cha
	Celtic	Jig
		Celtic Dance
		Reel
		Irish Dance
		Irish Hymn 1
	Irish Hymn 2	
	World	Turkish Euro
		J-Pop Hit 1
		Oriental Pop
		J-Pop Hit 2
		Hawaiian
	Classic	Choral Symphony
		Ethereal Hymn
		Romantic Ballet
		Ethereal Voices
		Green Fantasia
		Baroque Air
		String Adagio
		Moonlight 6-8
		Nocturne
		Learning 2-4
Orchestral March		
Orchestral Bolero		
Traditional 1		
Arpeggio 1		
Traditional 2		
Arpeggio 2		
Traditional 3		
Arpeggio 3		
Trad Waltz	Highland Waltz	
	Scand Waltz	
	French Waltz	
	Ober Walzer	

Category	Sub Category	Style Name
Latin&World	Trad Waltz	Italian Waltz
		German Waltz
		French Musette
		Bohemian Waltz
		Waltz
		Piano Slow Waltz
	March&Polka	US March
		Ober Polka
		German March
		Italian Polka
		6-8 March
		Zither Polka
		Piano March 1
		Piano March 2
4 Stroke		
6-8 Piano March		

Chord Types Recognized in the Fingered Mode / Im Fingered-Modus erkannte Akkordarten / Types d'accords reconnus en mode Fingered / Tipos de acordes reconocidos en el modo Fingered (digitado) / Tipos de acorde reconhecidos no modo dedilhado



Chord Name [Abbreviation]	Normal Voicing	Display for root "C"
1+8	1+8	C1+8
1+5	1+5	C1+5
Major [M]	1+3+5	C
Sixth [6]	1+(3)+5+6	C6
Major seventh [M7]	1+3+(5)+7	CM7
Major seventh flatted fifth [M7 b 5]	1+3+ b 5+7	CM7(b 5)
Major seventh add sharp eleventh [M7(# 11)]	1+(2)+3+ # 4+5+7	CM7(# 11)
Add ninth [(add9)]	1+2+3+5	Cadd9
Major seventh ninth [M7_9]	1+2+3+(5)+7	CM7(9)
Sixth ninth [6_9]	1+2+3+(5)+6	C6(9)
Flatted fifth [(b 5)]	1+3+ b 5	C b 5
Augmented [aug]	1+3+ # 5	Caug
Seventh augmented [7aug]	1+3+ # 5+ b 7	C7aug
Major seventh augmented [M7aug]	1+(3)+ # 5+7	CM7aug
Minor [m]	1+ b 3+5	Cm
Minor sixth [m6]	1+ b 3+5+6	Cm6
Minor seventh [m7]	1+ b 3+(5)+ b 7	Cm7
Minor seventh flatted fifth [m7 b 5]	1+ b 3+ b 5+ b 7	Cm7(b 5)
Minor add ninth [m(add9)]	1+2+ b 3+5	Cm add9
Minor seventh ninth [m7(9)]	1+2+ b 3+(5)+ b 7	Cm7(9)
Minor seventh eleventh [m7(11)]	1+(2)+ b 3+4+5+(b 7)	Cm7(11)
Minor major seventh flatted fifth [mM7 b 5]	1+ b 3+ b 5+7	CmM7(b 5)
Minor major seventh [mM7]	1+ b 3+(5)+7	CmM7
Minor major seventh ninth [mM7(9)]	1+2+ b 3+(5)+7	CmM7(9)
Diminished [dim]	1+ b 3+ b 5	Cdim
Diminished seventh [dim7]	1+ b 3+ b 5+6	Cdim7
Seventh [7]	1+3+(5)+ b 7	C7
Seventh suspended fourth [7sus4]	1+4+5+ b 7	C7sus4
Seventh ninth [7(9)]	1+2+3+(5)+ b 7	C7(9)
Seventh add sharp eleventh [7(# 11)]	1+(2)+3+ # 4+5+ b 7	C7(# 11)
Seventh add thirteenth [7(13)]	1+3+(5)+6+ b 7	C7(13)
Seventh flatted fifth [7 b 5]	1+3+ b 5+ b 7	C7(b 5)
Seventh flatted ninth [7(b 9)]	1+ b 2+3+(5)+ b 7	C7(b 9)
Seventh add flatted thirteenth [7(b 13)]	1+3+5+ b 6+ b 7	C7(b 13)
Seventh sharp ninth [7(# 9)]	1+ # 2+3+(5)+ b 7	C7(# 9)
Suspended fourth [sus4]	1+4+5	Csus4
One plus two plus five [sus2]	1+2+5	Csus2
cancel	1+ b 2+2	Cancel

* Notes in parentheses can be omitted.

Effect Type List / Liste der Effekttypen / Liste des types d'effet / Lista de tipos de efecto / Lista de tipos de efeito

Reverb Block

Category	Type Name	Description	MSB	LSB	
Reverb	Real Large Hall	Real reverb simulating the acoustics of a large sized hall.	1	32	
	Real Medium Hall	Real reverb simulating the acoustics of a medium sized hall.	1	33	
	Real Bright Hall	Real reverb simulating the acoustics of a bright sounding hall.	1	34	
	Basic Hall	Reverb simulating the acoustics of a hall. Standard setting.	1	21	
	Light Hall	Reverb simulating the acoustics of a hall. Light setting.	1	22	
	Ballad Hall	Reverb simulating the acoustics of a hall. For ballad type music.	1	19	
	Piano Hall	Reverb simulating the acoustics of a hall. For piano sound.	1	20	
	Hall 1	Reverb simulating the acoustics of a hall.	1	0	
	Hall 2		1	16	
	Hall 3		1	17	
	Hall 4		1	18	
	Hall 5		1	1	
	Vocal Hall 1	Reverb suitable for vocals.	1	27	
	Vocal Hall 2		1	28	
	Piano Recital Hall	Reverb simulating the acoustics of a medium sized recital hall. For piano sound.	1	24	
	Piano Concert Hall	Reverb simulating the acoustics of a large sized hall. For piano sound.	1	4	
	Piano Cathedral	Reverb simulating the acoustics of a cathedral. For piano sound.	1	5	
	Real Room	Real reverb simulating the acoustics of a room.	2	32	
	Real Power Room	Real reverb simulating the acoustics of a room with powerful room reflections.	2	33	
	Acoustic Room	Reverb simulating the acoustics of a room. Standard setting.	2	20	
	Drums Room	Reverb simulating the acoustics of a room. For drum sounds.	2	21	
	Piano Chamber	Reverb simulating the acoustics of a chamber. For piano sound.	2	24	
	Stage	Reverb suitable for a solo instrument.	3	16	
	Piano Club	Reverb simulating the acoustics of a club. For piano sound.	3	24	
	Real Large Plate	Real reverb simulating a large plate reverb unit.	4	32	
	Real Medium Plate	Real reverb simulating a medium sized plate reverb unit.	4	33	
	Real Rattle Plate	Real reverb simulating a plate reverb unit with spring rattle.	4	34	
	Plate	Reverb simulating a plate reverb unit.	4	16	
	Piano Plate	Reverb simulating a plate reverb unit. For piano sound.	4	24	
	Hall M	Reverb simulating the acoustics of a hall.	1	6	
	Hall L		1	7	
	Atmosphere Hall	A unique long reverb with atmosphere.	1	23	
	Large Hall	Reverb simulating the acoustics of a hall.	1	2	
	Medium Hall		1	3	
	Percussion Room		2	22	
	Room 1	Reverb simulating the acoustics of a room.	2	16	
	Room 2		2	17	
	Room 3		2	18	
	Room 4		2	19	
	Room 5		2	0	
	Room 6		2	1	
	Room 7		2	2	
	Room S		2	5	
	Room M		2	6	
	Room L		2	7	
	Warm Room		Reverb simulating the acoustics of a warm room.	2	3
	White Room		A unique short reverb with a bit of initial delay.	16	0
	Woody Room		Reverb simulating the acoustics of a wood-built room.	2	4
	Stage 2	Reverb suitable for a solo instrument.	3	17	
	Stage 3		3	0	
	Stage 4		3	1	
	Plate 2	Reverb simulating a plate reverb unit.	4	17	
	Plate 3		4	0	
	GM Plate		4	7	
	Rich Plate		4	1	
Tunnel	Simulates a cylindrical space expanding to left and right.	17	0		
Canyon	A hypothetical acoustic space which extends without limit.	18	0		
Basement	A bit of initial delay followed by reverb with a unique resonance.	19	0		
---	No Effect	No effect.	0	0	

Chorus Block

Category	Type Name	Description	MSB	LSB
Reverb	Hall 1	Reverb simulating the acoustics of a hall.	1	0
	Hall 2		1	16
	Hall 3		1	17
	Hall 4		1	18
	Hall 5		1	1
	Acoustic Room	Reverb simulating the acoustics of a room. Standard setting.	2	20
	Drums Room	Reverb simulating the acoustics of a room. For drum sounds.	2	21
	Stage	Reverb suitable for a solo instrument.	3	16
Plate	Reverb simulating a plate reverb unit.	4	16	
Delay	Tempo Delay 1	Tempo-synchronized delay.	21	0
	Tempo Delay 2		21	16
	Tempo Echo	Tempo-synchronized echo.	21	8
	Tempo Cross 1	Tempo-synchronized cross delay.	22	0
	Tempo Cross 2		22	16
	Tempo Cross 3		22	17
	Tempo Cross 4		22	18
Modulation	Chorus 1	Conventional chorus program with rich, warm chorusing.	66	17
	Chorus 2		66	8
	Symphonic	Adds more stages to the modulation of Celeste.	68	16
	Flanger	Creates a sound similar to that of a jet airplane.	67	8
	Tempo Flanger	Tempo-synchronized flanger.	107	0
	Phaser	Cyclically modulates the phase to add modulation to the sound.	72	0
	Tempo Phaser	Tempo-synchronized phaser.	108	0
	E-Piano Phaser	Cyclically modulates the phase to add modulation to the sound. For electric piano.	72	17
	Dual Rotary Speaker Bright	Simulates a rotary speaker.	99	16
	Dual Rotary Speaker Warm		99	17
	Rotary Speaker		69	16
	Tremolo	Rich Tremolo effect with both volume and pitch modulation.	70	16
	E-Piano Tremolo		70	18
	Tempo Tremolo	Tempo-synchronized rich Tremolo effect with both volume and pitch modulation.	120	0
	Auto Pan	Several panning effects that automatically shift the sound position (left, right, front, back).	71	16
Tempo Auto Pan	Tempo-synchronized auto pan.	121	0	
Legacy	Hall M	Reverb simulating the acoustics of a hall.	1	6
	Hall L		1	7
	Atmosphere Hall	A unique long reverb with atmosphere.	1	23
	Percussion Room	Reverb simulating the acoustics of a room. For percussion sounds.	2	22
	Room 1	Reverb simulating the acoustics of a room.	2	16
	Room 2		2	17
	Room 3		2	18
	Room 4		2	19
	Room 5		2	0
	Room 6		2	1
	Room 7		2	2
	Room S		2	5
	Room M		2	6
	Room L	2	7	
	Stage 2	Reverb suitable for a solo instrument.	3	17
	Stage 3		3	0
	Stage 4		3	1
	Plate 2	Reverb simulating a plate reverb unit.	4	17
	Plate 3		4	0
	GM Plate		4	7
	Karaoke 1	Echo for karaoke.	20	0
	Karaoke 2		20	1
	Karaoke 3		20	2
	Early Reflection 1	This effect isolates only the early reflection components of the reverb.	9	0
	Early Reflection 2		9	1
	Chorus 3	Conventional chorus program with rich, warm chorusing.	66	16
	Chorus 4		66	1
	Chorus 5		65	2
	Chorus 6		65	0
	Chorus 7		65	1
Chorus 8	65		8	

Chorus Block

Category	Type Name	Description	MSB	LSB
Legacy	Chorus Fast	Conventional chorus program with rich, warm chorusing.	65	16
	Chorus Lite		65	17
	GM Chorus 1		65	3
	GM Chorus 2		65	4
	GM Chorus 3		65	5
	GM Chorus 4		65	6
	Feedback Chorus		65	7
	Celeste 1	A 3-phase LFO adds modulation and spaciousness to the sound.	66	0
	Celeste 2		66	2
	Symphonic 2	Adds more stages to the modulation of Celeste.	68	0
	Ensemble Detune 1	Chorus effect without modulation, created by adding a slightly pitch-shifted sound.	87	0
	Ensemble Detune 2		87	16
	Flanger 2	Creates a sound similar to that of a jet airplane.	67	16
	Flanger 3		67	17
	Flanger 4		67	1
	Flanger 5		67	0
	GM Flanger		67	7
	Phaser 2		Cyclically modulates the phase to add modulation to the sound.	72
	Phaser 3	72		19
	Tempo Phaser 2	Tempo-synchronized phaser.	108	16
	E-Piano Phaser 2	Cyclically modulates the phase to add modulation to the sound. For electric piano.	72	18
	E-Piano Phaser 3		72	16
	Dual Rotary Speaker 1	Simulates a rotary speaker.	99	0
	Dual Rotary Speaker 2		99	1
	Rotary Speaker 2		71	17
	Rotary Speaker 3		71	18
	Rotary Speaker 4		70	17
	Rotary Speaker 5		66	18
	Rotary Speaker 6		69	0
	Rotary Speaker 7		71	22
	2way Rotary Speaker		86	0
	Tremolo 2	Rich Tremolo effect with both volume and pitch modulation.	71	19
	Tremolo 3		70	0
	Guitar Tremolo 1		71	20
	Guitar Tremolo 2		70	19
	Vibraphone Rotor	Vibraphone effect.	119	0
	Auto Pan 2	Several panning effects that automatically shift the sound position (left, right, front, back).	71	0
	Auto Pan 3		71	1
	E-Piano Auto Pan		71	21
	Tempo Auto Pan 2	Tempo-synchronized auto pan.	121	1
Pitch Change 1	Changes the pitch of the input signal.	80	16	
Pitch Change 2		80	0	
Pitch Change 3		80	1	
---	No Effect	No effect.	0	0

Effect Block

CVP-709	CVP-705	XG Block Name
●	●	XG Variation Block
●	●	XG Insertion1 Block
●	●	XG Insertion2 Block
●	●	XG Insertion3 Block
●		XG Insertion4 Block
●		XG Insertion5 Block
●		XG Insertion6 Block (only for MIC & Song)
●		XG Insertion7 Block (only for Style)
●		XG Insertion8 Block (only for Style)

Category	Type Name	Description	MSB	LSB
Reverb	Hall 1	Reverb simulating the acoustics of a hall.	1	0
	Hall 2		1	16
	Hall 3		1	17
	Hall 4		1	18
	Hall 5		1	1
	Acoustic Room	Reverb simulating the acoustics of a room. Standard setting.	2	20
	Drums Room	Reverb simulating the acoustics of a room. For drum sounds.	2	21
	Stage	Reverb suitable for a solo instrument.	3	16
Plate	Reverb simulating a plate reverb unit.	4	16	
Delay	Delay LCR 1	Produces three delayed sounds: L, R and C (center).	5	16
	Delay LCR 2		5	0
	Delay LR	Produces two delayed sounds: L and R. Two feedback delays are provided.	6	0
	Echo	Two delayed sounds (L and R), and independent feedback delays for L and R.	7	0
	Cross Delay 1	The feedback of the two delayed sounds is crossed.	8	0
	Cross Delay 2		8	16
	Tempo Delay 1	Tempo-synchronized delay.	21	0
	Tempo Delay 2		21	16
	Tempo Echo	Tempo-synchronized echo.	21	8
	Tempo Cross 1	Tempo-synchronized cross delay.	22	0
	Tempo Cross 2		22	16
	Tempo Cross 3		22	17
Tempo Cross 4	22		18	
Distortion	US Combo Twin	American combo amp simulator. Setting for typical sound.	99	32
	US Combo Rich Clean	American combo amp simulator. Setting for rich clean sound.	99	33
	US Combo Thin Clean	American combo amp simulator. Setting for thin clean sound.	99	34
	US Combo Crunch	American combo amp simulator. Setting for crunch sound.	99	35
	Jazz Combo Basic	Jazz combo amp simulator. Setting for basic sound.	100	32
	Jazz Combo Warm Chorus	Jazz combo amp simulator. Setting for warm chorus sound.	100	33
	US High Gain Dirty	American high gain amp simulator. Setting for dirty sound.	101	32
	US High Gain Riff	American high gain amp simulator. Setting for guitar riffs.	101	33
	US High Gain Burn	American high gain amp simulator. Setting for burn sound.	101	34
	US High Gain Solo	American high gain amp simulator. Setting for guitar solos.	101	35
	British Lead Dirty	British stack amp simulator. Setting for dirty sound.	102	32
	British Lead Drive	British stack amp simulator. Setting for overdrive sound.	102	33
	British Lead Gainer	British stack amp simulator. Setting for gainer sound.	102	34
	British Lead Hard	British stack amp simulator. Setting for hard sound.	102	35
	Multi FX Distortion Solo	Multi effector for guitar. Setting for guitar solo.	95	32
	Multi FX Distortion Basic	Multi effector for guitar. Setting for basic distortion.	95	33
	Multi FX Overdrive Chorus	Multi effector for guitar. Setting for overdrive & chorus.	95	34
	Multi FX Crunch Wah	Multi effector for guitar. Setting for crunch & wah.	95	35
	Multi FX Oldies Delay	Multi effector for guitar. Setting for vintage delay.	95	36
	Multi FX Vintage Echo	Multi effector for guitar. Setting for vintage echo.	95	37
	Small Stereo Distortion	Stereo distortion for guitar. Setting for distortion sound.	96	32
	Small Stereo Overdrive	Stereo distortion for guitar. Setting for overdrive sound.	96	33
	Small Stereo Vintage Amp	Stereo distortion for guitar. Setting for vintage sound.	96	34
	Small Stereo Heavy Dist	Stereo distortion for guitar. Setting for heavy sound.	96	35
	British Combo Classic	British combo amp simulator. Setting for classic sound.	97	32
	British Combo Top Boost	British combo amp simulator. Setting for "TOP BOOST" sound.	97	33
	British Combo Custom	British combo amp simulator. Setting for custom sound.	97	34
	British Combo Heavy	British combo amp simulator. Setting for heavy sound.	97	35
	British Legend Blues	British stack amp simulator. Setting for blues sound.	98	32

Effect Block

Category	Type Name	Description	MSB	LSB	
Distortion	British Legend Heavy1	British stack amp simulator. Setting for heavy sound 1.	98	33	
	British Legend Heavy2	British stack amp simulator. Setting for heavy sound 2.	98	34	
	British Legend Clean	British stack amp simulator. Setting for clean sound.	98	35	
	British Legend Dirty Clean	British stack amp simulator. Setting for crunch sound.	98	36	
	V Distortion Crunch	Distortion which simulates the sound of a vintage tube, fuzz effect, etc.	98	18	
	V Distortion Blues		98	21	
	Stereo Amp Sim Solid	Stereo amp simulator.	75	29	
	Stereo Amp Sim Crunch		75	30	
	Stereo Amp Sim Blues		75	28	
V Distortion Hard + Delay	V Distortion Hard and Delay are connected in series.	98	1		
EQ & Comp	Vintage Compressor	This simulates an analog compressor, giving a vintage flavor to the sound.	124	4	
	Compressor Medium	Compressor with medium setting.	83	16	
	Compressor Heavy	Compressor with heavy setting.	83	17	
	Compressor Melody	Compressor for the Melody part.	105	16	
	Compressor Bass	Compressor for the Bass part.	105	17	
	EQ Telephone	Equalizer effect that cuts both high and low frequencies, to simulate the sound heard through a telephone receiver.	76	17	
	3Band EQ	A mono EQ with adjustable LOW, MID, and HIGH equalization.	76	0	
	Loop FX 1	Degrades the audio quality of the input signal. Ideal for drum sounds.	94	16	
	Loop FX 2		94	17	
	Lo-Fi Drum 1		94	18	
	Lo-Fi Drum 2		94	19	
	Lo-Fi Drum 3		76	19	
Lo-Fi Drum 4	76		20		
Modulation	Chorus 1		Conventional chorus program with rich, warm chorusing.	66	17
	Chorus 2			66	8
	Symphonic	Adds more stages to the modulation of Celeste.	68	16	
	Vintage Flanger	This simulates an analog flanger, giving a strong vintage flavor to the sound.	124	1	
	Flanger	Creates a sound similar to that of a jet airplane.	67	8	
	V Flanger	A simulation of an analog flanger effect. The LFO has a random setting.	104	0	
	Tempo Flanger	Tempo-synchronized flanger.	107	0	
	Vintage Phaser	This simulates an analog phaser, giving a strong vintage flavor to the sound. It is effective in mono.	124	2	
	Vintage Phaser Stereo	This simulates an analog phaser, giving a strong vintage flavor to the sound. It is effective in stereo.	124	3	
	Phaser	Cyclically modulates the phase to add modulation to the sound.	72	0	
	Tempo Phaser	Tempo-synchronized phaser.	108	0	
	E-Piano Phaser	Cyclically modulates the phase to add modulation to the sound. For electric piano.	72	17	
	Vintage Auto Wah	This simulates an analog wah pedal effect, giving a strong vintage flavor to the sound. It cyclically changes the central frequency of the wah filter.	124	5	
	Auto Wah	Cyclically modulates the center frequency of a wah filter.	78	16	
	Auto Wah + Distortion	Distortion can be applied to the output of Auto Wah.	78	17	
	Tempo Auto Wah	Tempo-synchronized Auto Wah.	79	0	
	Vintage Touch Wah	This simulates an analog wah pedal effect, giving a strong vintage flavor to the sound. It changes the central frequency of the wah filter according to the input level.	125	2	
	Touch Wah	Changes the center frequency of a wah filter according to the input level.	82	0	
	Touch Wah + Distortion	Distortion can be applied to the output of Touch Wah.	82	16	
	Vintage Pedal Wah Basic	Vintage Wah which can be controlled by "Pedal Control" parameter. (See Effect Parameter List.)	125	1	
	Vintage Pedal Wah Disco		125	16	
	Pedal Wah	Changes the center frequency of a wah filter according to "Pedal Control" parameter. (See Effect Parameter List.)	122	0	
	Pedal Wah + Distortion	Distortion can be applied to the output of Pedal Wah.	122	1	
	Dual Rotary Speaker Bright	Simulates a rotary speaker.	99	16	
	Dual Rotary Speaker Warm		99	17	
	Rotary Speaker		69	16	
	Tremolo	Rich Tremolo effect with both volume and pitch modulation.	70	16	
	E-Piano Tremolo		70	18	
	Tempo Tremolo		120	0	
	Auto Pan	Several panning effects that automatically shift the sound position (left, right, front, back).	71	16	
	Tempo Auto Pan	Tempo-synchronized auto pan.	121	0	
	Legacy	Hall M	Reverb simulating the acoustics of a hall.	1	6
Hall L		1		7	
Atmosphere Hall		A unique long reverb with atmosphere.	1	23	
Percussion Room		Reverb simulating the acoustics of a room. For percussion sounds.	2	22	

Effect Block

Category	Type Name	Description	MSB	LSB
Legacy	Room 1	Reverb simulating the acoustics of a room.	2	16
	Room 2		2	17
	Room 3		2	18
	Room 4		2	19
	Room 5		2	0
	Room 6		2	1
	Room 7		2	2
	Room S		2	5
	Room M		2	6
	Room L		2	7
	White Room	A unique short reverb with a bit of initial delay.	16	0
	Stage 2	Reverb suitable for a solo instrument.	3	17
	Stage 3		3	0
	Stage 4		3	1
	Plate 2	Reverb simulating a plate reverb unit.	4	17
	Plate 3		4	0
	GM Plate		4	7
	Tunnel	Simulates a cylindrical space expanding to left and right.	17	0
	Canyon	A hypothetical acoustic space which extends without limit.	18	0
	Basement	A bit of initial delay followed by reverb with a unique resonance.	19	0
	Karaoke 1	Echo for karaoke.	20	0
	Karaoke 2		20	1
	Karaoke 3		20	2
	Early Reflection 1	This effect isolates only the early reflection components of the reverb.	9	0
	Early Reflection 2		9	1
	Gate Reverb 1	Simulation of gated reverb.	10	0
	Gate Reverb 2		10	16
	Reverse Gate	Simulation of gated reverb played back in reverse.	11	0
	V Distortion Warm	Distortion which simulates the sound of a vintage tube, fuzz effect, etc.	98	22
	V Distortion Classic Hard		98	23
	V Distortion Classic Soft		98	20
	V Distortion Metal		98	24
	V Distortion Edgy		98	19
	V Distortion Solid		98	25
	V Distortion Clean 1		98	17
	V Distortion Clean 2		98	26
	V Distortion Twin		98	16
	V Distortion Rockabilly		103	18
	V Distortion Jazz Clean		98	27
	V Distortion Fusion		103	19
	V Distortion Hard		98	0
	V Distortion Soft		98	2
	Stereo Amp Sim Clean		Stereo amp simulator.	75
	Stereo Amp Sim BluesHarp	75		31
	Distortion Hard 1	Hard-edge distortion.	75	16
	Distortion Hard 2		75	22
	Distortion Soft 1	Soft, warm distortion.	75	17
	Distortion Soft 2		75	23
	Distortion Heavy	Heavy distortion.	73	0
	Overdrive	Adds mild distortion to the sound.	74	0
	Stereo Distortion	Stereo distortion.	73	8
	Stereo Overdrive	Stereo overdrive.	74	8
	Stereo Distortion Hard	Hard-edge stereo distortion.	75	18
Stereo Distortion Soft	Soft, warm soft distortion.	75	19	
Amp Simulator 1	A simulation of a guitar amp.	75	0	
Amp Simulator 2		75	1	
Stereo Amp Simulator 1	Stereo amp simulator.	75	20	
Stereo Amp Simulator 2		75	21	
Stereo Amp Simulator 3		75	8	
Stereo Amp Simulator 4		75	24	
Stereo Amp Simulator 5		75	25	
Stereo Amp Simulator 6		75	26	

Effect Block

Category	Type Name	Description	MSB	LSB	
Legacy	Distortion + Delay 1	Distortion and Delay are connected in series.	95	16	
	Distortion + Delay 2		95	0	
	Overdrive + Delay 1	Overdrive and Delay are connected in series.	95	17	
	Overdrive + Delay 2		95	1	
	Comp + Dist + Delay 1	Compressor, Distortion and Delay are connected in series.	96	16	
	Comp + Dist + Delay 2		96	0	
	Comp + OD + Delay 1	Compressor, Overdrive and Delay are connected in series.	96	17	
	Comp + OD + Delay 2		96	1	
	V Distortion Soft + Delay	V Distortion Soft and Delay are connected in series.	98	3	
	V Dist Hard + Tmp Delay 1	V Distortion Hard and Tempo Delay are connected in series.	103	0	
	V Dist Hard + Tmp Delay 2		103	17	
	V Dist Soft + Tmp Delay 1	V Distortion Soft and Tempo Delay are connected in series.	103	1	
	V Dist Soft + Tmp Delay 2		103	16	
	Distortion + Tempo Delay	Distortion and Tempo Delay are connected in series.	100	0	
	Overdrive + Tempo Delay	Overdrive and Tempo Delay are connected in series.	100	1	
	Comp + Distortion 1	Since a Compressor is included in the first stage, steady distortion can be produced regardless of changes in input level.	73	16	
	Comp + Distortion 2		73	1	
	Comp + Dist + Tmp Delay	Compressor, Distortion and Tempo Delay are connected in series.	101	0	
	Comp + OD + Tmp Delay 1	Compressor, Overdrive and Tempo Delay are connected in series.	101	1	
	Comp + OD + Tmp Delay 2		101	16	
	Comp + OD + Tmp Delay 3		101	17	
	Comp + OD + Tmp Delay 4		101	18	
	Comp + OD + Tmp Delay 5		101	19	
	Comp + OD + Tmp Delay 6		101	20	
	Multiband Compressor		Multi-band compressor that allows you to adjust the compression effect for individual frequency bands.	105	0
	Compressor	Holds down the output level when a specified input level is exceeded. A sense of attack can also be added to the sound.	83	0	
	Noise Gate	Gates the input when the input signal falls below a specified level.	84	0	
	EQ Disco	Equalizer effect that boosts both high and low frequencies, as is typical in most disco music.	76	16	
	2Band EQ	A stereo EQ with adjustable LOW and HIGH. Ideal for drum Parts.	77	0	
	Stereo 3Band EQ	A stereo EQ with adjustable LOW, MID, and HIGH equalization.	76	18	
	Harmonic Enhancer 1	Adds new harmonics to the input signal to make the sound stand out.	81	16	
	Harmonic Enhancer 2		81	0	
	Isolator	Controls the level of a specified frequency band of the input signal.	115	0	
	Chorus 3	Conventional chorus program with rich, warm chorusing.	66	16	
	Chorus 4		66	1	
	Chorus 5		65	2	
	Chorus 6		65	0	
	Chorus 7		65	1	
	Chorus 8		65	8	
	Chorus Fast		65	16	
	Chorus Lite		65	17	
	GM Chorus 1		65	3	
	GM Chorus 2		65	4	
	GM Chorus 3		65	5	
	GM Chorus 4		65	6	
	Feedback Chorus		65	7	
	Celeste 1		A 3-phase LFO adds modulation and spaciousness to the sound.	66	0
	Celeste 2			66	2
	Symphonic 2		Adds more stages to the modulation of Celeste.	68	0
	Ensemble Detune 1	Chorus effect without modulation, created by adding a slightly pitch-shifted sound.	87	0	
	Ensemble Detune 2		87	16	
	Ambience Chorus	Chorus which added early reflection sound.	65	9	
	Ambience Celeste	Celeste which added early reflection sound.	66	9	
Ambience Symphonic	Symphonic which added early reflection sound.	68	9		
Vintage Flanger 2	This simulates an analog flanger, giving a strong vintage flavor to the sound.	124	16		
Flanger 2	Creates a sound similar to that of a jet airplane.	67	16		
Flanger 3		67	17		
Flanger 4		67	1		
Flanger 5		67	0		
GM Flanger		67	7		
Dynamic Flanger		Dynamically controlled flanger.	110	0	

Effect Block

Category	Type Name	Description	MSB	LSB
Legacy	Ambience Flanger	Flanger which added early reflection sound.	67	9
	Vintage Phaser 2	This simulates an analog phaser, giving a strong vintage flavor to the sound. It is effective in mono.	124	17
	Vintage Phaser Stereo 2	This simulates an analog phaser, giving a strong vintage flavor to the sound. It is effective in stereo.	124	18
	Vintage Phaser Stereo 3		124	19
	Vintage Phaser Stereo 4		124	20
	Phaser 2		Cyclically modulates the phase to add modulation to the sound.	72
	Phaser 3	72		19
	Tempo Phaser 2	Tempo-synchronized phaser.	108	16
	E-Piano Phaser 2	Cyclically modulates the phase to add modulation to the sound. For electric piano.	72	18
	E-Piano Phaser 3		72	16
	Dynamic Phaser	Dynamically controlled phaser.	111	0
	Auto Wah 2	Cyclically modulates the center frequency of a wah filter.	78	0
	Auto Wah + Distortion 2	Distortion can be applied to the output of Auto Wah.	78	1
	Auto Wah + Dist Hard		78	21
	Auto Wah + Dist Heavy		78	23
	Auto Wah + Dist Lite		78	25
	Auto Wah + Overdrive 1	Overdrive distortion can be applied to the output of Auto Wah.	78	18
	Auto Wah + Overdrive 2		78	2
	Auto Wah + OD Hard		78	22
	Auto Wah + OD Heavy		78	24
	Auto Wah + OD Lite		78	26
	Tmp AutoWah + Dist		Tempo-synchronized Auto Wah. Distortion can be applied to the output.	79
	Tmp AutoWah + Dist Hard	79		21
	Tmp AutoWah + Dist Heavy	79		23
	Tmp AutoWah + Dist Lite	79		25
	Tmp AutoWah + OD	Tempo-synchronized Auto Wah. Overdrive distortion can be applied to the output.	79	2
	Tmp AutoWah + OD Hard		79	22
	Tmp AutoWah + OD Heavy		79	24
	Tmp AutoWah + OD Lite		79	26
	Touch Wah 2	Changes the center frequency of a wah filter according to the input level.	82	8
	Touch Wah 3		82	20
	Touch Wah + Distortion 2	Distortion can be applied to the output of Touch Wah.	82	1
	Touch Wah + Dist Hard		82	21
	Touch Wah + Dist Heavy		82	23
	Touch Wah + Dist Lite		82	25
	Touch Wah + Overdrive 1	Overdrive distortion can be applied to the output of Touch Wah.	82	17
	Touch Wah + Overdrive 2		82	2
	Touch Wah + OD Hard		82	22
	Touch Wah + OD Heavy		82	24
	Touch Wah + OD Lite		82	26
	Wah + Dist + Delay 1		Wah, Distortion and Delay are connected in series.	97
	Wah + Dist + Delay 2	97		0
	Wah + Dist + Tmp Delay	Wah, Distortion and Tempo Delay are connected in series.	102	0
	Wah + Overdrive + Delay 1	Wah, Overdrive and Delay are connected in series.	97	17
	Wah + Overdrive + Delay 2		97	1
	Wah + OD + Tmp Delay 1	Wah, Overdrive and Tempo Delay are connected in series.	102	1
	Wah + OD + Tmp Delay 2		102	16
	Clavi Touch Wah	Clavinet Touch Wah	82	18
	EP Touch Wah	EP Touch Wah	82	19
	Pedal Wah + Dist Hard	Distortion can be applied to the output of Pedal Wah.	122	21
	Pedal Wah + Dist Heavy		122	23
	Pedal Wah + Dist Lite		122	25
Pedal Wah + Overdrive	Overdrive distortion can be applied to the output of Pedal Wah.		122	2
Pedal Wah + OD Hard		122	22	
Pedal Wah + OD Heavy		122	24	
Pedal Wah + OD Lite		122	26	
Dual Rotary Speaker 1		Simulates a rotary speaker.	99	0
Dual Rotary Speaker 2			99	1
Rotary Speaker 2	71		17	
Rotary Speaker 3	71		18	
Rotary Speaker 4	70		17	
Rotary Speaker 5	66		18	

Category	Type Name	Description	MSB	LSB
Legacy	Rotary Speaker 6	Simulates a rotary speaker.	69	0
	Rotary Speaker 7		71	22
	2way Rotary Speaker		86	0
	Dist + Rotary SP	Distortion and rotary speaker connected in series.	69	1
	Dist + 2way Rotary SP	Distortion and 2-way rotary speaker connected in series.	86	1
	OD + Rotary SP	Overdrive and rotary speaker connected in series.	69	2
	OD + 2way Rotary SP	Overdrive and 2-way rotary speaker connected in series.	86	2
	Amp Sim + Rotary SP	Amp simulator and rotary speaker connected in series.	69	3
	Amp Sim + 2way Rotary SP	Amp simulator and 2-way rotary speaker connected in series.	86	3
	Tremolo 2	Rich Tremolo effect with both volume and pitch modulation.	71	19
	Tremolo 3		70	0
	Guitar Tremolo 1		71	20
	Guitar Tremolo 2		70	19
	Vibraphone Rotor	Vibraphone effect.	119	0
	Auto Pan 2	Several panning effects that automatically shift the sound position (left, right, front, back).	71	0
	Auto Pan 3		71	1
	E-Piano Auto Pan		71	21
	Tempo Auto Pan 2	Tempo-synchronized auto pan.	121	1
	Pitch Change 1	Changes the pitch of the input signal.	80	16
	Pitch Change 2		80	0
	Pitch Change 3		80	1
	Voice Cancel	Attenuates the vocal part of a CD or other source.	85	0
	Ambience	Blurs the stereo positioning of the sound to add spatial width.	88	0
	Talking Modulation	Adds a vowel sound to the input signal.	93	0
	Lo-Fi	Degrades the audio quality of the input signal.	94	0
	Dynamic Filter	Dynamically controlled filter.	109	0
	Dynamic Ring Modulator	Dynamically controlled Ring Modulator.	112	0
Ring Modulator	An effect that modifies the pitch by applying amplitude modulation to the frequency of the input.	113	0	
---	No Effect	No effect.	0	0
---	Through	Bypass without applying an effect.	64	0

Vocal Harmony Type List / Liste der Vocal-Harmony-Typen / Liste des types d'harmonies vocales / Lista de tipos de armonías vocales / Lista de tipos de harmonia vocal

Type Name	MSB	LSB	Vocal Harmony	Vocal Effect	Description
StandardDuet	12	0	On	Off	Standard setting for lead vocal plus 1 harmony part. Useful for many music genres.
StandardTrio	12	1	On	Off	Standard setting for lead vocal plus 2 harmony parts. Useful for many music genres.
StandardQuartet	12	2	On	Off	Standard setting for lead vocal plus 3 harmony parts. Useful for many music genres.
StudioVocals	12	33	On	On	Good for studio productions with suitable EQ setting and less Reverb.
JazzyQuartet	12	3	On	Off	Good for Bass, Tenor and Alto singers; for Jazz repertoire. You will hear additional 6th notes.
SchlagerTrio	12	4	On	On	Good for standard Schlager repertoire with simple harmony chords.
Destiny'sPop	12	5	On	On	Good for female singers with lead vocal plus 2 harmony parts above; for female Pop and R&B repertoire.
VocalDoublor	12	34	Off	On	Use this preset to overdub your singing in real time. Turn the "Harmony" on the Vocal Harmony display on to add harmony parts with Vocal Doublor effect.
VocoderVH	12	6	On	Off	Standard vocoder setting; ideal for controlling with "UPPER" part.
VocoderMONO	12	7	On	Off	Standard vocoder setting; ideal for controlling with "UPPER" part. You can play mono (single-note) melodies.
Rock&Roll	12	35	Off	On	Good for Rock&Roll songs from the 50's and 60's with typical delay sound. Turn the "Harmony" on the Vocal Harmony display on to add harmony parts with Blues chords.
TempoCross	12	36	Off	On	Tempo Cross Delay on lead vocal. Turn the "Harmony" on the Vocal Harmony display on to add harmony parts; good for Pop songs or special show effects.
HeavyVoice	12	37	Off	On	Good for Rock and Pop with overdriven vocal. Turn the "Harmony" on the Vocal Harmony display on to add Harm.1 with 1 octave down.
TelephoneChoir	12	38	On	On	Typical Lo-Fi vocal ensemble; use as old fashioned ensemble sound or exciting effect in Rock, Pop and Jazz.
LikeThe80s	12	39	On	On	Good for 80's Pop with typical reverb image.
Gramophone	12	40	On	On	Typical 30's vocal ensemble; use as old fashioned gramophone sound.
PokerPhaser	12	41	On	On	Good for modern Pop songs using phaser effect for lead vocal.
DetuneVoice	12	8	On	Off	Lead vocal plus two additional detuned harmony parts for exciting detuned sound.
PerfectFourth	12	9	On	On	Quartet singing only perfect fourths; parallel movement of all parts.
SingCMajorScale	12	10	On	Off	Sing C major scale and the harmony parts will create suitable chord notes based on the C major scale. You can edit the key root and type by "Harmony Assign" setting  on the Vocal Harmony display.
BalladChoir	12	11	On	On	Good for Ballad backing vocals with long reverb.
ChurchChoir	12	12	On	On	Good for standard church songs and Christmas songs with long reverb; recommended for Bass, Tenor and Alto voice.
GregorianChoir	12	13	On	On	Good for rubato Gregorian-chant-type monophonic songs with large reverb; parallel movement of all parts.
GospelChoir	12	14	On	On	Good for Gospel songs with long reverb on harmony parts and minor 7th feel.
CosmicChoir	12	42	On	On	Extreme phasing vocals; useful for exciting effects in Dance and Modern Music.
AlpenGirls	12	15	On	On	Good for male singer with 2 female harmony parts above lead vocal.
CountryRock	12	16	On	On	Typical Country Rock quartet; recommended range is tenor/alto.
R&BDiva	12	17	On	On	Good for female alto singer for R&B repertoire; also usable with Tenor lead vocal.
ClosedPopChicks	12	18	On	On	Good for female singers with two harmony parts below. Change volume of Harm.3 for an additional (3rd) part below.
QueenOfPop	12	43	Off	On	Good for Pop and R&B songs using Tempo Delay. Turn the "Harmony" on the Vocal Harmony display on to add 2nd Voice.
Bob->Mary	12	19	On	On	Male singer can sound like Female voice with long romantic reverb. Use "Balance" on the Vocal Harmony display to add a male duet partner.
Mary->Bob	12	20	On	Off	Female singer can sound like Male voice with short reverb. Use "Balance" on the Vocal Harmony display to add a female duet partner.
FlangingVocals	12	44	Off	On	Useful for modern Pop, Rock and Dance music.
JazzySisters	12	21	On	On	Good for Bass and Tenor Singers. Harmony parts add 3 female Jazz singers.
QuartetOnStage	12	22	On	On	Good for Rock and Pop Music. Harmony parts make up a quartet.
DelayedHarmony	12	45	On	On	Useful in several genres with a tempo-synced delay choir as background.
KidsChoir	12	23	On	Off	Want to be a child again? Use this preset type and sing with your friends...
ChorusChoir	12	46	On	On	The chorus effect adds a rich and exciting characteristics to your voice and the harmony parts.
BohemianVocode	12	47	On	On	Tempo flanging Vocoder Type; good for Rock or Pop songs and Intros.
RobotVoice	12	48	On	On	Do you want to sound like a robot? This is the setting. Use Harm.3 for variation.
ChordalXG	90	0	On	Off	CHORDAL type setting of previous Vocal Harmony system.
DetuneXG	91	0	On	Off	DETUNE type setting of previous Vocal Harmony system.
ChromaticXG	92	0	On	Off	CHROMATIC type setting of previous Vocal Harmony system.
VocoderXG	89	0	On	Off	VOCODER type setting of previous Vocal Harmony system.
Thru	64	0	Off	Off	Bypass without any harmonies and effects.

Vocal Effect Type List / Liste der Gesangseffekt-Typen / Liste des types d'effets vocaux / Lista de tipos de efectos vocales / Lista de tipos de efeito vocal

Type Name	Description	MSB	LSB
Romantic Rev (Romantic Reverb)	Long reverb for vocal part. Romantic image.	1	0
80s Pop Rev (80s'Pop Reverb)	Long reverb for vocal part. 80's pop image.	1	16
Room	Reverb simulating the acoustics of a room.	2	0
Stage (Concert Stage)	Reverb simulating the concert stage.	3	0
Plate	Reverb simulating a plate reverb unit.	4	0
VocalDoubler	Immediate delay with center focused feeling.	5	16
StereoSpread	Immediate delay with spread feeling.	5	17
Delay	Produces simple delayed sounds: L, R, and C (center).	5	0
Short Delay	Produces short delayed sound with narrow image.	5	1
R&R Delay (Rock&Roll Delay)	Produces slap back echo sound. Good for Rock&Roll music.	5	18
Cross Delay	The feedback of the two delayed sounds is crossed.	8	0
Tempo Delay	Tempo-synchronized delay.	21	0
Tempo Cross (Tempo Cross Delay)	Tempo-synchronized cross delay.	22	0
Chorus	Conventional chorus program with rich, warm chorusing.	66	0
EQ Hi-Fi	Equalizer effect that boosts both high and low frequencies.	76	16
EQ Tel	Equalizer effect that cuts both high and low frequencies.	76	0
Gramophone	Produces Lo-Fi sound with gramophone image.	94	0
Robot	Produces Lo-Fi sound with robotic image.	94	16
Overdriven	Produces overdriven sound. Good for rock and dance music.	98	0
Scream&Shout	Produces heavy distorted sound.	98	16
TempoFlanger	Tempo-synchronized flanger.	107	0
TempoPhaser	Tempo-synchronized phaser.	108	0
TempoAutoPan	Tempo-synchronized auto pan.	121	0
No Effect	No effect.	0	0

Parameter Chart / Parametertabelle / Tableau des paramètres / Gráfico de parâmetros / Gráfico de parâmetro

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Home															
Voice (Left)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Style	-
Voice (Main)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Voice	-
Voice (Layer)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Voice	-
Part On/Off (Main)	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Voice	-
Part On/Off (Layer)	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Voice	-
Part On/Off (Left)	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Style	-
Song (MIDI/Audio)	○	○	×	×	×	×	×	-	×	-	×	×	○	Song	-
Registration Area Show/Hide	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Style	○	○	×	×	×	×	×	-	×	-	×	×	○	Style	-
Home (MIDI Song)															
Extra On/Off	○	○	×	×	×	×	×	-	×	-	×	×	○	Song	-
Left On/Off	○	○	×	×	×	×	×	-	○	Guide Setting	×	×	○	Song	-
Right On/Off	○	○	×	×	×	×	×	-	○	Guide Setting	×	×	○	Song	-
Channels Show/Hide on Song Recording Window	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Home (Audio Song)															
Pitch Shift	○	○	×	×	×	×	×	-	×	-	×	×	○	Song	-
Time Stretch	○	○	×	×	×	×	×	-	×	-	×	×	○	Song	-
Vocal Cancel	○	○	×	×	×	×	×	-	×	-	×	×	○	Song	-
Style Control															
ACMP On/Off	○	○	×	×	×	×	×	-	×	-	×	○ (On)	○	Style	-
Auto Fill In	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Section	○	○	×	×	×	×	×	-	×	-	×	×	○	Style	-
Sync Start	○	○	×	×	×	×	×	-	×	-	×	○ (On)	○	Style	-
Sync Stop	○	○	×	×	×	×	×	-	×	-	×	×	○	Style	-
Transpose															
Transpose	○	○	×	×	×	×	×	-	×	-	×	×	○	Transpose	-
Tempo															
Master Tempo	○	○	×	×	×	×	×	-	○	Tempo	○	×	○	Tempo	-
Song															
Synchro Start	○	○	×	×	×	×	×	-	×	-	×	×	○	Song	-
Channel On/Off	○	○	×	×	×	×	×	-	×	-	×	×	○	Song	-
Registration															
Regist Memory Contents	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Items to Register Show/Hide on Registration Memory Window	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Regist Contents Name	○	○	×	×	×	×	×	-	×	-	×	×	○	-	-
One Touch Setting															
OTS Link	○	○	×	×	×	○ (On)	×	-	×	-	×	×	×	-	-
Menu															
Short Cut	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Split Point & Fingering															
Split Point (Left)	○	○	○	×	×	×	×	-	×	-	×	×	○	Style	Split Point
Split Point (Style)	○	○	○	×	×	×	×	-	○	Guide Setting	×	×	○	Style	Split Point
Fingering Type	○	○	○	×	×	×	×	-	×	-	×	×	○	Style	Fingering Type
Chord Detection Area	○	○	○	×	×	×	×	-	○	Guide Setting	×	×	○	Style	-
Manual Bass	○	○	○	×	×	×	×	-	○	Guide Setting	×	×	○	Style	-
Transpose															
Master Transpose	○	○	×	×	×	×	×	-	×	-	×	×	○	Transpose	-
Song Transpose	○	○	×	×	×	×	×	-	×	-	×	×	○	Transpose	-
Keyboard Transpose	○	○	×	×	×	×	×	-	×	-	×	×	○	Transpose	-
Transpose Assign	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Balance															
Offset Volume Style	○	○	×	×	×	×	×	-	×	-	×	×	○	Style	-
Volume Left	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Style	-
Volume Main	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Voice	-
Volume Layer	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Voice	-
Volume Mic	○	○	×	×	×	×	×	-	○	Vocal Harmony/Mic Setting	×	×	○	Vocal Harmony/Mic Setting	Vocal Harmony/Mic Setting

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Offset Volume Song	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Aux In Volume	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–
WLAN Volume	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–
Piano Room															
Voice	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Style	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Style Part On/Off	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Detail Setting															
Environment	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Lid Position	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Tune	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Dynamics Control	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Section Control	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Fingering Type	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Split Point	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Piano Lock	○	○	○	×	×	×	×	–	×	–	×	×	×	–	–
Score															
View Setting															
Size	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Left On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Right On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Chord On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Lyrics On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Pedal On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Note On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Fingering On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Color On/Off	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Detail Setting															
Right Ch	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Left Ch	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Key Signature	○	○	×	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Quantize	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Note Name	○	○	○	×	×	×	×	–	○	Score Setting	×	×	×	–	–
Lyrics															
Background (*1)	○	○	○	×	×	×	×	–	○	Lyrics Setting	×	×	×	–	–
Text Viewer															
Text File	○	○	×	×	×	×	×	–	×	–	×	×	○	Text	–
Mixer															
Panel															
Filter															
Harmonic Content (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Harmonic Content (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Harmonic Content (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Brightness (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Brightness (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Brightness (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
EQ															
High Gain (Style) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
High Gain (Left)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Style	–
High Gain (Main)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
High Gain (Layer)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
High Gain (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–
Low Gain (Style) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Low Gain (Left)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Style	–
Low Gain (Main)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
Low Gain (Layer)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
Low Gain (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Effect															
Insertion Effect Depth (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	–
Insertion Effect Depth (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Depth (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Depth (Mic)	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Chorus/Reverb															
Reverb Depth (Style) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Reverb Depth (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	–
Reverb Depth (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Reverb Depth (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Reverb Depth (Mic)	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Reverb Depth (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–
Chorus Depth (Style) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Chorus Depth (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	–
Chorus Depth (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Chorus Depth (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Chorus Depth (Mic)	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Chorus Depth (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–
Pan/Volume															
Pan (Style) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Pan (Left)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–
Pan (Main)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Pan (Layer)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Pan (Mic)	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Pan (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	×	–	–
Volume (Style) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Style	–
Volume (Left)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Style	–
Volume (Main)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Volume (Layer)	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Voice	–
Volume (Mic)	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Volume (Song) Offset	○	○	×	×	×	×	×	–	×	–	×	×	○	Song	–
Style															
Filter															
Harmonic Content	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Brightness	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
EQ															
Low Gain	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
High Gain	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Effect															
Insertion Effect Depth	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Chorus/Reverb															
Reverb Depth	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Chorus Depth	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Pan/Volume															
Pan	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Volume	○	○	×	×	×	×	×	–	×	–	○	×	○	Style	–
Song Ch 1-8															
Song Ch 9-16															
Filter															
Harmonic Content Song Part	○	○	×	×	×	×	×	–	○	Filter	×	×	×	–	–
Brightness Song Part	○	○	×	×	×	×	×	–	○	Filter	×	×	×	–	–
EQ															
EQ Low Gain Song Part	○	○	×	×	×	×	×	–	○	EQ	×	×	×	–	–
EQ High Gain Song Part	○	○	×	×	×	×	×	–	○	EQ	×	×	×	–	–
Effect															
Insertion Effect Depth Song Part	○	○	×	×	×	×	×	–	○	Effect	×	×	×	–	–

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group	
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group		
Chorus/Reverb																
Reverb Depth Song Part	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Chorus Depth Song Part	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Pan/Volume																
Part Volume Song	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Volume	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Part Pan Song	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Pan	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Master																
Compressor																
On/Off	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Type	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Threshold Offset	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Ratio Offset	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Output Offset	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
EQ																
Type	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Master EQ
Parameter	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Master EQ
Channel On/Off																
Channel On/Off (Song)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Song	<input type="checkbox"/>
Channel On/Off (Style)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style	<input type="checkbox"/>
Voice																
Voice (Style)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style	<input type="checkbox"/>
Voice (Song)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Voice	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Reverb																
Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style/Song	Reverb Type
Return Level	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style/Song	Reverb Return Level
Chorus																
Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style/Song	<input type="checkbox"/>
Return Level	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style/Song	Chorus Return Level
Assign Detail Setting																
Variation Effect Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style/Song	<input type="checkbox"/>
Variation Effect Return Level	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style/Song	Variation Effect (System) Return Level
Insertion Effect 1 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/Song	<input type="checkbox"/>
Insertion Effect 2 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/Song	<input type="checkbox"/>
Insertion Effect 3 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect/ Vocal Harmony/ Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/ Song/ Mic Setting	Vocal Harmony/ Mic Setting
Insertion Effect 3 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/Song	<input type="checkbox"/>
Insertion Effect 4 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/Song	<input type="checkbox"/>
Insertion Effect 5 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/Song	<input type="checkbox"/>
Insertion Effect 6 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect/ Vocal Harmony/ Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style/Song/ Mic Setting	Vocal Harmony/ Mic Setting
Insertion Effect 7 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style	<input type="checkbox"/>
Insertion Effect 8 Type	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Style	<input type="checkbox"/>
Effect Parameter (Reverb/Chorus/Variation)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Effect Parameter (Insertion 1-2)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/Song	<input type="checkbox"/>
Effect Parameter (Insertion 3)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect/ Vocal Harmony/ Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/ Song/ Mic Setting	Vocal Harmony/ Mic Setting
Effect Parameter (Insertion 1-5)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voice/Style/Song	<input type="checkbox"/>
Effect Parameter (Insertion 6)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Effect/ Vocal Harmony/ Mic Setting	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Song/ Mic Setting	Vocal Harmony/ Mic Setting
Effect Parameter (Insertion 7-8)	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Music Finder																
Sort By	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Sort Order	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Search Keyword	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Record	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Keyboard Harmony															
Harmony/Echo	○	○	×	×	×	×	×	–	○	Keyboard Voice	×	○	○	Harmony	–
Type	○	○	×	×	×	×	○	Keyboard Harmony	○	Keyboard Voice	×	○	○	Harmony	–
Volume	○	○	×	×	×	×	○	Keyboard Harmony	○	Keyboard Voice	×	○	○	Harmony	–
Speed	○	○	×	×	×	×	○	Keyboard Harmony	○	Keyboard Voice	×	○	○	Harmony	–
Assign	○	○	×	×	×	×	○	Keyboard Harmony	○	Keyboard Voice	×	○	○	Harmony	–
Chord Note Only	○	○	×	×	×	×	○	Keyboard Harmony	○	Keyboard Voice	×	○	○	Harmony	–
Minimum Velocity	○	○	×	×	×	×	○	Keyboard Harmony	○	Keyboard Voice	×	○	○	Harmony	–
Mic Setting															
EQ Low Frequency	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
EQ Low Gain	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
EQ Mid Frequency	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
EQ Mid Gain	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
EQ High Frequency	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
EQ High Gain	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Noise Gate On/Off	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Noise Gate Threshold	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Compressor On/Off	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Compressor Threshold	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Compressor Ratio	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Compressor Out	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Pitch Detect Vocal Type	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Pitch Detect Background Noise Cut	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Pitch Detect Speed	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
User Setting	○	○	○	×	○	×	×	–	×	–	×	×	×	–	–
Mic Volume	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Talk Setting															
Talk Setting Volume	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk Setting Pan	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk Setting Reverb Depth	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk Setting Chorus Depth	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk Setting Reduction Level	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk EQ Low Frequency	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk EQ Low Gain	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk EQ Mid Frequency	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk EQ Mid Gain	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk EQ High Frequency	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk EQ High Gain	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk Noise Gate On/Off	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk Noise Gate Threshold	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk Compressor On/Off	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk Compressor Threshold	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk Compressor Ratio	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Talk Compressor Out	○	○	×	×	○	×	×	–	×	–	×	×	×	–	–
Vocal Harmony															
On/Off	○	○	×	×	○	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Type	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Mode	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Song Channel	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Keyboard	○	○	×	×	×	×	×	–	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Song Channel Mute/Play	○	○	×	×	×	×	×	–	×	–	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Balance	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Chord Source	○	○	×	×	×	×	×	-	×	-	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Chordal Type	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Effect On/Off	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Effect Type	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Effect Depth To Lead	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Effect Depth To Harmony	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Reverb Depth	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Chorus Depth	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony Edit															
Transpose Mode	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Pitch Correct	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Session Table	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Key Root	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Key Type	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Lead Pitch Detect Speed	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony Pitch Detect Speed	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony Effect	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony Stability	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Lead Vibrato Depth	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony Vibrato Depth	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Vibrato Speed	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Vibrato Delay	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Part Mixer															
Lead Transpose	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Lead Detune	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Lead Formant	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Lead Volume	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Lead Pan	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Lead Octave	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 1 Transpose	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 1 Detune	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 1 Formant Shift	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 1 Volume	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 1 Pan	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 1 Degree	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Harmony 2 Transpose	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 2 Detune	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 2 Formant Shift	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 2 Volume	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 2 Pan	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 2 Degree	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 3 Transpose	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 3 Detune	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 3 Formant Shift	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 3 Volume	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 3 Pan	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Harmony 3 Degree	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Vocal Harmony Effect															
Parameters	○	○	×	×	○	×	×	-	○	Vocal Harmony/ Mic Setting	×	×	○	Vocal Harmony/ Mic Setting	Vocal Harmony/ Mic Setting
Voice Edit															
Common															
Volume (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Volume (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Volume (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
Touch Sense Depth (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Touch Sense Depth (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Touch Sense Depth (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
Touch Sense Offset (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Touch Sense Offset (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Touch Sense Offset (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
Part Octave (Main/Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Part Octave (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
Sound															
Mono/Poly (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Mono/Poly (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Mono/Poly (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
EG Attack (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
EG Attack (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
EG Attack (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
EG Decay (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
EG Decay (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
EG Decay (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
EG Release (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
EG Release (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
EG Release (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
Vibrato Depth (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Vibrato Depth (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Vibrato Depth (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
Vibrato Speed (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Vibrato Speed (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Vibrato Speed (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
Vibrato Delay (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Vibrato Delay (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Vibrato Delay (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
Modulation Filter (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Modulation Filter (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Modulation Filter (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Modulation Amplitude (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation Amplitude (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation Amplitude (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Modulation LFO Pitch (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation LFO Pitch (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation LFO Pitch (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Modulation LFO Filter (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation LFO Filter (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation LFO Filter (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Modulation LFO Amplitude (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation LFO Amplitude (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Modulation LFO Amplitude (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Effect															
Insertion Effect On/Off (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Type (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect On/Off (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Type (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect On/Off (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Type (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Variation On/Off (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Variation Value (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Variation On/Off (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Variation Value (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Variation On/Off (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Variation Value (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	–
Insertion Effect Type Parameter (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Type Parameter (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Insertion Effect Type Parameter (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Vibe Rotor On/Off (Main)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Vibe Rotor On/Off (Layer)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Voice	–
Vibe Rotor On/Off (Left)	○	○	×	×	×	×	○	Effect	○	Keyboard Voice	×	○	○	Style	–
EQ															
EQ Low Freq (Main)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
EQ Low Freq (Layer)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
EQ Low Freq (Left)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Style	–
EQ High Freq (Main)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
EQ High Freq (Layer)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Voice	–
EQ High Freq (Left)	○	○	×	×	×	×	○	EQ	○	Keyboard Voice	×	○	○	Style	–
Pedal															
Function Assign	○	○	×	×	×	×	○	Pedal	○	Keyboard Voice	×	○	○	Pedal	–
Detail Setting	○	○	×	×	×	×	○	Pedal	○	Keyboard Voice	×	○	○	Pedal	–
Organ Flute															
Footage (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Footage (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Footage (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–
Type (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Type (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Type (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–
Vibrato On/Off (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Vibrato On/Off (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Vibrato On/Off (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–
Vibrato Depth (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Vibrato Depth (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Vibrato Depth (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Vibrato Speed (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Vibrato Speed (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	–
Vibrato Speed (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	–
Attack Footage (Main)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Attack Footage (Layer)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Voice	–
Attack Footage (Left)	○	○	×	×	×	×	○	–	○	Keyboard Voice	×	○	○	Style	–

Parameter	CVP-705	CVP-709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Attack Mode (Main)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Voice	-
Attack Mode (Layer)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Voice	-
Attack Mode (Left)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Style	-
Attack Length (Main)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Voice	-
Attack Length (Layer)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Voice	-
Attack Length (Left)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Style	-
Response (Main)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Voice	-
Response (Layer)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Voice	-
Response (Left)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Style	-
Volume (Main)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Voice	-
Volume (Layer)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Voice	-
Volume (Left)	○	○	×	×	×	×	○	-	○	Keyboard Voice	×	○	○	Style	-
Style Creator															
Basic															
Pattern Length	○	○	×	×	×	×	×	-	×	-	○	×	×	-	-
Tempo	○	○	×	×	×	×	×	-	×	-	○	×	×	-	-
Beat	○	○	×	×	×	×	×	-	×	-	○	×	×	-	-
Rec Channel															
Step Edit															
Main Filter	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Control Change Filter	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
SFF Edit															
Play Root															
Play/Source Root	○	○	×	×	×	×	×	-	×	-	○	×	×	-	-
Play/Source Chord	○	○	×	×	×	×	×	-	×	-	○	×	×	-	-
NTR/NTT															
NTR	○	○	×	×	×	×	×	-	×	-	○	×	×	-	-
NTT	○	○	×	×	×	×	×	-	×	-	○	×	×	-	-
NTT Bass	○	○	×	×	×	×	×	-	×	-	○	×	×	-	-
High Key/Note Limit															
High Key	○	○	×	×	×	×	×	-	×	-	○	×	×	-	-
Note Limit Low	○	○	×	×	×	×	×	-	×	-	○	×	×	-	-
Note Limit High	○	○	×	×	×	×	×	-	×	-	○	×	×	-	-
RTR															
RTR	○	○	×	×	×	×	×	-	×	-	○	×	×	-	-
Song Creator															
Setup															
Setup Select	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Step Edit															
Main Filter	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Control Change Filter	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Style Filter	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Regist Sequence															
Regist Sequence Data	○	○	×	×	×	×	×	-	×	-	×	×	○	-	-
Regist Sequence On/Off	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Regist+ Pedal	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Regist- Pedal	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Sequence End	○	○	×	×	×	×	×	-	×	-	×	×	○	-	-
Voice Setting															
Tune															
Tuning Main	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Voice	-
Tuning Layer	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Voice	-
Tuning Left	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Style	-
Octave (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Octave (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Octave (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
Pitch Bend Range (Main)	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Voice	-
Pitch Bend Range (Layer)	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Voice	-
Pitch Bend Range (Left)	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Style	-

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Portamento Time (Main)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Portamento Time (Layer)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Voice	-
Portamento Time (Left)	○	○	×	×	×	×	○	Voice	○	Keyboard Voice	×	○	○	Style	-
Piano															
VRM On/Off	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Damper Resonance	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
String Resonance	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Reverb Depth	○	○	×	×	×	×	×	-	×	-	×	×	○	Voice	-
Chorus Depth	○	○	×	×	×	×	×	-	×	-	×	×	○	Voice	-
Tuning Curve	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Key Off Sampling	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Voice Set															
Voice Set On/Off (Main)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Voice Set On/Off (Layer)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Voice Set On/Off (Left)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Setting															
Category Button	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
SA2 Auto Articulation		○	○	×	×	×	×	-	×	-	×	×	×	-	-
Style Setting															
Setting															
Dynamics Control	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Display Tempo	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Stop ACMP	○	○	○	×	×	×	×	-	×	-	×	×	○	Style	-
ACMP On/Off Default	○	○	○	×	×	×	×	-	×	-	×	×	○	Style	-
OTS Link Timing	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Syncho Stop Window	○	○	○	×	×	×	×	-	×	-	×	×	○	Style	-
Change Behavior															
Section Set	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Tempo	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Part On/Off	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Music Finder Style Tempo	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Song Setting															
Guide															
Type	○	○	○	×	×	×	×	-	○	Guide Setting	×	×	×	-	-
Lamp	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Lamp Timing	○	○	○	×	×	×	×	-	○	Guide Setting	×	×	×	-	-
Part Ch															
Right	○	○	○	×	×	×	×	-	○	-	×	×	×	-	-
Left	○	○	○	×	×	×	×	-	○	-	×	×	×	-	-
Auto Set	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Lyrics															
Language	○	○	○	×	×	×	×	-	○	Lyrics Setting	×	×	×	-	-
Play															
Repeat Mode	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Quick Start	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
MIDI Song Fast Forward Type	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
USB MIDI Song Auto Open	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Chord Detection Priority	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Rec															
Audio Rec Format	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Metronome															
Metronome															
Volume	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Sound	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Time Signature	○	○	×	×	×	×	×	-	○	-	○	×	×	-	-
Tap Tempo															
Volume	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Style	-
Sound	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Style	-

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Tuning															
Master Tune															
Master Tune	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Scale Tune															
Scale Type	○	○	×	×	×	×	×	-	×	-	×	×	○	Scale	-
Base Note	○	○	×	×	×	×	×	-	×	-	×	×	○	Scale	-
Tune	○	○	×	×	×	×	×	-	×	-	×	×	○	Scale	-
Part Select	○	○	×	×	×	×	×	-	×	-	×	×	○	Scale	-
Keyboard															
Keyboard															
Touch Curve	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Fixed Velocity	○	○	×	×	×	×	×	-	×	-	×	×	○	Voice	-
Touch Response Part On/Off	○	○	×	×	×	×	×	-	×	-	×	×	○	Voice	-
Left Hold	○	○	×	×	×	×	×	-	○	Keyboard Voice	×	○	○	Style	-
Assignable															
Pedal															
Function Assign	○	○	×	×	×	×	○	Pedal	○	Keyboard Voice	×	○	○	Pedal	-
Detail Setting	○	○	×	×	×	×	○	Pedal	○	Keyboard Voice	×	○	○	Pedal	-
Depends On Main Voice	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
AUX Pedal Polarity	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Fade In Time	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Fade Out Time	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Fade Out Hold Time	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Assignable															
Function Assign	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Detail Setting	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Registration Freeze															
Setting	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
MIDI															
Setting	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Preset Setting Name	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
System															
Local Control	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Clock	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Transmit Clock	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Transpose MIDI Input	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Start/Stop	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
SysEx Transmit	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
SysEx Receive	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Chord SysEx Transmit	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Chord SysEx Receive	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Transmit															
Ch	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Filter	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Receive															
Part	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Filter	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
On Bass Note															
Bass (On Bass Note)	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Chord Detect															
Chord Detect	○	○	×	○	×	×	×	-	×	-	×	×	×	-	-
Utility															
Speaker/Connectivity															
Speaker	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Stereophonic Optimizer	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
IAC	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
IAC Depth	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
AUX In Noise Gate	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Content (*1)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-

Parameter	CVP -705	CVP -709	Backup/Restore				Voice Set	Voice Set Group	Song		Style		Registration		Parameter Lock Group
			System	MIDI	User Effect	Music Finder			Song	Song Setup Group	Style Data	OTS	Regist	Freeze Group	
Display															
Home Theme	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
LCD Brightness	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Time Stamp	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Pop-up Display Time	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Transition Effect	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Voice Area	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Touch Sound	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Parameter Lock															
Parameter Lock	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
System															
Language (*1)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Owner Name (*1)	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Auto Power Off	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Voice Guide	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Voice Guide Controller	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-
Voice Guide Volume	○	○	○	×	×	×	×	-	×	-	×	×	×	-	-

*1: Cannot be reset with Factory Reset.



ZN97450

Manual Development Department
© 2015 Yamaha Corporation

Published 04/2015 MWAP*.*.**C0

ZN97450